

90218701
3rd copy

U C L A
ENVIRONMENTAL
SCIENCE &
ENGINEERING


19960419 187



DISTRIBUTION STATEMENT A

Approved for public release;
Distribution Unlimited

DISCLAIMER NOTICE



THIS DOCUMENT IS BEST QUALITY AVAILABLE. THE COPY FURNISHED TO DTIC CONTAINED A SIGNIFICANT NUMBER OF PAGES WHICH DO NOT REPRODUCE LEGIBLY.



April 26, 1990

ENVIRONMENTAL SCIENCE AND ENGINEERING
SCHOOL OF PUBLIC HEALTH
10833 LE CONTE AVENUE
LOS ANGELES, CALIFORNIA 90024-1772Mark Besmer
Program Manager's Office for
Rocky Mountain Arsenal Contamination Cleanup
Building 111
Commerce City, Colorado 80022-2188

Dear Mark:

You asked for some clarification regarding the "conservative, nontoxic tracer" we would propose to use in field studies near the Basin F area at the Arsenal. In all good field work on contaminant transport in groundwater, one or more chemicals, usually simple salts (discussed below), are added to serve as conservative tracers. This has been the case in a variety of field experiments conducted by universities, U.S. Geological Survey and Canadian governmental research agencies, as detailed below. The term "conservative" implies that the chemical does not adsorb to the geologic medium (sand, silt, clay, etc.) nor does it degrade or transform during its passage through the medium. With these properties, the tracer mimics the movement of the water itself. By comparing the tracer behavior to that of the contaminants, it is possible to unambiguously determine if the contaminants are adsorbed or degraded as they move through the medium. If no tracer is used, the interpretation of the behavior of the contaminants is difficult if not impossible, especially when quantitative estimates of transport parameters are desired such as in our work.

The chemicals that have generally been used as conservative tracers in previous field work (and confirmed to act conservatively, i.e. not adsorb or degrade) are simple salts containing chloride, bromide or iodide, such as sodium chloride (table salt), potassium chloride, sodium bromide, potassium bromide, potassium iodide, etc. Whether the salt contains sodium or potassium is generally a matter of whichever salt is cheaper, more available, etc. Examples of tracers used in previous field work are the following:

Sodium Chloride and Potassium Bromide

Canadian Forces Base Borden, Ontario, Canada.

This was a field experiment on organic contaminant transport in a sand aquifer impacted by a plume of contamination from a landfill. The work was conducted by Stanford University in collaboration with the University of Waterloo; I was the designer and implementer of the experiment. Approval for the work was obtained from the Canadian Forces by Professor John Cherry of the University of Waterloo. Two tracers were used for redundancy; both behaved conservatively for over three years of observation. Results are published in December 1986 issue of the scientific journal Water Resources Research. This work was sponsored by the U.S. E.P.A.

Sodium Iodide

Gloucester, Ontario, Canada.

This was a field experiment to determine the rate at which contaminants from a hazardous waste landfill could be flushed from a sand aquifer. The work was conducted by the Canadian National Hydrology Research Institute in Ottawa, Canada. The concern was that the organic contaminants were migrating towards a water supply and information on their rate of migration was needed to plan the cleanup. Thus the tracer was crucial to their experiment.

Sodium Bromide

Mobile, Alabama.

This was a large field experiment on tracer behavior in a layered sand aquifer. No organic contaminants were present. The main purpose was to use the tracer to determine the relative permeability of the various layers in the aquifer. This work was sponsored by the U.S.E.P.A. It has been described in numerous publications in scientific journals such as Water Resources Research, Ground Water, etc.

Lithium Bromide

Otis Air Force Base, Cape Cod, Massachusetts.

This was a large scale field experiment on solute transport in a sand aquifer impacted by sewage infiltration beds. The work was conducted by the United States Geological Survey in collaboration with the Massachusetts Institute of Technology. The lithium salt was used because of interest in the behavior of lithium itself, which was not conservative (i.e. interacted with the geologic medium). The bromide tracer was shown to have been conservative over a span of several years in a paper now in press in the scientific journal Water Resources Research. Aspects of the work are also described in a recent article in the journal Science (vol. 247, pp.1569-1572, March 1990).

Potassium Bromide

Moffett Naval Air Station, Mountain View, California.

This is an ongoing evaluation of in-situ bioremediation being conducted in a sand/gravel aquifer by Stanford University. I was managing the project at its start before I moved to UCLA, and secured approval from the California Regional Water Quality Control Board and the Environmental Protection Agency prior to beginning the field research. Since that time, there have been many short term experiments involving the injection of the tracer. It has been shown to be conservative in its behavior in a report available through the National Technical Information Service (NTIS #PB88-130257, Nov 87) and a paper now in press in the scientific journal Ground Water. This work is funded by the U.S.E.P.A.

Potassium Iodide

Rocky Mountain Arsenal, Commerce City, Colorado.

This was the experiment I conducted with my group from UCLA and in collaboration with Ebasco, Inc. and R.L. Stollar and Associates. The experiment, conducted in Summer 1988, determined the rate of flushing of two organic contaminants from the sand aquifer. Iodide was used as the tracer since 1) background chloride levels were too high for use to use chloride as a tracer, 2) the various parties reviewing our plans readily accepted iodide as a harmless, nontoxic chemical (since it is used in table salt as a nutritional supplement), and 3) we guessed that the parties were less familiar with potassium bromide and chose not to attempt an argument for it.


Not all field studies are listed above, but this brief review illustrates that the most frequently used tracers are bromide salts. They have been used for studies in contaminated aquifers in the U.S. and Canada by a variety of researchers, all working with government funding. Of course, one would prefer not to add salt to an aquifer, but it is generally acknowledged that the very slight degradation caused by the use of the tracer is absolutely insignificant by comparison to the improvement in

understanding of the behavior of the much more worrisome contaminants, and the corresponding improvement in understanding of how to manage or clean up the contamination problem.

In any future work we might receive approval to conduct at the Rocky Mountain Arsenal, we would prefer to use sodium or potassium bromide, with sodium or potassium iodide as a second choice. Like all chemicals, including table salt, these salts possess some toxicity to animals if the dose is extremely high (several hundred to thousand milligrams per kilogram body weight). No such exposures would be remotely possible in our work. We plan to inject into the aquifer a 24-48 hour pulses of the tracer in concentrations on the order of 300 milligrams per liter, which is actually quite low (roughly equivalent to a quarter teaspoon of salt in a glass of water). No person is likely to be exposed even to those concentrations, of course, since the groundwater on the Arsenal near Basin F is contaminated with organic compounds and is not used for drinking. However, even if they were, it is unlikely the bromide or iodide salts would have a detrimental or even noticeable impact: for example, potassium bromide has medicinal use in lower doses as a sedative (hence the now outdated expression "take a bromide"), while potassium iodide is routinely added to table salt as a nutritional supplement.

I hope this addresses the issue we discussed. If I can provide any additional information, please let me know. Thanks for your continued interest in this work. I think the proposed project will prove very useful for your management or cleanup efforts while also very intriguing from a scientific point of view.

Sincerely,

A handwritten signature in cursive script that reads "Douglas M. Mackay". The signature is written in dark ink and is positioned above the typed name.

Douglas M. Mackay
Assistant Professor

cc: R. Stollar, R.L. Stollar and Associates
K. Glover, R.L. Stollar and Associates

REPORT DOCUMENTATION PAGE

Form Approved
OMB No. 0704-0188

Public reporting burden for this collection of information is estimated to average 1 hour per response, including the time for reviewing instructions, searching existing data sources, gathering and maintaining the data needed, and completing and reviewing the collection of information. Send comments regarding this burden estimate or any other aspect of this collection of information, including suggestions for reducing this burden, to Washington Headquarters Services, Directorate for Information Operations and Reports, 1215 Jefferson Davis Highway, Suite 1204, Arlington, VA 22202-4302, and to the Office of Management and Budget, Paperwork Reduction Project (0704-0188), Washington, DC 20503.

| | | | | | |
|---|---|--|----------------------------|---|--|
| 1. AGENCY USE ONLY (Leave blank) | | 2. REPORT DATE 04/00/90 | | 3. REPORT TYPE AND DATES COVERED | |
| 4. TITLE AND SUBTITLE FLUSHING OF ORGANIC CONTAMINANTS FROM A GROUNDWATER PLUME AT THE ROCKY MOUNTAIN ARSENAL | | | | 5. FUNDING NUMBERS | |
| 6. AUTHOR(S) MACKAY, D.; THORBJARNARSON, K. | | | | | |
| 7. PERFORMING ORGANIZATION NAME(S) AND ADDRESS(ES) UNIVERSITY OF CALIFORNIA, LOS ANGELES. SCHOOL OF PUBLIC HEALTH LOS ANGELES, CA | | | | 8. PERFORMING ORGANIZATION REPORT NUMBER 90218R01 | |
| 9. SPONSORING/MONITORING AGENCY NAME(S) AND ADDRESS(ES) | | | | 10. SPONSORING/MONITORING AGENCY REPORT NUMBER | |
| 11. SUPPLEMENTARY NOTES | | | | | |
| 12a. DISTRIBUTION/AVAILABILITY STATEMENT APPROVED FOR PUBLIC RELEASE; DISTRIBUTION IS UNLIMITED | | | | 12b. DISTRIBUTION CODE | |
| 13. ABSTRACT (Maximum 200 words) DURING THE SUMMER OF 1988, UCLA CONDUCTED A FIELD EXPERIMENT ON FLUSHING OF ORGANIC CONTAMINANTS FROM A CONTAMINATED AQUIFER IN THE WESTERN TIER OF RMA. THE OBJECTIVES OF THE STUDY WERE TO: 1. ESTIMATE THE HYDRAULIC CONDUCTIVITY OF THE AQUIFER 2. ESTIMATE THE DEGREE TO WHICH TRCLE AND 111TCE ARE RETARDED IN THEIR MOBILITY DUE TO SORPTION BY THE AQUIFER MEDIA 3. DETERMINE THE EFFECTS OF SPATIAL VARIABILITY OF AQUIFER PROPERTIES ON WATER FLOW AND TRCLE AND 111TCE FLUSHING RATES 4. COMPARE RESULTS OF FIELD AND LABORATORY INVESTIGATIONS. THE LABORATORY ANALYSES OF CORING SAMPLES INDICATED THAT BOTH THE HYDRAULIC CONDUCTIVITY OF THE AQUIFER AND THE TRCLE MOBILITY ARE LIKELY TO VARY SIGNIFICANTLY WITH DEPTH. THE FIELD EXPERIMENT CONSISTED OF 1) AIR STRIPPING EXTRACTED WATER, 2) SPIKING IT WITH A TRACER, AND 3) REINJECTING IT. THE FIELD DATA SHOW THAT FLUSHING WILL BE VERY EFFICIENT IN THE HIGHLY PERMEABLE STRATA, | | | | | |
| 14. SUBJECT TERMS LABORATORY STUDIES, WELL CONSTRUCTION, HYDRAULIC CONDUCTIVITY ESTIMATES | | | | 15. NUMBER OF PAGES | |
| | | | | 16. PRICE CODE | |
| 17. SECURITY CLASSIFICATION OF REPORT UNCLASSIFIED | 18. SECURITY CLASSIFICATION OF THIS PAGE | 19. SECURITY CLASSIFICATION OF ABSTRACT | 20. LIMITATION OF ABSTRACT | | |

**FLUSHING OF ORGANIC CONTAMINANTS
FROM A GROUND WATER PLUME AT THE
ROCKY MOUNTAIN ARSENAL:
VOLUME II. APPENDICES**

Douglas M. Mackay, Ph.D
Kathryn W. Thorbjarnarson
UCLA School of Public Health
Environmental Science and Engineering
Los Angeles, CA 90024-1772

ES&E Tech. Report No. 90-69
April 1990

TABLE OF CONTENTS

| | |
|--|-----|
| INTRODUCTION | 1 |
| APPENDIX A. GRAIN SIZE PARAMETERS | 2 |
| APPENDIX B. LABORATORY HYDRAULIC CONDUCTIVITY ESTIMATES . . | 51 |
| APPENDIX C. LOCATION AND CONSTRUCTION OF WELLS | 61 |
| APPENDIX D. SOLUTE CONCENTRATIONS IN WATER SAMPLES | 80 |
| APPENDIX E. CALCULATIONS OF PULSE BREAKTHROUGH MEANS | 102 |

INTRODUCTION

In this volume, appendices containing various raw and reduced data are presented. These appendices are referred to in the text of the first volume "Flushing of Organic Contaminants from a Ground Water Plume at the Rocky Mountain Arsenal: Volume I. Field and Laboratory Studies.

APPENDIX A. GRAIN SIZE PARAMETERS

GRAIN SIZE PARAMETERS

| Core # | Depth interval (ft) ¹ | Mean (phi) | Sorting (phi) | Description |
|--------|----------------------------------|------------|---------------|-------------------------------------|
| 1 | 59.50-61.00 | 0.11 | 1.43 | poorly sorted coarse sand |
| 1 | 61.00-62.00 | -0.65 | 1.45 | poorly sorted very coarse sand |
| 1 | 62.00-63.50 | -0.62 | 1.64 | poorly sorted very coarse sand |
| 1 | 69.25-70.25 | -0.04 | 1.53 | poorly sorted very coarse sand |
| 1 | 70.25-71.25 | -0.31 | 1.30 | moderately sorted very coarse sand |
| 1 | 71.25-72.00 | 0.09 | 1.44 | poorly sorted coarse sand |
| 1 | 74.00-75.00 | 0.29 | 1.54 | poorly sorted coarse sand |
| 1 | 75.00-76.00 | 0.22 | 1.34 | moderately sorted coarse sand |
| 1 | 76.00-77.00 | 0.49 | 1.22 | moderately sorted coarse sand |
| 1 | 77.00-78.00 | 0.72 | 1.15 | moderately sorted coarse sand |
| 1 | 78.00-79.00 | 0.70 | 1.10 | moderately sorted coarse sand |
| 1 | 79.00-80.00 | 1.33 | 1.07 | moderately sorted medium sand |
| 1 | 80.00-81.00 | 0.38 | 1.45 | poorly sorted coarse sand |
| 1 | 81.00-81.75 | -0.42 | 1.53 | poorly sorted very coarse sand |
| 1 | 81.75-82.75 | 0.80 | 1.28 | moderately sorted coarse sand |
| 1 | 82.75-83.75 | -0.17 | 1.59 | poorly sorted very coarse sand |
| 1 | 84.00-85.25 | 0.91 | 1.19 | moderately sorted coarse sand |
| 1 | 85.25-86.25 | 0.26 | 1.57 | poorly sorted coarse sand |
| 1 | 86.25-87.25 | 0.94 | 1.97 | poorly sorted coarse sand |
| 1 | 87.25-88.50 | 0.42 | 2.01 | very poorly sorted coarse sand |
| 2 | 56.50-57.50 | 0.49 | 1.56 | poorly sorted coarse sand |
| 2 | 57.50-58.50 | -0.06 | 1.54 | poorly sorted very coarse sand |
| 2 | 58.50-59.50 | -0.46 | 1.62 | poorly sorted very coarse sand |
| 2 | 59.50-60.50 | -1.03 | 1.78 | poorly sorted gravel |
| 2 | 60.50-61.50 | -0.60 | 1.72 | poorly sorted very coarse sand |
| 2 | 64.00-65.00 | 0.25 | 1.40 | poorly sorted coarse sand |
| 2 | 65.00-66.00 | -1.06 | 1.72 | poorly sorted gravel |
| 2 | 66.00-67.00 | -1.69 | 1.61 | poorly sorted gravel |
| 2 | 67.00-68.00 | -1.06 | 1.43 | poorly sorted gravel |
| 3 | 59.80-61.05 | -0.08 | 1.53 | poorly sorted very coarse sand |
| 3 | 61.05-62.30 | -0.07 | 1.84 | poorly sorted very coarse sand |
| 3 | 64.80-65.80 | -0.96 | 1.67 | poorly sorted very coarse sand |
| 3 | 65.80-66.80 | -0.92 | 1.55 | poorly sorted very coarse sand |
| 3 | 66.80-67.80 | -0.87 | 1.59 | poorly sorted very coarse sand |
| 3 | 67.80-69.80 | -1.00 | 1.73 | poorly sorted very coarse sand |
| 3 | 69.80-70.80 | 0.15 | 1.21 | moderately sorted coarse sand |
| 3 | 70.80-71.80 | -1.24 | 1.63 | poorly sorted gravel |
| 3 | 71.80-72.80 | -1.59 | 1.91 | poorly sorted gravel |
| 3 | 72.80-74.30 | -0.42 | 2.68 | extremely poorly sorted v.c. sand |
| 3 | 74.80-75.80 | 1.36 | 1.10 | moderately sorted medium sand |
| 3 | 75.80-76.80 | 0.69 | 1.39 | moderately sorted coarse sand |
| 3 | 76.80-77.80 | 0.97 | 1.03 | moderately sorted coarse sand |
| 3 | 77.80-78.80 | 0.91 | 1.24 | moderately sorted coarse sand |
| 3 | 79.80-80.80 | 0.78 | 1.03 | moderately sorted coarse sand |
| 3 | 80.80-81.80 | 0.87 | 1.16 | moderately sorted coarse sand |
| 3 | 81.80-82.80 | -0.72 | 2.54 | very poorly sorted very coarse sand |
| 3 | 82.80-83.80 | 0.25 | 1.49 | poorly sorted coarse sand |
| 3 | 86.05-86.30 | 1.18 | 1.45 | poorly sorted medium sand |

(1) All depths relative to a ground elevation of 5176.4 ft

Method of Moments Grain Size Analysis

RMA 33080

Sample 59.5-61

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -2.5 | 93.2 | 8.02 | -20.06 | -2.61 |
| -1.5 | 153.2 | 13.19 | -19.78 | -1.61 |
| -0.5 | 283.6 | 24.42 | -12.21 | -0.61 |
| 0.5 | 361.1 | 31.09 | 15.54 | 0.39 |
| 1.5 | 177.5 | 15.28 | 22.92 | 1.39 |
| 2.5 | 55 | 4.74 | 11.84 | 2.39 |
| 3.5 | 23.7 | 2.04 | 7.14 | 3.39 |
| 4.5 | 14.2 | 1.22 | 5.50 | 4.39 |
| | 1161.5 | 100 | 10.90 | |

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -2.5 | 6.81 | 54.62 | -142.49 | 371.76 |
| -1.5 | 2.59 | 34.14 | -54.94 | 88.39 |
| -0.5 | 0.37 | 9.05 | -5.51 | 3.36 |
| 0.5 | 0.15 | 4.75 | 1.86 | 0.73 |
| 1.5 | 1.94 | 29.57 | 41.13 | 57.22 |
| 2.5 | 5.72 | 27.07 | 64.73 | 154.77 |
| 3.5 | 11.50 | 23.46 | 79.57 | 269.81 |
| 4.5 | 19.28 | 23.57 | 103.51 | 454.51 |
| | | 206.25 | 87.85 | 1400.55 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 0.1089539 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 2.0624940 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.4361386$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 0.8785272 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.2965965 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 14.005503 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 3.2924053 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 61-62

| Phi Class Midpoint | Wt (g) | Wt % | Midpt*Wt% | Deviation Mpt-Mean |
|-----------------------|--------|-------|-----------|-----------------------|
| -2.5 | 152 | 20.72 | -51.80 | -1.85 |
| -1.5 | 159.8 | 21.78 | -32.67 | -0.85 |
| -0.5 | 204.1 | 27.82 | -13.91 | 0.15 |
| 0.5 | 137.8 | 18.78 | 9.39 | 1.15 |
| 1.5 | 45.8 | 6.24 | 9.36 | 2.15 |
| 2.5 | 19 | 2.59 | 6.47 | 3.15 |
| 3.5 | 8.6 | 1.17 | 4.10 | 4.15 |
| 4.5 | 6.5 | 0.89 | 3.99 | 5.15 |
| | 733.6 | 100 | -65.06 | |

| Phi Class Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------------------|-------|-----------|-----------|-----------|
| -2.5 | 3.42 | 70.87 | -131.06 | 242.37 |
| -1.5 | 0.72 | 15.71 | -13.35 | 11.34 |
| -0.5 | 0.02 | 0.63 | 0.10 | 0.01 |
| 0.5 | 1.32 | 24.87 | 28.61 | 32.93 |
| 1.5 | 4.63 | 28.88 | 62.10 | 133.56 |
| 2.5 | 9.93 | 25.71 | 81.00 | 255.20 |
| 3.5 | 17.23 | 20.20 | 83.83 | 347.93 |
| 4.5 | 26.53 | 23.51 | 121.07 | 623.58 |
| | | 210.37 | 232.30 | 1646.92 |

First Moment:

$$\text{Mean} = \frac{\text{Sum}(\text{Wt}\% * \text{Midpt})}{100}$$

$$= -0.650627$$

Second Moment:

$$\text{Dispersion} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^2))}{100}$$

$$= 2.1036746$$

Square Root of Second Moment:
Standard Deviation=

$$1.4504049$$

$$\text{Third Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^3))}{100}$$

$$= 2.3230305$$

$$\text{Skewness} = \frac{\text{Third Moment}}{(\text{Standard deviation}^3)}$$

$$= 0.7613547$$

$$\text{Fourth Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^4))}{100}$$

$$= 16.469216$$

$$\text{Kurtosis} = \frac{\text{Fourth Moment}}{(\text{Standard Deviation}^4)}$$

$$= 3.7214808$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 62-63.5

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -2.5 | 289.3 | 27.49 | -68.74 | -1.88 |
| -1.5 | 188.3 | 17.90 | -26.84 | -0.88 |
| -0.5 | 202 | 19.20 | -9.60 | 0.12 |
| 0.5 | 212.2 | 20.17 | 10.08 | 1.12 |
| 1.5 | 92.3 | 8.77 | 13.16 | 2.12 |
| 2.5 | 38.4 | 3.65 | 9.12 | 3.12 |
| 3.5 | 17.8 | 1.69 | 5.92 | 4.12 |
| 4.5 | 11.9 | 1.13 | 5.09 | 5.12 |

| | | |
|--------|-----|--------|
| 1052.2 | 100 | -61.80 |
|--------|-----|--------|

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -2.5 | 3.54 | 97.38 | -183.27 | 344.90 |
| -1.5 | 0.78 | 13.92 | -12.28 | 10.83 |
| -0.5 | 0.01 | 0.27 | 0.03 | 0.00 |
| 0.5 | 1.25 | 25.21 | 28.18 | 31.51 |
| 1.5 | 4.49 | 39.35 | 83.35 | 176.54 |
| 2.5 | 9.72 | 35.48 | 110.63 | 344.95 |
| 3.5 | 16.96 | 28.69 | 118.14 | 486.50 |
| 4.5 | 26.19 | 29.62 | 151.62 | 776.00 |

| | | |
|--------|--------|---------|
| 269.92 | 296.41 | 2171.24 |
|--------|--------|---------|

First Moment:

Mean = $\text{Sum}(\text{Wt}\% \cdot \text{Midpt}) / 100$
 = -0.618038

Second Moment:

Dispersion = $\text{Sum}((\text{Wt}\%) \cdot (\text{Dev}^2)) / 100$
 = 2.6992393

Square Root of Second Moment:

Standard Deviation = 1.6429361

Third Moment = $\text{Sum}((\text{Wt}\%) \cdot (\text{Dev}^3)) / 100$
 = 2.9641390

Skewness = Third Moment / (Standard deviation*3)
 = 0.6684000

Fourth Moment = $\text{Sum}((\text{Wt}\%) \cdot (\text{Dev}^4)) / 100$
 = 21.712363

Kurtosis = Fourth Moment / (Standard Deviation*4)
 = 2.9800552

Method of Moments Grain Size Analysis

RMA 33080

Sample 69.25-70.25

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -2.5 | 125.9 | 15.96 | -39.90 | -2.46 |
| -1.5 | 72.5 | 9.19 | -13.79 | -1.46 |
| -0.5 | 167 | 21.17 | -10.59 | -0.46 |
| 0.5 | 251.1 | 31.83 | 15.92 | 0.54 |
| 1.5 | 111.7 | 14.16 | 21.24 | 1.54 |
| 2.5 | 39.2 | 4.97 | 12.42 | 2.54 |
| 3.5 | 15.6 | 1.98 | 6.92 | 3.54 |
| 4.5 | 5.8 | 0.74 | 3.31 | 4.54 |
| | 788.8 | 100 | -4.46 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | | | | |
| -2.5 | 6.03 | 96.23 | -236.27 | 580.14 |
| -1.5 | 2.12 | 19.47 | -28.33 | 41.24 |
| -0.5 | 0.21 | 4.39 | -2.00 | 0.91 |
| 0.5 | 0.30 | 9.44 | 5.14 | 2.80 |
| 1.5 | 2.39 | 33.79 | 52.19 | 80.61 |
| 2.5 | 6.48 | 32.18 | 81.88 | 208.36 |
| 3.5 | 12.56 | 24.85 | 88.08 | 312.20 |
| 4.5 | 20.65 | 15.19 | 69.02 | 313.66 |
| | | 235.53 | 29.70 | 1539.91 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -0.044624 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 2.3552601 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.5346856$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 0.2970151 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.0821713 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 15.399111 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 2.7759899 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 70.25-71.25

| Phi Class | Midpoint | Wt (g) | Wt % | Midpt*Wt% | Deviation Mpt-Mean |
|-----------|----------|--------|-------|-----------|-----------------------|
| | -2.5 | 63.9 | 9.87 | -24.66 | -2.19 |
| | -1.5 | 139 | 21.46 | -32.19 | -1.19 |
| | -0.5 | 176.6 | 27.27 | -13.63 | -0.19 |
| | 0.5 | 173.9 | 26.85 | 13.42 | 0.81 |
| | 1.5 | 72.4 | 11.18 | 16.77 | 1.81 |
| | 2.5 | 16.4 | 2.53 | 6.33 | 2.81 |
| | 3.5 | 3.3 | 0.51 | 1.78 | 3.81 |
| | 4.5 | 2.2 | 0.34 | 1.53 | 4.81 |
| | | 647.7 | 100 | -30.65 | |

| Phi Class | Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|----------|-------|-----------|-----------|-----------|
| | -2.5 | 4.81 | 47.47 | -104.11 | 228.37 |
| | -1.5 | 1.42 | 30.57 | -36.48 | 43.54 |
| | -0.5 | 0.04 | 1.02 | -0.20 | 0.04 |
| | 0.5 | 0.65 | 17.47 | 14.09 | 11.36 |
| | 1.5 | 3.26 | 36.48 | 65.90 | 119.06 |
| | 2.5 | 7.88 | 19.94 | 55.97 | 157.09 |
| | 3.5 | 14.49 | 7.38 | 28.10 | 106.97 |
| | 4.5 | 23.10 | 7.85 | 37.72 | 181.29 |
| | | | 168.17 | 60.99 | 847.72 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -0.306546 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 1.6817357 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.2968175$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 0.6099216 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.2796645 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 8.4772439 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 2.9973618 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 71.25-72

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -2.5 | 13.5 | 4.63 | -11.57 | -2.59 |
| -1.5 | 33.6 | 11.51 | -17.27 | -1.59 |
| -0.5 | 118.4 | 40.58 | -20.29 | -0.59 |
| 0.5 | 73.8 | 25.29 | 12.65 | 0.41 |
| 1.5 | 26.1 | 8.94 | 13.42 | 1.41 |
| 2.5 | 5 | 1.71 | 4.28 | 2.41 |
| 3.5 | 15 | 5.14 | 17.99 | 3.41 |
| 4.5 | 6.4 | 2.19 | 9.87 | 4.41 |
| | 291.8 | 100 | 9.08 | |

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -2.5 | 6.71 | 31.05 | -80.46 | 208.45 |
| -1.5 | 2.53 | 29.14 | -46.36 | 73.75 |
| -0.5 | 0.35 | 14.16 | -8.37 | 4.94 |
| 0.5 | 0.17 | 4.23 | 1.73 | 0.71 |
| 1.5 | 1.99 | 17.76 | 25.03 | 35.27 |
| 2.5 | 5.80 | 9.95 | 23.96 | 57.73 |
| 3.5 | 11.62 | 59.75 | 203.68 | 694.40 |
| 4.5 | 19.44 | 42.64 | 188.01 | 828.95 |
| | | 208.69 | 307.23 | 1904.19 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 0.0908156 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 2.0868519 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.4445940$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 3.0723156 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 1.0191271 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 19.041873 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 4.3724657 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 74-75

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -2.5 | 41.8 | 7.04 | -17.60 | -2.79 |
| -1.5 | 86.5 | 14.57 | -21.85 | -1.79 |
| -0.5 | 121 | 20.38 | -10.19 | -0.79 |
| 0.5 | 158 | 26.61 | 13.31 | 0.21 |
| 1.5 | 109.4 | 18.43 | 27.64 | 1.21 |
| 2.5 | 50.7 | 8.54 | 21.35 | 2.21 |
| 3.5 | 20.4 | 3.44 | 12.03 | 3.21 |
| 4.5 | 5.9 | 0.99 | 4.47 | 4.21 |
| | 593.7 | 100 | 29.15 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | | | | |
| -2.5 | 7.79 | 54.86 | -153.15 | 427.51 |
| -1.5 | 3.21 | 46.76 | -83.77 | 150.07 |
| -0.5 | 0.63 | 12.77 | -10.10 | 8.00 |
| 0.5 | 0.04 | 1.16 | 0.24 | 0.05 |
| 1.5 | 1.46 | 26.91 | 32.52 | 39.31 |
| 2.5 | 4.88 | 41.65 | 91.99 | 203.16 |
| 3.5 | 10.29 | 35.37 | 113.50 | 364.15 |
| 4.5 | 17.71 | 17.60 | 74.08 | 311.75 |
| | | 237.09 | 65.31 | 1504.00 |

First Moment:

$$\text{Mean} = \frac{\text{Sum}(\text{Wt}\% * \text{Midpt})}{100}$$

$$= 0.2914771$$

Second Moment:

$$\text{Dispersion} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^2))}{100}$$

$$= 2.3708689$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.5397626$$

$$\text{Third Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^3))}{100}$$

$$= 0.6530634$$

$$\text{Skewness} = \frac{\text{Third Moment}}{(\text{Standard deviation}^3)}$$

$$= 0.1788932$$

$$\text{Fourth Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^4))}{100}$$

$$= 15.040001$$

$$\text{Kurtosis} = \frac{\text{Fourth Moment}}{(\text{Standard Deviation}^4)}$$

$$= 2.6756714$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 75-76

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -2.5 | 104.8 | 10.89 | -27.22 | -2.72 |
| -1.5 | 49.1 | 5.10 | -7.65 | -1.72 |
| -0.5 | 166.4 | 17.29 | -8.65 | -0.72 |
| 0.5 | 402.8 | 41.85 | 20.93 | 0.28 |
| 1.5 | 193.2 | 20.07 | 30.11 | 1.28 |
| 2.5 | 30.6 | 3.18 | 7.95 | 2.28 |
| 3.5 | 8.7 | 0.90 | 3.16 | 3.28 |
| 4.5 | 6.8 | 0.71 | 3.18 | 4.28 |
| | 962.4 | 100 | 21.81 | |

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -2.5 | 7.39 | 80.45 | -218.68 | 594.38 |
| -1.5 | 2.95 | 15.06 | -25.87 | 44.45 |
| -0.5 | 0.52 | 8.92 | -6.40 | 4.60 |
| 0.5 | 0.08 | 3.33 | 0.94 | 0.26 |
| 1.5 | 1.64 | 32.99 | 42.29 | 54.21 |
| 2.5 | 5.21 | 16.56 | 37.78 | 86.21 |
| 3.5 | 10.77 | 9.74 | 31.96 | 104.87 |
| 4.5 | 18.33 | 12.95 | 55.47 | 237.52 |
| | | 179.99 | -82.52 | 1126.51 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 0.2181005 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 1.7998968 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.3416023$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= -0.825233 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= -0.341747 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 11.265118 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 3.4772871 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 76-77

| Phi Class | Midpoint | Wt (g) | Wt % | Midpt*Wt% | Deviation Mpt-Mean |
|-----------|----------|--------|-------|-----------|-----------------------|
| -2.5 | | 26.3 | 4.07 | -10.16 | -2.99 |
| -1.5 | | 40.8 | 6.31 | -9.46 | -1.99 |
| -0.5 | | 107.8 | 16.66 | -8.33 | -0.99 |
| 0.5 | | 275.4 | 42.57 | 21.29 | 0.01 |
| 1.5 | | 149 | 23.03 | 34.55 | 1.01 |
| 2.5 | | 32.4 | 5.01 | 12.52 | 2.01 |
| 3.5 | | 9.8 | 1.51 | 5.30 | 3.01 |
| 4.5 | | 5.4 | 0.83 | 3.76 | 4.01 |
| | | 646.9 | 100 | 49.46 | |

| Phi Class | Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|----------|-------|-----------|-----------|-----------|
| -2.5 | | 8.97 | 36.46 | -109.18 | 326.94 |
| -1.5 | | 3.98 | 25.09 | -50.05 | 99.82 |
| -0.5 | | 0.99 | 16.48 | -16.40 | 16.31 |
| 0.5 | | 0.00 | 0.00 | 0.00 | 0.00 |
| 1.5 | | 1.01 | 23.28 | 23.41 | 23.54 |
| 2.5 | | 4.02 | 20.14 | 40.39 | 81.01 |
| 3.5 | | 9.03 | 13.68 | 41.12 | 123.60 |
| 4.5 | | 16.04 | 13.39 | 53.64 | 214.85 |
| | | | 148.54 | -17.05 | 886.06 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 0.4945895 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 1.4853625 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.2187545$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= -0.170511 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= -0.094189 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 8.8606339 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 4.0160566 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 77-78

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -2.5 | 13.2 | 1.80 | -4.49 | -3.22 |
| -1.5 | 23 | 3.13 | -4.70 | -2.22 |
| -0.5 | 108.3 | 14.75 | -7.37 | -1.22 |
| 0.5 | 344.4 | 46.90 | 23.45 | -0.22 |
| 1.5 | 177 | 24.10 | 36.16 | 0.78 |
| 2.5 | 40 | 5.45 | 13.62 | 1.78 |
| 3.5 | 15.4 | 2.10 | 7.34 | 2.78 |
| 4.5 | 13 | 1.77 | 7.97 | 3.78 |
| | 734.3 | 100 | 71.97 | |

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -2.5 | 10.37 | 18.63 | -60.00 | 193.17 |
| -1.5 | 4.93 | 15.43 | -34.25 | 76.03 |
| -0.5 | 1.49 | 21.94 | -26.76 | 32.64 |
| 0.5 | 0.05 | 2.26 | -0.50 | 0.11 |
| 1.5 | 0.61 | 14.68 | 11.45 | 8.94 |
| 2.5 | 3.17 | 17.27 | 30.74 | 54.73 |
| 3.5 | 7.73 | 16.21 | 45.08 | 125.32 |
| 4.5 | 14.29 | 25.30 | 95.64 | 361.57 |
| | | 131.73 | 61.40 | 852.51 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 0.7196649 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 1.3172654 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.1477218$$

$$\text{Third Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100$$

$$= 0.6140434$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.4061524 \end{aligned}$$

$$\text{Fourth Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100$$

$$= 8.5250847$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 4.9130601 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 78-79

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -2.5 | 4.4 | 0.83 | -2.08 | -3.20 |
| -1.5 | 13.4 | 2.54 | -3.80 | -2.20 |
| -0.5 | 96.7 | 18.30 | -9.15 | -1.20 |
| 0.5 | 247.3 | 46.79 | 23.40 | -0.20 |
| 1.5 | 118.5 | 22.42 | 33.63 | 0.80 |
| 2.5 | 28.7 | 5.43 | 13.58 | 1.80 |
| 3.5 | 11.4 | 2.16 | 7.55 | 2.80 |
| 4.5 | 8.1 | 1.53 | 6.90 | 3.80 |
| | 528.5 | 100 | 70.02 | |

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -2.5 | 10.24 | 8.53 | -27.29 | 87.32 |
| -1.5 | 4.84 | 12.27 | -27.00 | 59.42 |
| -0.5 | 1.44 | 26.36 | -31.63 | 37.96 |
| 0.5 | 0.04 | 1.88 | -0.38 | 0.08 |
| 1.5 | 0.64 | 14.34 | 11.47 | 9.18 |
| 2.5 | 3.24 | 17.59 | 31.66 | 56.98 |
| 3.5 | 7.84 | 16.91 | 47.34 | 132.55 |
| 4.5 | 14.44 | 22.13 | 84.09 | 319.51 |
| | | 120.00 | 88.26 | 702.99 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 0.7001892 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 1.2000378 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.0954623$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 0.8826262 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.6714048 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 7.0299390 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 4.8815945 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 79-80

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -2.5 | 0.5 | 0.07 | -0.19 | -3.83 |
| -1.5 | 3.9 | 0.58 | -0.88 | -2.83 |
| -0.5 | 33.6 | 5.03 | -2.52 | -1.83 |
| 0.5 | 246.6 | 36.94 | 18.47 | -0.83 |
| 1.5 | 231.3 | 34.65 | 51.98 | 0.17 |
| 2.5 | 103.3 | 15.48 | 38.69 | 1.17 |
| 3.5 | 35.5 | 5.32 | 18.61 | 2.17 |
| 4.5 | 12.8 | 1.92 | 8.63 | 3.17 |
| | 667.5 | 100 | 132.80 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | | | | |
| -2.5 | 14.65 | 1.10 | -4.20 | 16.08 |
| -1.5 | 8.00 | 4.67 | -13.21 | 37.37 |
| -0.5 | 3.34 | 16.82 | -30.75 | 56.21 |
| 0.5 | 0.69 | 25.33 | -20.97 | 17.37 |
| 1.5 | 0.03 | 1.02 | 0.18 | 0.03 |
| 2.5 | 1.37 | 21.26 | 24.91 | 29.20 |
| 3.5 | 4.72 | 25.09 | 54.49 | 118.36 |
| 4.5 | 10.06 | 19.29 | 61.20 | 194.13 |
| | | 114.59 | 71.64 | 468.74 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% \cdot \text{Midpt}) / 100 \\ &= 1.3280149 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) \cdot (\text{Dev}^2)) / 100 \\ &= 1.1458518 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.0704447$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) \cdot (\text{Dev}^3)) / 100 \\ &= 0.7164449 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.5841039 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) \cdot (\text{Dev}^4)) / 100 \\ &= 4.6874399 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 3.5700867 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 80-81

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -2.5 | 29.1 | 4.20 | -10.51 | -2.88 |
| -1.5 | 46.1 | 6.66 | -9.99 | -1.88 |
| -0.5 | 142.7 | 20.62 | -10.31 | -0.88 |
| 0.5 | 300.2 | 43.38 | 21.69 | 0.12 |
| 1.5 | 128.1 | 18.51 | 27.76 | 1.12 |
| 2.5 | 30.8 | 4.45 | 11.13 | 2.12 |
| 3.5 | 9.4 | 1.36 | 4.75 | 3.12 |
| 4.5 | 5.7 | 0.82 | 3.71 | 4.12 |
| | 692.1 | 100 | 38.22 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | | | | |
| -2.5 | 8.31 | 34.93 | -100.67 | 290.17 |
| -1.5 | 3.54 | 23.60 | -44.42 | 83.61 |
| -0.5 | 0.78 | 16.05 | -14.16 | 12.49 |
| 0.5 | 0.01 | 0.60 | 0.07 | 0.01 |
| 1.5 | 1.25 | 23.12 | 25.85 | 28.89 |
| 2.5 | 4.48 | 19.96 | 42.27 | 89.51 |
| 3.5 | 9.72 | 13.20 | 41.16 | 128.33 |
| 4.5 | 16.96 | 13.96 | 57.50 | 236.78 |
| | | 145.43 | 7.60 | 869.79 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 0.3822424 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 1.4542736 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.2059326$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 0.0760006 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.0433359 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 8.6978775 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 4.1126433 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 81-81.75

| Phi Class | Midpoint | Wt (g) | Wt % | Midpt*Wt% | Deviation Mpt-Mean |
|-----------|----------|--------|-------|-----------|-----------------------|
| | -2.5 | 100.2 | 18.58 | -46.45 | -2.08 |
| | -1.5 | 101.1 | 18.75 | -28.12 | -1.08 |
| | -0.5 | 126.3 | 23.42 | -11.71 | -0.08 |
| | 0.5 | 126 | 23.36 | 11.68 | 0.92 |
| | 1.5 | 55.5 | 10.29 | 15.44 | 1.92 |
| | 2.5 | 17.3 | 3.21 | 8.02 | 2.92 |
| | 3.5 | 7.6 | 1.41 | 4.93 | 3.92 |
| | 4.5 | 5.3 | 0.98 | 4.42 | 4.92 |
| | | 539.3 | 100 | -41.79 | |

| Phi Class | Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|----------|-------|-----------|-----------|-----------|
| | -2.5 | 4.34 | 80.55 | -167.71 | 349.20 |
| | -1.5 | 1.17 | 21.95 | -23.76 | 25.71 |
| | -0.5 | 0.01 | 0.16 | -0.01 | 0.00 |
| | 0.5 | 0.84 | 19.68 | 18.07 | 16.58 |
| | 1.5 | 3.68 | 37.85 | 72.60 | 139.23 |
| | 2.5 | 8.51 | 27.31 | 79.69 | 232.53 |
| | 3.5 | 15.35 | 21.63 | 84.75 | 332.03 |
| | 4.5 | 24.19 | 23.77 | 116.89 | 574.84 |
| | | | 232.91 | 180.51 | 1670.12 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -0.417856 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 2.3290581 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.5261251$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 1.8050607 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.5078334 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 16.701217 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 3.0788425 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 81.75-82.75

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -2.5 | 21.7 | 3.63 | -9.06 | -3.30 |
| -1.5 | 22.7 | 3.79 | -5.69 | -2.30 |
| -0.5 | 76.6 | 12.80 | -6.40 | -1.30 |
| 0.5 | 220.9 | 36.91 | 18.45 | -0.30 |
| 1.5 | 181.3 | 30.29 | 45.44 | 0.70 |
| 2.5 | 50.7 | 8.47 | 21.18 | 1.70 |
| 3.5 | 16.1 | 2.69 | 9.42 | 2.70 |
| 4.5 | 8.5 | 1.42 | 6.39 | 3.70 |
| | 598.5 | 100 | 79.72 | |

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -2.5 | 10.87 | 39.42 | -129.97 | 428.55 |
| -1.5 | 5.28 | 20.02 | -45.98 | 105.63 |
| -0.5 | 1.68 | 21.54 | -27.94 | 36.25 |
| 0.5 | 0.09 | 3.26 | -0.97 | 0.29 |
| 1.5 | 0.49 | 14.96 | 10.51 | 7.39 |
| 2.5 | 2.90 | 24.56 | 41.82 | 71.21 |
| 3.5 | 7.30 | 19.65 | 53.11 | 143.55 |
| 4.5 | 13.71 | 19.47 | 72.10 | 266.97 |
| | | 162.88 | -27.32 | 1059.82 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 0.7972431 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 1.6287726 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.2762337$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= -0.273173 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= -0.131415 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 10.598237 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 3.9949624 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 82.75-83.75

| Phi Class | Midpoint | Wt (g) | Wt % | Midpt*Wt% | Deviation Mpt-Mean |
|-----------|----------|--------|-------|-----------|-----------------------|
| -2.5 | | 115.3 | 16.21 | -40.54 | -2.33 |
| -1.5 | | 91.4 | 12.85 | -19.28 | -1.33 |
| -0.5 | | 179.1 | 25.19 | -12.59 | -0.33 |
| 0.5 | | 189.5 | 26.65 | 13.32 | 0.67 |
| 1.5 | | 79.3 | 11.15 | 16.73 | 1.67 |
| 2.5 | | 28.7 | 4.04 | 10.09 | 2.67 |
| 3.5 | | 14.6 | 2.05 | 7.19 | 3.67 |
| 4.5 | | 13.2 | 1.86 | 8.35 | 4.67 |
| | | 711.1 | 100 | -16.73 | |

| Phi Class | Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|----------|-------|-----------|-----------|-----------|
| -2.5 | | 5.44 | 88.23 | -205.82 | 480.12 |
| -1.5 | | 1.78 | 22.83 | -30.43 | 40.55 |
| -0.5 | | 0.11 | 2.79 | -0.93 | 0.31 |
| 0.5 | | 0.45 | 11.87 | 7.92 | 5.28 |
| 1.5 | | 2.78 | 31.00 | 51.69 | 86.17 |
| 2.5 | | 7.11 | 28.71 | 76.59 | 204.28 |
| 3.5 | | 13.45 | 27.61 | 101.26 | 371.36 |
| 4.5 | | 21.78 | 40.44 | 188.73 | 880.84 |
| | | | 253.48 | 189.01 | 2068.92 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -0.167276 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 2.5347736 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.5920972$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 1.8900644 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.4683471 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 20.689165 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 3.2200649 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 84-85.25

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -2.5 | 8.4 | 1.29 | -3.22 | -3.41 |
| -1.5 | 27.7 | 4.25 | -6.37 | -2.41 |
| -0.5 | 84.5 | 12.95 | -6.48 | -1.41 |
| 0.5 | 224.5 | 34.41 | 17.20 | -0.41 |
| 1.5 | 214.3 | 32.84 | 49.26 | 0.59 |
| 2.5 | 68.2 | 10.45 | 26.13 | 1.59 |
| 3.5 | 17 | 2.61 | 9.12 | 2.59 |
| 4.5 | 7.9 | 1.21 | 5.45 | 3.59 |
| | 652.5 | 100 | 91.10 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | | | | |
| -2.5 | 11.64 | 14.98 | -51.09 | 174.28 |
| -1.5 | 5.81 | 24.68 | -59.50 | 143.45 |
| -0.5 | 1.99 | 25.78 | -36.38 | 51.34 |
| 0.5 | 0.17 | 5.81 | -2.39 | 0.98 |
| 1.5 | 0.35 | 11.39 | 6.71 | 3.95 |
| 2.5 | 2.52 | 26.39 | 41.93 | 66.63 |
| 3.5 | 6.70 | 17.46 | 45.21 | 117.05 |
| 4.5 | 12.88 | 15.59 | 55.97 | 200.87 |
| | | 142.09 | 0.46 | 758.56 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 0.9110344 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 1.4209357 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.1920300$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 0.0046021 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.0027170 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 7.5855615 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 3.7569799 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33080

Sample 85.25-86.25

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -2.5 | 78.2 | 12.23 | -30.58 | -2.76 |
| -1.5 | 58.3 | 9.12 | -13.68 | -1.76 |
| -0.5 | 101.5 | 15.87 | -7.94 | -0.76 |
| 0.5 | 199.7 | 31.23 | 15.62 | 0.24 |
| 1.5 | 133.3 | 20.85 | 31.27 | 1.24 |
| 2.5 | 47.6 | 7.44 | 18.61 | 2.24 |
| 3.5 | 13 | 2.03 | 7.12 | 3.24 |
| 4.5 | 7.8 | 1.22 | 5.49 | 4.24 |

| | | |
|-------|-----|-------|
| 639.4 | 100 | 25.91 |
|-------|-----|-------|

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -2.5 | 7.61 | 93.11 | -256.90 | 708.82 |
| -1.5 | 3.09 | 28.22 | -49.64 | 87.32 |
| -0.5 | 0.58 | 9.15 | -6.95 | 5.27 |
| 0.5 | 0.06 | 1.81 | 0.44 | 0.11 |
| 1.5 | 1.54 | 32.10 | 39.83 | 49.42 |
| 2.5 | 5.02 | 37.38 | 83.77 | 187.71 |
| 3.5 | 10.50 | 21.35 | 69.21 | 224.29 |
| 4.5 | 17.98 | 21.94 | 93.04 | 394.58 |

| | | |
|--------|--------|---------|
| 245.06 | -27.20 | 1657.51 |
|--------|--------|---------|

First Moment:

Mean = $\text{Sum}(\text{Wt}\% * \text{Midpt}) / 100$
 = 0.2591492

Second Moment:

Dispersion = $\text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100$
 = 2.4505927

Square Root of Second Moment:

Standard Deviation = 1.5654369

Third Moment = $\text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100$
 = -0.271962

Skewness = Third Moment / (Standard deviation*3)
 = -0.070892

Fourth Moment = $\text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100$
 = 16.575147

Kurtosis = Fourth Moment / (Standard Deviation*4)
 = 2.7600384

Method of Moments Grain Size Analysis

RMA 33080

Sample 86.25-87.25

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -2.5 | 28 | 5.41 | -13.54 | -3.44 |
| -1.5 | 73.5 | 14.21 | -21.32 | -2.44 |
| -0.5 | 84 | 16.24 | -8.12 | -1.44 |
| 0.5 | 76.1 | 14.72 | 7.36 | -0.44 |
| 1.5 | 100.1 | 19.36 | 29.04 | 0.56 |
| 2.5 | 66.6 | 12.88 | 32.20 | 1.56 |
| 3.5 | 43.8 | 8.47 | 29.65 | 2.56 |
| 4.5 | 45 | 8.70 | 39.16 | 3.56 |

| | | |
|-------|-----|-------|
| 517.1 | 100 | 94.42 |
|-------|-----|-------|

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -2.5 | 11.86 | 64.23 | -221.23 | 761.98 |
| -1.5 | 5.97 | 84.92 | -207.55 | 507.30 |
| -0.5 | 2.09 | 33.88 | -48.93 | 70.67 |
| 0.5 | 0.20 | 2.90 | -1.29 | 0.57 |
| 1.5 | 0.31 | 5.98 | 3.32 | 1.85 |
| 2.5 | 2.42 | 31.17 | 48.50 | 75.46 |
| 3.5 | 6.53 | 55.33 | 141.41 | 361.41 |
| 4.5 | 12.64 | 110.03 | 391.24 | 1391.18 |

| | | |
|--------|--------|---------|
| 388.45 | 105.47 | 3170.41 |
|--------|--------|---------|

First Moment:

Mean = $\text{Sum}(\text{Wt}\% * \text{Midpt}) / 100$
 = 0.9442080

Second Moment:

Dispersion = $\text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100$
 = 3.8844815

Square Root of Second Moment:

Standard Deviation = 1.9709088

Third Moment = $\text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100$
 = 1.0546880

Skewness = Third Moment / (Standard deviation*3)
 = 0.1377604

Fourth Moment = $\text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100$
 = 31.704138

Kurtosis = Fourth Moment / (Standard Deviation*4)
 = 2.1011150

Method of Moments Grain Size Analysis

RMA 33080

Sample 87.25-88.5

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -2.5 | 86.5 | 8.78 | -21.94 | -2.92 |
| -1.5 | 194.4 | 19.73 | -29.59 | -1.92 |
| -0.5 | 205.3 | 20.83 | -10.42 | -0.92 |
| 0.5 | 164.8 | 16.72 | 8.36 | 0.08 |
| 1.5 | 107.4 | 10.90 | 16.35 | 1.08 |
| 2.5 | 80.2 | 8.14 | 20.35 | 2.08 |
| 3.5 | 80.1 | 8.13 | 28.45 | 3.08 |
| 4.5 | 66.8 | 6.78 | 30.50 | 4.08 |
| | 985.5 | 100 | 42.05 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | | | | |
| -2.5 | 8.53 | 74.87 | -218.65 | 638.58 |
| -1.5 | 3.69 | 72.76 | -139.74 | 268.37 |
| -0.5 | 0.85 | 17.65 | -16.25 | 14.96 |
| 0.5 | 0.01 | 0.11 | 0.01 | 0.00 |
| 1.5 | 1.17 | 12.70 | 13.71 | 14.80 |
| 2.5 | 4.32 | 35.19 | 73.18 | 152.16 |
| 3.5 | 9.48 | 77.08 | 237.35 | 730.92 |
| 4.5 | 16.64 | 112.80 | 460.18 | 1877.27 |
| | | 403.15 | 409.78 | 3697.07 |

First Moment:

$$\text{Mean} = \frac{\text{Sum}(\text{Wt}\% * \text{Midpt})}{100}$$

$$= 0.4205479$$

Second Moment:

$$\text{Dispersion} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^2))}{100}$$

$$= 4.0315361$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 2.0078685$$

$$\text{Third Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^3))}{100}$$

$$= 4.0978205$$

$$\text{Skewness} = \frac{\text{Third Moment}}{(\text{Standard deviation}^3)}$$

$$= 0.5062290$$

$$\text{Fourth Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^4))}{100}$$

$$= 36.970689$$

$$\text{Kurtosis} = \frac{\text{Fourth Moment}}{(\text{Standard Deviation}^4)}$$

$$= 2.2746596$$

Method of Moments Grain Size Analysis

RMA Core 2

Sample 56.5-57.5

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -5.99 |
| -4.5 | 0 | 0.00 | 0.00 | -4.99 |
| -3.5 | 18.62 | 2.45 | -8.59 | -3.99 |
| -2.5 | 34.09 | 4.49 | -11.23 | -2.99 |
| -1.5 | 62.6 | 8.25 | -12.37 | -1.99 |
| -0.5 | 127.6 | 16.81 | -8.40 | -0.99 |
| 0.5 | 251.6 | 33.14 | 16.57 | 0.01 |
| 1.5 | 166.2 | 21.89 | 32.84 | 1.01 |
| 2.5 | 58.2 | 7.67 | 19.17 | 2.01 |
| 3.5 | 24.9 | 3.28 | 11.48 | 3.01 |
| 4.5 | 15.3 | 2.02 | 9.07 | 4.01 |
| | 759.11 | 100 | 48.54 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | | | | |
| -5.5 | 35.83 | 0.00 | 0.00 | 0.00 |
| -4.5 | 24.85 | 0.00 | 0.00 | 0.00 |
| -3.5 | 15.88 | 38.96 | -155.28 | 618.84 |
| -2.5 | 8.91 | 40.03 | -119.49 | 356.74 |
| -1.5 | 3.94 | 32.51 | -64.54 | 128.14 |
| -0.5 | 0.97 | 16.32 | -16.09 | 15.85 |
| 0.5 | 0.00 | 0.01 | 0.00 | 0.00 |
| 1.5 | 1.03 | 22.54 | 22.86 | 23.20 |
| 2.5 | 4.06 | 31.12 | 62.68 | 126.28 |
| 3.5 | 9.09 | 29.81 | 89.86 | 270.89 |
| 4.5 | 16.12 | 32.48 | 130.41 | 523.52 |
| | | 243.77 | -49.58 | 2063.47 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 0.4854434 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 2.4376824 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.5613079$$

$$\text{Third Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100$$

$$= -0.495841$$

$$\text{Skewness} = \text{Third Moment} / (\text{Standard deviation}^3)$$

$$= -0.130279$$

$$\text{Fourth Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100$$

$$= 20.634744$$

$$\text{Kurtosis} = \text{Fourth Moment} / (\text{Standard Deviation}^4)$$

$$= 3.4725205$$

Method of Moments Grain Size Analysis

RMA Core 2

Sample 57.5-58.5

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -5.44 |
| -4.5 | 6.3 | 0.90 | -4.07 | -4.44 |
| -3.5 | 20.2 | 2.90 | -10.14 | -3.44 |
| -2.5 | 57.1 | 8.19 | -20.47 | -2.44 |
| -1.5 | 84.1 | 12.06 | -18.09 | -1.44 |
| -0.5 | 146 | 20.93 | -10.47 | -0.44 |
| 0.5 | 245.3 | 35.17 | 17.59 | 0.56 |
| 1.5 | 97 | 13.91 | 20.86 | 1.56 |
| 2.5 | 23.5 | 3.37 | 8.42 | 2.56 |
| 3.5 | 10.1 | 1.45 | 5.07 | 3.56 |
| 4.5 | 7.8 | 1.12 | 5.03 | 4.56 |
| | 697.4 | 100 | -6.25 | |

| Phi Class | | | | |
|-----------|--------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -5.5 | 29.57 | 0.00 | 0.00 | 0.00 |
| -4.5 | 19.69 | 17.79 | -78.93 | 350.27 |
| -3.5 | 11.82 | 34.23 | -117.65 | 404.42 |
| -2.5 | 5.94 | 48.64 | -118.57 | 289.01 |
| -1.5 | 2.07 | 24.92 | -35.82 | 51.49 |
| -0.5 | 0.19 | 4.01 | -1.75 | 0.77 |
| 0.5 | 0.32 | 11.13 | 6.26 | 3.52 |
| 1.5 | 2.44 | 33.96 | 53.06 | 82.91 |
| 2.5 | 6.57 | 22.13 | 56.70 | 145.30 |
| 3.5 | 12.69 | 18.38 | 65.48 | 233.27 |
| 4.5 | 20.82 | 23.28 | 106.22 | 484.65 |
| | 238.46 | -65.00 | 2045.61 | |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -0.062517 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 2.3846059 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.5442169$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= -0.650018 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= -0.176522 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 20.456142 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 3.5974145 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA Core 2

Sample 58.5-59.5

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -5.04 |
| -4.5 | 19.3 | 2.78 | -12.49 | -4.04 |
| -3.5 | 32.8 | 4.72 | -16.51 | -3.04 |
| -2.5 | 65.5 | 9.42 | -23.55 | -2.04 |
| -1.5 | 103.7 | 14.91 | -22.37 | -1.04 |
| -0.5 | 177.8 | 25.57 | -12.78 | -0.04 |
| 0.5 | 202.1 | 29.06 | 14.53 | 0.96 |
| 1.5 | 66.6 | 9.58 | 14.37 | 1.96 |
| 2.5 | 14.7 | 2.11 | 5.28 | 2.96 |
| 3.5 | 6.9 | 0.99 | 3.47 | 3.96 |
| 4.5 | 6 | 0.86 | 3.88 | 4.96 |
| | | 695.4 | 100 | -46.16 |

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -5.5 | 25.39 | 0.00 | 0.00 | 0.00 |
| -4.5 | 16.31 | 45.26 | -182.79 | 738.17 |
| -3.5 | 9.23 | 43.54 | -132.30 | 401.99 |
| -2.5 | 4.16 | 39.14 | -79.78 | 162.61 |
| -1.5 | 1.08 | 16.08 | -16.70 | 17.34 |
| -0.5 | 0.00 | 0.04 | -0.00 | 0.00 |
| 0.5 | 0.92 | 26.87 | 25.84 | 24.85 |
| 1.5 | 3.85 | 36.85 | 72.29 | 141.80 |
| 2.5 | 8.77 | 18.54 | 54.91 | 162.63 |
| 3.5 | 15.69 | 15.57 | 61.69 | 244.40 |
| 4.5 | 24.62 | 21.24 | 105.39 | 522.88 |
| | | 263.14 | -91.45 | 2416.68 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -0.461604 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 2.6313989 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.6221587$$

$$\text{Third Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100$$

$$= -0.914458$$

$$\text{Skewness} = \text{Third Moment} / (\text{Standard deviation}^3)$$

$$= -0.214231$$

$$\text{Fourth Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100$$

$$= 24.166777$$

$$\text{Kurtosis} = \text{Fourth Moment} / (\text{Standard Deviation}^4)$$

$$= 3.4901600$$

Method of Moments Grain Size Analysis

RMA Core 2

Sample 59.5-60.5

| Phi Class | Midpoint | Wt (g) | Wt % | Midpt*Wt% | Deviation Mpt-Mean |
|-----------|----------|--------|-------|-----------|-----------------------|
| | -5.5 | 0 | 0.00 | 0.00 | -4.47 |
| | -4.5 | 48.5 | 7.10 | -31.95 | -3.47 |
| | -3.5 | 40.9 | 5.99 | -20.96 | -2.47 |
| | -2.5 | 104.4 | 15.29 | -38.21 | -1.47 |
| | -1.5 | 149.7 | 21.92 | -32.88 | -0.47 |
| | -0.5 | 144.1 | 21.10 | -10.55 | 0.53 |
| | 0.5 | 121 | 17.72 | 8.86 | 1.53 |
| | 1.5 | 49.8 | 7.29 | 10.94 | 2.53 |
| | 2.5 | 13.7 | 2.01 | 5.01 | 3.53 |
| | 3.5 | 6.4 | 0.94 | 3.28 | 4.53 |
| | 4.5 | 4.5 | 0.66 | 2.96 | 5.53 |
| | | 683 | 100 | -103.50 | |

| Phi Class | Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|----------|-------|-----------|-----------|-----------|
| | -5.5 | 19.94 | 0.00 | 0.00 | 0.00 |
| | -4.5 | 12.01 | 85.26 | -295.42 | 1023.62 |
| | -3.5 | 6.08 | 36.39 | -89.69 | 221.09 |
| | -2.5 | 2.15 | 32.81 | -48.06 | 70.41 |
| | -1.5 | 0.22 | 4.74 | -2.20 | 1.02 |
| | -0.5 | 0.29 | 6.04 | 3.23 | 1.73 |
| | 0.5 | 2.36 | 41.74 | 64.07 | 98.35 |
| | 1.5 | 6.43 | 46.86 | 118.78 | 301.10 |
| | 2.5 | 12.50 | 25.07 | 88.61 | 313.22 |
| | 3.5 | 20.57 | 19.27 | 87.40 | 396.34 |
| | 4.5 | 30.64 | 20.18 | 111.72 | 618.39 |
| | | | 318.35 | 38.43 | 3045.28 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -1.034992 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 3.1834753 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.7842296$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 0.3843476 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.0676662 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 30.452790 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 3.0048590 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA Core 2

Sample 60.5-61.5

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -4.90 |
| -4.5 | 17.8 | 3.09 | -13.90 | -3.90 |
| -3.5 | 27.2 | 4.72 | -16.52 | -2.90 |
| -2.5 | 77.1 | 13.38 | -33.46 | -1.90 |
| -1.5 | 103.6 | 17.98 | -26.97 | -0.90 |
| -0.5 | 132.6 | 23.02 | -11.51 | 0.10 |
| 0.5 | 130.4 | 22.63 | 11.32 | 1.10 |
| 1.5 | 55.3 | 9.60 | 14.40 | 2.10 |
| 2.5 | 19.4 | 3.37 | 8.42 | 3.10 |
| 3.5 | 7.6 | 1.32 | 4.62 | 4.10 |
| 4.5 | 5.1 | 0.89 | 3.98 | 5.10 |
| | | 576.1 | 100 | -59.63 |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | | | | |
| -5.5 | 24.05 | 0.00 | 0.00 | 0.00 |
| -4.5 | 15.24 | 47.08 | -183.80 | 717.48 |
| -3.5 | 8.43 | 39.81 | -115.59 | 335.63 |
| -2.5 | 3.62 | 48.50 | -92.33 | 175.76 |
| -1.5 | 0.82 | 14.69 | -13.27 | 11.99 |
| -0.5 | 0.01 | 0.21 | 0.02 | 0.00 |
| 0.5 | 1.20 | 27.21 | 29.83 | 32.70 |
| 1.5 | 4.39 | 42.18 | 88.43 | 185.38 |
| 2.5 | 9.59 | 32.28 | 99.97 | 309.53 |
| 3.5 | 16.78 | 22.14 | 90.68 | 371.45 |
| 4.5 | 25.97 | 22.99 | 117.18 | 597.18 |
| | | 297.09 | 21.12 | 2737.10 |

First Moment:

$$\text{Mean} = \frac{\text{Sum}(\text{Wt}\% * \text{Midpt})}{100}$$

$$= -0.596337$$

Second Moment:

$$\text{Dispersion} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^2))}{100}$$

$$= 2.9709308$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.7236388$$

$$\text{Third Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^3))}{100}$$

$$= 0.2112047$$

$$\text{Skewness} = \frac{\text{Third Moment}}{(\text{Standard Deviation}^3)}$$

$$= 0.0412443$$

$$\text{Fourth Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^4))}{100}$$

$$= 27.370993$$

$$\text{Kurtosis} = \frac{\text{Fourth Moment}}{(\text{Standard Deviation}^4)}$$

$$= 3.1010264$$

Method of Moments Grain Size Analysis

RMA Core 2

Sample 64-65

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -2.5 | 29.2 | 4.15 | -10.36 | -2.75 |
| -1.5 | 93.9 | 13.33 | -20.00 | -1.75 |
| -0.5 | 189 | 26.84 | -13.42 | -0.75 |
| 0.5 | 211.5 | 30.03 | 15.01 | 0.25 |
| 1.5 | 110.2 | 15.65 | 23.47 | 1.25 |
| 2.5 | 43.1 | 6.12 | 15.30 | 2.25 |
| 3.5 | 18 | 2.56 | 8.95 | 3.25 |
| 4.5 | 9.4 | 1.33 | 6.01 | 4.25 |
| | 704.3 | 100 | 24.95 | |

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -2.5 | 7.56 | 31.34 | -86.18 | 236.95 |
| -1.5 | 3.06 | 40.81 | -71.40 | 124.91 |
| -0.5 | 0.56 | 15.08 | -11.30 | 8.47 |
| 0.5 | 0.06 | 1.88 | 0.47 | 0.12 |
| 1.5 | 1.56 | 24.47 | 30.59 | 38.26 |
| 2.5 | 5.06 | 30.99 | 69.75 | 156.97 |
| 3.5 | 10.57 | 27.00 | 87.77 | 285.30 |
| 4.5 | 18.07 | 24.11 | 102.49 | 435.63 |
| | | 195.69 | 122.20 | 1286.60 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 0.2495385 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 1.9568629 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.3988791$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 1.2219759 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.4463977 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 12.865984 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 3.3598678 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA Core 2

Sample 65-66

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -4.44 |
| -4.5 | 38.4 | 5.43 | -24.43 | -3.44 |
| -3.5 | 46.7 | 6.60 | -23.11 | -2.44 |
| -2.5 | 121.9 | 17.23 | -43.09 | -1.44 |
| -1.5 | 154 | 21.77 | -32.66 | -0.44 |
| -0.5 | 158.7 | 22.44 | -11.22 | 0.56 |
| 0.5 | 119.9 | 16.95 | 8.48 | 1.56 |
| 1.5 | 40.9 | 5.78 | 8.67 | 2.56 |
| 2.5 | 16.1 | 2.28 | 5.69 | 3.56 |
| 3.5 | 6.3 | 0.89 | 3.12 | 4.56 |
| 4.5 | 4.4 | 0.62 | 2.80 | 5.56 |
| | | 707.3 | 100 | -105.75 |

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -5.5 | 19.74 | 0.00 | 0.00 | 0.00 |
| -4.5 | 11.85 | 64.34 | -221.49 | 762.50 |
| -3.5 | 5.97 | 39.39 | -96.21 | 235.00 |
| -2.5 | 2.08 | 35.86 | -51.73 | 74.63 |
| -1.5 | 0.20 | 4.26 | -1.89 | 0.83 |
| -0.5 | 0.31 | 6.97 | 3.89 | 2.17 |
| 0.5 | 2.43 | 41.12 | 64.04 | 99.75 |
| 1.5 | 6.54 | 37.82 | 96.73 | 247.38 |
| 2.5 | 12.66 | 28.81 | 102.48 | 364.58 |
| 3.5 | 20.77 | 18.50 | 84.32 | 384.27 |
| 4.5 | 30.89 | 19.21 | 106.78 | 593.41 |
| | | 296.29 | 86.91 | 2764.51 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -1.057472 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 2.9629418 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.7213197$$

$$\text{Third Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100$$

$$= 0.8690831$$

$$\text{Skewness} = \text{Third Moment} / (\text{Standard deviation}^3)$$

$$= 0.1704027$$

$$\text{Fourth Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100$$

$$= 27.645099$$

$$\text{Kurtosis} = \text{Fourth Moment} / (\text{Standard Deviation}^4)$$

$$= 3.1489944$$

Method of Moments Grain Size Analysis

RMA Core 2

Sample 66-67

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -3.81 |
| -4.5 | 21.6 | 3.03 | -13.63 | -2.81 |
| -3.5 | 123.2 | 17.28 | -60.47 | -1.81 |
| -2.5 | 200.4 | 28.10 | -70.26 | -0.81 |
| -1.5 | 167.2 | 23.45 | -35.17 | 0.19 |
| -0.5 | 98.5 | 13.81 | -6.91 | 1.19 |
| 0.5 | 57.8 | 8.11 | 4.05 | 2.19 |
| 1.5 | 24.7 | 3.46 | 5.20 | 3.19 |
| 2.5 | 11.5 | 1.61 | 4.03 | 4.19 |
| 3.5 | 4.8 | 0.67 | 2.36 | 5.19 |
| 4.5 | 3.4 | 0.48 | 2.15 | 6.19 |
| | 713.1 | 100 | -168.65 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | | | | |
| -5.5 | 14.54 | 0.00 | 0.00 | 0.00 |
| -4.5 | 7.92 | 23.98 | -67.46 | 189.80 |
| -3.5 | 3.29 | 56.82 | -103.04 | 186.86 |
| -2.5 | 0.66 | 18.60 | -15.13 | 12.31 |
| -1.5 | 0.03 | 0.82 | 0.15 | 0.03 |
| -0.5 | 1.41 | 19.45 | 23.07 | 27.38 |
| 0.5 | 4.78 | 38.75 | 84.73 | 185.26 |
| 1.5 | 10.15 | 35.17 | 112.07 | 357.11 |
| 2.5 | 17.53 | 28.27 | 118.33 | 495.40 |
| 3.5 | 26.90 | 18.11 | 93.91 | 487.07 |
| 4.5 | 38.27 | 18.25 | 112.89 | 698.41 |
| | | 258.20 | 359.53 | 2639.63 |

First Moment:

$$\text{Mean} = \frac{\text{Sum}(\text{Wt}\% * \text{Midpt})}{100} = -1.686509$$

Second Moment:

$$\text{Dispersion} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^2))}{100} = 2.5819579$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.6068472$$

$$\text{Third Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^3))}{100} = 3.5953270$$

$$\text{Skewness} = \frac{\text{Third Moment}}{(\text{Standard deviation}^3)} = 0.8665919$$

$$\text{Fourth Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^4))}{100} = 26.396250$$

$$\text{Kurtosis} = \frac{\text{Fourth Moment}}{(\text{Standard Deviation}^4)} = 3.9595324$$

Method of Moments Grain Size Analysis

RMA Core 2

Sample 67-68

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -4.44 |
| -4.5 | 0 | 0.00 | 0.00 | -3.44 |
| -3.5 | 0 | 0.00 | 0.00 | -2.44 |
| -2.5 | 218.3 | 32.36 | -80.89 | -1.44 |
| -1.5 | 178.4 | 26.44 | -39.66 | -0.44 |
| -0.5 | 132.9 | 19.70 | -9.85 | 0.56 |
| 0.5 | 87.2 | 12.92 | 6.46 | 1.56 |
| 1.5 | 35 | 5.19 | 7.78 | 2.56 |
| 2.5 | 13.9 | 2.06 | 5.15 | 3.56 |
| 3.5 | 5.3 | 0.79 | 2.75 | 4.56 |
| 4.5 | 3.7 | 0.55 | 2.47 | 5.56 |
| | | 674.7 | 100 | -105.79 |

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -5.5 | 19.73 | 0.00 | 0.00 | 0.00 |
| -4.5 | 11.85 | 0.00 | 0.00 | 0.00 |
| -3.5 | 5.96 | 0.00 | 0.00 | 0.00 |
| -2.5 | 2.08 | 67.29 | -97.04 | 139.94 |
| -1.5 | 0.20 | 5.17 | -2.29 | 1.01 |
| -0.5 | 0.31 | 6.13 | 3.42 | 1.91 |
| 0.5 | 2.43 | 31.37 | 48.87 | 76.13 |
| 1.5 | 6.54 | 33.94 | 86.82 | 222.06 |
| 2.5 | 12.66 | 26.08 | 92.78 | 330.12 |
| 3.5 | 20.77 | 16.32 | 74.38 | 339.01 |
| 4.5 | 30.89 | 16.94 | 94.15 | 523.27 |
| | | 203.23 | 301.09 | 1633.45 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -1.057877 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 2.0323327 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.4255990$$

$$\text{Third Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100$$

$$= 3.0109027$$

$$\text{Skewness} = \text{Third Moment} / (\text{Standard deviation}^3)$$

$$= 1.0392128$$

$$\text{Fourth Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100$$

$$= 16.334525$$

$$\text{Kurtosis} = \text{Fourth Moment} / (\text{Standard Deviation}^4)$$

$$= 3.9547306$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 58.5-59.75

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -5.42 |
| -4.5 | 9.7 | 1.12 | -5.03 | -4.42 |
| -3.5 | 43 | 4.96 | -17.36 | -3.42 |
| -2.5 | 46.7 | 5.39 | -13.46 | -2.42 |
| -1.5 | 97.3 | 11.22 | -16.83 | -1.42 |
| -0.5 | 183.4 | 21.15 | -10.58 | -0.42 |
| 0.5 | 305.2 | 35.20 | 17.60 | 0.58 |
| 1.5 | 141.1 | 16.27 | 24.41 | 1.58 |
| 2.5 | 29.9 | 3.45 | 8.62 | 2.58 |
| 3.5 | 7 | 0.81 | 2.83 | 3.58 |
| 4.5 | 3.8 | 0.44 | 1.97 | 4.58 |
| | 867.1 | 100 | -7.84 | |

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -5.5 | 29.39 | 0.00 | 0.00 | 0.00 |
| -4.5 | 19.55 | 21.87 | -96.71 | 427.60 |
| -3.5 | 11.71 | 58.06 | -198.66 | 679.73 |
| -2.5 | 5.86 | 31.58 | -76.48 | 185.22 |
| -1.5 | 2.02 | 22.68 | -32.24 | 45.83 |
| -0.5 | 0.18 | 3.76 | -1.59 | 0.67 |
| 0.5 | 0.33 | 11.77 | 6.81 | 3.94 |
| 1.5 | 2.49 | 40.54 | 63.99 | 100.99 |
| 2.5 | 6.65 | 22.92 | 59.11 | 152.40 |
| 3.5 | 12.80 | 10.34 | 36.99 | 132.36 |
| 4.5 | 20.96 | 9.19 | 42.06 | 192.56 |
| | | 232.71 | -196.72 | 1921.29 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -0.078364 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 2.3271250 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.5254917$$

$$\text{Third Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100$$

$$= -1.967230$$

$$\text{Skewness} = \text{Third Moment} / (\text{Standard deviation}^3)$$

$$= -0.554147$$

$$\text{Fourth Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100$$

$$= 19.212914$$

$$\text{Kurtosis} = \text{Fourth Moment} / (\text{Standard Deviation}^4)$$

$$= 3.5477564$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 59.75-61

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -5.43 |
| -4.5 | 64 | 7.02 | -31.60 | -4.43 |
| -3.5 | 31 | 3.40 | -11.90 | -3.43 |
| -2.5 | 33.1 | 3.63 | -9.08 | -2.43 |
| -1.5 | 66.9 | 7.34 | -11.01 | -1.43 |
| -0.5 | 165 | 18.10 | -9.05 | -0.43 |
| 0.5 | 311.7 | 34.20 | 17.10 | 0.57 |
| 1.5 | 184.9 | 20.29 | 30.43 | 1.57 |
| 2.5 | 37.1 | 4.07 | 10.18 | 2.57 |
| 3.5 | 10.6 | 1.16 | 4.07 | 3.57 |
| 4.5 | 7.1 | 0.78 | 3.51 | 4.57 |
| | 911.4 | 100 | -7.36 | |

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -5.5 | 29.45 | 0.00 | 0.00 | 0.00 |
| -4.5 | 19.59 | 137.58 | -609.00 | 2695.66 |
| -3.5 | 11.74 | 39.93 | -136.82 | 468.81 |
| -2.5 | 5.89 | 21.38 | -51.88 | 125.88 |
| -1.5 | 2.03 | 14.93 | -21.30 | 30.38 |
| -0.5 | 0.18 | 3.29 | -1.40 | 0.60 |
| 0.5 | 0.33 | 11.25 | 6.46 | 3.70 |
| 1.5 | 2.48 | 50.24 | 79.06 | 124.40 |
| 2.5 | 6.62 | 26.96 | 69.39 | 178.58 |
| 3.5 | 12.77 | 14.85 | 53.08 | 189.68 |
| 4.5 | 20.92 | 16.30 | 74.53 | 340.87 |
| | | 336.72 | -537.90 | 4158.57 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -0.073622 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 3.3672480 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.8350062$$

$$\text{Third Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100$$

$$= -5.378960$$

$$\text{Skewness} = \text{Third Moment} / (\text{Standard deviation}^3)$$

$$= -0.870533$$

$$\text{Fourth Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100$$

$$= 41.585709$$

$$\text{Kurtosis} = \text{Fourth Moment} / (\text{Standard Deviation}^4)$$

$$= 3.6677006$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 63.5-64.5

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -4.54 |
| -4.5 | 0 | 0.00 | 0.00 | -3.54 |
| -3.5 | 40.7 | 6.01 | -21.04 | -2.54 |
| -2.5 | 153.8 | 22.71 | -56.79 | -1.54 |
| -1.5 | 215.3 | 31.80 | -47.70 | -0.54 |
| -0.5 | 97.7 | 14.43 | -7.21 | 0.46 |
| 0.5 | 71.7 | 10.59 | 5.29 | 1.46 |
| 1.5 | 51.7 | 7.64 | 11.45 | 2.46 |
| 2.5 | 31.8 | 4.70 | 11.74 | 3.46 |
| 3.5 | 10 | 1.48 | 5.17 | 4.46 |
| 4.5 | 4.4 | 0.65 | 2.92 | 5.46 |
| | 677.1 | 100 | -96.15 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|--------|-----------|-----------|-----------|
| Midpoint | | | | |
| -5.5 | 20.60 | 0.00 | 0.00 | 0.00 |
| -4.5 | 12.52 | 0.00 | 0.00 | 0.00 |
| -3.5 | 6.44 | 38.73 | -98.32 | 249.59 |
| -2.5 | 2.37 | 53.76 | -82.71 | 127.25 |
| -1.5 | 0.29 | 9.22 | -4.96 | 2.67 |
| -0.5 | 0.21 | 3.07 | 1.42 | 0.65 |
| 0.5 | 2.14 | 22.62 | 33.06 | 48.32 |
| 1.5 | 6.06 | 46.26 | 113.88 | 280.32 |
| 2.5 | 11.98 | 56.27 | 194.79 | 674.29 |
| 3.5 | 19.91 | 29.40 | 131.16 | 585.17 |
| 4.5 | 29.83 | 19.38 | 105.86 | 578.17 |
| | 278.73 | 394.17 | 2546.44 | |

First Moment:

$$\text{Mean} = \frac{\text{Sum}(\text{Wt}\% * \text{Midpt})}{100}$$

$$= -0.961527$$

Second Moment:

$$\text{Dispersion} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^2))}{100}$$

$$= 2.7872881$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.6695173$$

$$\text{Third Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^3))}{100}$$

$$= 3.9417329$$

$$\text{Skewness} = \frac{\text{Third Moment}}{(\text{Standard deviation}^3)}$$

$$= 0.8470604$$

$$\text{Fourth Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^4))}{100}$$

$$= 25.464374$$

$$\text{Kurtosis} = \frac{\text{Fourth Moment}}{(\text{Standard Deviation}^4)}$$

$$= 3.2777006$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 64.5-65.5

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -4.58 |
| -4.5 | 0 | 0.00 | 0.00 | -3.58 |
| -3.5 | 50.8 | 7.11 | -24.88 | -2.58 |
| -2.5 | 123.4 | 17.27 | -43.18 | -1.58 |
| -1.5 | 196.3 | 27.47 | -41.21 | -0.58 |
| -0.5 | 171.2 | 23.96 | -11.98 | 0.42 |
| 0.5 | 99.2 | 13.88 | 6.94 | 1.42 |
| 1.5 | 38.8 | 5.43 | 8.15 | 2.42 |
| 2.5 | 22.6 | 3.16 | 7.91 | 3.42 |
| 3.5 | 8 | 1.12 | 3.92 | 4.42 |
| 4.5 | 4.2 | 0.59 | 2.65 | 5.42 |
| | 714.5 | 100 | -91.69 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|--------|-----------|-----------|-----------|
| Midpoint | | | | |
| -5.5 | 21.00 | 0.00 | 0.00 | 0.00 |
| -4.5 | 12.84 | 0.00 | 0.00 | 0.00 |
| -3.5 | 6.67 | 47.44 | -122.54 | 316.52 |
| -2.5 | 2.51 | 43.28 | -68.52 | 108.47 |
| -1.5 | 0.34 | 9.34 | -5.45 | 3.18 |
| -0.5 | 0.17 | 4.17 | 1.74 | 0.72 |
| 0.5 | 2.01 | 27.87 | 39.50 | 55.96 |
| 1.5 | 5.84 | 31.72 | 76.67 | 185.31 |
| 2.5 | 11.68 | 36.93 | 126.19 | 431.17 |
| 3.5 | 19.51 | 21.84 | 96.48 | 426.16 |
| 4.5 | 29.34 | 17.25 | 93.43 | 506.13 |
| | 239.85 | 237.51 | 2033.62 | |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -0.916934 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 2.3984535 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.5486941$$

$$\text{Third Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100$$

$$= 2.3750641$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.6394084 \end{aligned}$$

$$\text{Fourth Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100$$

$$= 20.336230$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 3.5351498 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 65.5-66.5

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -4.63 |
| -4.5 | 7.3 | 0.95 | -4.29 | -3.63 |
| -3.5 | 45.1 | 5.89 | -20.62 | -2.63 |
| -2.5 | 138 | 18.03 | -45.06 | -1.63 |
| -1.5 | 197.3 | 25.77 | -38.66 | -0.63 |
| -0.5 | 161.2 | 21.06 | -10.53 | 0.37 |
| 0.5 | 125.6 | 16.41 | 8.20 | 1.37 |
| 1.5 | 59.5 | 7.77 | 11.66 | 2.37 |
| 2.5 | 21.1 | 2.76 | 6.89 | 3.37 |
| 3.5 | 6.5 | 0.85 | 2.97 | 4.37 |
| 4.5 | 4 | 0.52 | 2.35 | 5.37 |
| | | 765.6 | 100 | -87.08 |

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -5.5 | 21.43 | 0.00 | 0.00 | 0.00 |
| -4.5 | 13.17 | 12.56 | -45.58 | 165.41 |
| -3.5 | 6.91 | 40.72 | -107.06 | 281.49 |
| -2.5 | 2.65 | 47.84 | -77.94 | 126.99 |
| -1.5 | 0.40 | 10.20 | -6.42 | 4.04 |
| -0.5 | 0.14 | 2.90 | 1.07 | 0.40 |
| 0.5 | 1.88 | 30.83 | 42.26 | 57.93 |
| 1.5 | 5.62 | 43.68 | 103.56 | 245.53 |
| 2.5 | 11.36 | 31.31 | 105.56 | 355.81 |
| 3.5 | 19.10 | 16.22 | 70.89 | 309.86 |
| 4.5 | 28.85 | 15.07 | 80.94 | 434.73 |
| | | 251.34 | 167.29 | 1982.18 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -0.870820 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 2.5133543 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.5853562$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 1.6728871 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.4198421 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 19.821814 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 3.1378771 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 66.5-68.5

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -4.50 |
| -4.5 | 15.9 | 1.22 | -5.49 | -3.50 |
| -3.5 | 138.8 | 10.64 | -37.25 | -2.50 |
| -2.5 | 252.2 | 19.34 | -48.35 | -1.50 |
| -1.5 | 291.2 | 22.33 | -33.50 | -0.50 |
| -0.5 | 236.3 | 18.12 | -9.06 | 0.50 |
| 0.5 | 212.4 | 16.29 | 8.14 | 1.50 |
| 1.5 | 94.6 | 7.25 | 10.88 | 2.50 |
| 2.5 | 38.4 | 2.94 | 7.36 | 3.50 |
| 3.5 | 14.5 | 1.11 | 3.89 | 4.50 |
| 4.5 | 9.7 | 0.74 | 3.35 | 5.50 |

| | | |
|------|-----|---------|
| 1304 | 100 | -100.02 |
|------|-----|---------|

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -5.5 | 20.25 | 0.00 | 0.00 | 0.00 |
| -4.5 | 12.25 | 14.93 | -52.27 | 182.93 |
| -3.5 | 6.25 | 66.51 | -166.27 | 415.63 |
| -2.5 | 2.25 | 43.50 | -65.24 | 97.85 |
| -1.5 | 0.25 | 5.58 | -2.79 | 1.39 |
| -0.5 | 0.25 | 4.53 | 2.27 | 1.13 |
| 0.5 | 2.25 | 36.66 | 55.00 | 82.51 |
| 1.5 | 6.25 | 45.35 | 113.38 | 283.49 |
| 2.5 | 12.25 | 36.08 | 126.28 | 442.02 |
| 3.5 | 20.25 | 22.52 | 101.34 | 456.07 |
| 4.5 | 30.25 | 22.50 | 123.78 | 680.80 |

| | | |
|--------|--------|---------|
| 298.17 | 235.48 | 2643.82 |
|--------|--------|---------|

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -1.000230 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 2.9817484 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.7267739$$

$$\text{Third Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100$$

$$= 2.3548378$$

$$\text{Skewness} = \text{Third Moment} / (\text{Standard deviation}^3)$$

$$= 0.4573561$$

$$\text{Fourth Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100$$

$$= 26.438209$$

$$\text{Kurtosis} = \text{Fourth Moment} / (\text{Standard Deviation}^4)$$

$$= 2.9736512$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 68.5-69.5

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -5.65 |
| -4.5 | 0 | 0.00 | 0.00 | -4.65 |
| -3.5 | 0 | 0.00 | 0.00 | -3.65 |
| -2.5 | 9 | 1.31 | -3.28 | -2.65 |
| -1.5 | 98.3 | 14.33 | -21.49 | -1.65 |
| -0.5 | 228.6 | 33.32 | -16.66 | -0.65 |
| 0.5 | 200.9 | 29.29 | 14.64 | 0.35 |
| 1.5 | 101.5 | 14.80 | 22.19 | 1.35 |
| 2.5 | 35.4 | 5.16 | 12.90 | 2.35 |
| 3.5 | 8.1 | 1.18 | 4.13 | 3.35 |
| 4.5 | 4.2 | 0.61 | 2.76 | 4.35 |
| | 686 | 100 | 15.19 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | | | | |
| -5.5 | 31.94 | 0.00 | 0.00 | 0.00 |
| -4.5 | 21.64 | 0.00 | 0.00 | 0.00 |
| -3.5 | 13.34 | 0.00 | 0.00 | 0.00 |
| -2.5 | 7.03 | 9.23 | -24.47 | 64.88 |
| -1.5 | 2.73 | 39.10 | -64.59 | 106.70 |
| -0.5 | 0.42 | 14.16 | -9.23 | 6.02 |
| 0.5 | 0.12 | 3.55 | 1.24 | 0.43 |
| 1.5 | 1.82 | 26.89 | 36.25 | 48.87 |
| 2.5 | 5.51 | 28.45 | 66.81 | 156.87 |
| 3.5 | 11.21 | 13.24 | 44.32 | 148.37 |
| 4.5 | 18.91 | 11.58 | 50.33 | 218.84 |
| | | 146.19 | 100.65 | 750.99 |

First Moment:

$$\text{Mean} = \frac{\text{Sum}(\text{Wt}\% * \text{Midpt})}{100} = 0.1518950$$

Second Moment:

$$\text{Dispersion} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^2))}{100} = 1.4619133$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.2090960$$

$$\text{Third Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^3))}{100} = 1.0064894$$

$$\text{Skewness} = \frac{\text{Third Moment}}{(\text{Standard deviation}^3)} = 0.5694122$$

$$\text{Fourth Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^4))}{100} = 7.5098757$$

$$\text{Kurtosis} = \frac{\text{Fourth Moment}}{(\text{Standard Deviation}^4)} = 3.5139008$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 69.5-70.5

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -4.26 |
| -4.5 | 40.4 | 5.56 | -25.01 | -3.26 |
| -3.5 | 47.8 | 6.57 | -23.01 | -2.26 |
| -2.5 | 143.1 | 19.68 | -49.21 | -1.26 |
| -1.5 | 181.4 | 24.95 | -37.43 | -0.26 |
| -0.5 | 158.6 | 21.82 | -10.91 | 0.74 |
| 0.5 | 104.1 | 14.32 | 7.16 | 1.74 |
| 1.5 | 33.9 | 4.66 | 6.99 | 2.74 |
| 2.5 | 9.5 | 1.31 | 3.27 | 3.74 |
| 3.5 | 4.3 | 0.59 | 2.07 | 4.74 |
| 4.5 | 3.9 | 0.54 | 2.41 | 5.74 |
| | 727 | 100 | -123.66 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | | | | |
| -5.5 | 18.18 | 0.00 | 0.00 | 0.00 |
| -4.5 | 10.65 | 59.18 | -193.14 | 630.28 |
| -3.5 | 5.12 | 33.68 | -76.24 | 172.56 |
| -2.5 | 1.60 | 31.42 | -39.70 | 50.15 |
| -1.5 | 0.07 | 1.73 | -0.46 | 0.12 |
| -0.5 | 0.54 | 11.84 | 8.72 | 6.42 |
| 0.5 | 3.02 | 43.18 | 74.99 | 130.23 |
| 1.5 | 7.49 | 34.92 | 95.56 | 261.52 |
| 2.5 | 13.96 | 18.24 | 68.17 | 254.74 |
| 3.5 | 22.44 | 13.27 | 62.85 | 297.71 |
| 4.5 | 32.91 | 17.65 | 101.27 | 580.96 |
| | | 265.12 | 102.05 | 2384.69 |

First Moment:

$$\text{Mean} = \frac{\text{Sum}(\text{Wt}\% * \text{Midpt})}{100}$$

$$= -1.236588$$

Second Moment:

$$\text{Dispersion} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^2))}{100}$$

$$= 2.6512472$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.6282650$$

$$\text{Third Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^3))}{100}$$

$$= 1.0204554$$

$$\text{Skewness} = \frac{\text{Third Moment}}{(\text{Standard deviation}^3)}$$

$$= 0.2363843$$

$$\text{Fourth Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^4))}{100}$$

$$= 23.846912$$

$$\text{Kurtosis} = \frac{\text{Fourth Moment}}{(\text{Standard Deviation}^4)}$$

$$= 3.3925925$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 70.5-71.5

| Phi Class | | | | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | Wt (g) | Wt % | Midpt*Wt% | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -3.91 |
| -4.5 | 105.2 | 13.17 | -59.27 | -2.91 |
| -3.5 | 84.8 | 10.62 | -37.16 | -1.91 |
| -2.5 | 150.3 | 18.82 | -47.05 | -0.91 |
| -1.5 | 170.2 | 21.31 | -31.96 | 0.09 |
| -0.5 | 124.3 | 15.56 | -7.78 | 1.09 |
| 0.5 | 96 | 12.02 | 6.01 | 2.09 |
| 1.5 | 39 | 4.88 | 7.32 | 3.09 |
| 2.5 | 16 | 2.00 | 5.01 | 4.09 |
| 3.5 | 7.8 | 0.98 | 3.42 | 5.09 |
| 4.5 | 5.1 | 0.64 | 2.87 | 6.09 |
| | 798.7 | 100 | -158.59 | |

| Phi Class | | | | |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
| -5.5 | 15.32 | 0.00 | 0.00 | 0.00 |
| -4.5 | 8.49 | 111.85 | -325.95 | 949.85 |
| -3.5 | 3.66 | 38.90 | -74.46 | 142.52 |
| -2.5 | 0.84 | 15.72 | -14.37 | 13.14 |
| -1.5 | 0.01 | 0.16 | 0.01 | 0.00 |
| -0.5 | 1.18 | 18.35 | 19.93 | 21.64 |
| 0.5 | 4.35 | 52.30 | 109.08 | 227.54 |
| 1.5 | 9.52 | 46.50 | 143.49 | 442.79 |
| 2.5 | 16.69 | 33.44 | 136.65 | 558.32 |
| 3.5 | 25.87 | 25.26 | 128.47 | 653.40 |
| 4.5 | 37.04 | 23.65 | 143.93 | 875.96 |
| | | 366.13 | 266.78 | 3885.16 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -1.585889 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 3.6613346 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.9134614$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 2.6678461 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.3808041 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 38.851605 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 2.8982118 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 71.5-73

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -5.08 |
| -4.5 | 131 | 14.21 | -63.92 | -4.08 |
| -3.5 | 65.2 | 7.07 | -24.75 | -3.08 |
| -2.5 | 102.8 | 11.15 | -27.87 | -2.08 |
| -1.5 | 104.2 | 11.30 | -16.95 | -1.08 |
| -0.5 | 102.3 | 11.09 | -5.55 | -0.08 |
| 0.5 | 67.8 | 7.35 | 3.68 | 0.92 |
| 1.5 | 139.7 | 15.15 | 22.72 | 1.92 |
| 2.5 | 122.4 | 13.27 | 33.18 | 2.92 |
| 3.5 | 49.5 | 5.37 | 18.79 | 3.92 |
| 4.5 | 37.3 | 4.04 | 18.20 | 4.92 |
| | 922.2 | 100 | -42.46 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | | | | |
| -5.5 | 25.76 | 0.00 | 0.00 | 0.00 |
| -4.5 | 16.61 | 235.93 | -961.49 | 3918.42 |
| -3.5 | 9.46 | 66.87 | -205.64 | 632.42 |
| -2.5 | 4.31 | 48.01 | -99.64 | 206.80 |
| -1.5 | 1.16 | 13.07 | -14.05 | 15.11 |
| -0.5 | 0.01 | 0.06 | -0.00 | 0.00 |
| 0.5 | 0.85 | 6.29 | 5.81 | 5.37 |
| 1.5 | 3.70 | 56.11 | 108.00 | 207.86 |
| 2.5 | 8.55 | 113.53 | 332.03 | 971.06 |
| 3.5 | 15.40 | 82.68 | 324.47 | 1273.44 |
| 4.5 | 24.25 | 98.09 | 483.07 | 2378.92 |
| | | 720.63 | -27.46 | 9609.40 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= -0.424636 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 7.2063134 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 2.6844577$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= -0.274572 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= -0.014193 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 96.094049 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 1.8504195 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 73.5-74.5

| Phi Class | Midpoint | Wt (g) | Wt % | Midpt*Wt% | Deviation Mpt-Mean |
|-----------|----------|--------|-------|-----------|-----------------------|
| | -5.5 | 0 | 0.00 | 0.00 | -6.86 |
| | -4.5 | 0 | 0.00 | 0.00 | -5.86 |
| | -3.5 | 0 | 0.00 | 0.00 | -4.86 |
| | -2.5 | 0 | 0.00 | 0.00 | -3.86 |
| | -1.5 | 1.77 | 0.81 | -1.21 | -2.86 |
| | -0.5 | 17.25 | 7.86 | -3.93 | -1.86 |
| | 0.5 | 66.99 | 30.52 | 15.26 | -0.86 |
| | 1.5 | 74.53 | 33.95 | 50.93 | 0.14 |
| | 2.5 | 43.93 | 20.01 | 50.03 | 1.14 |
| | 3.5 | 12.09 | 5.51 | 19.28 | 2.14 |
| | 4.5 | 2.96 | 1.35 | 6.07 | 3.14 |
| | | 219.52 | 100 | 136.42 | |

| Phi Class | Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|----------|-------|-----------|-----------|-----------|
| | -5.5 | 47.12 | 0.00 | 0.00 | 0.00 |
| | -4.5 | 34.39 | 0.00 | 0.00 | 0.00 |
| | -3.5 | 23.66 | 0.00 | 0.00 | 0.00 |
| | -2.5 | 14.93 | 0.00 | 0.00 | 0.00 |
| | -1.5 | 8.20 | 6.61 | -18.95 | 54.26 |
| | -0.5 | 3.48 | 27.31 | -50.91 | 94.90 |
| | 0.5 | 0.75 | 22.79 | -19.70 | 17.02 |
| | 1.5 | 0.02 | 0.63 | 0.09 | 0.01 |
| | 2.5 | 1.29 | 25.82 | 29.32 | 33.30 |
| | 3.5 | 4.56 | 25.12 | 53.66 | 114.60 |
| | 4.5 | 9.83 | 13.26 | 41.58 | 130.38 |
| | | | 121.54 | 35.09 | 444.49 |

First Moment:

$$\begin{aligned}\text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 1.3642037\end{aligned}$$

Second Moment:

$$\begin{aligned}\text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 1.2153877\end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.1024462$$

$$\begin{aligned}\text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 0.3509103\end{aligned}$$

$$\begin{aligned}\text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.2618930\end{aligned}$$

$$\begin{aligned}\text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 4.4448702\end{aligned}$$

$$\begin{aligned}\text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 3.0090499\end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 74.5-75.5

| Phi Class Midpoint | Wt (g) | Wt % | Midpt*Wt% | Deviation Mpt-Mean |
|-----------------------|--------|--------|-----------|-----------------------|
| -5.5 | 0 | 0.00 | 0.00 | -6.19 |
| -4.5 | 0 | 0.00 | 0.00 | -5.19 |
| -3.5 | 2.9 | 1.27 | -4.44 | -4.19 |
| -2.5 | 5.03 | 2.20 | -5.50 | -3.19 |
| -1.5 | 15.13 | 6.61 | -9.92 | -2.19 |
| -0.5 | 38.15 | 16.67 | -8.34 | -1.19 |
| 0.5 | 75.21 | 32.87 | 16.44 | -0.19 |
| 1.5 | 58.18 | 25.43 | 38.14 | 0.81 |
| 2.5 | 25.5 | 11.14 | 27.86 | 1.81 |
| 3.5 | 5.98 | 2.61 | 9.15 | 2.81 |
| 4.5 | 2.73 | 1.19 | 5.37 | 3.81 |
| | | 228.81 | 100 | 68.77 |

| Phi Class Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------------------|-------|-----------|-----------|-----------|
| -5.5 | 38.29 | 0.00 | 0.00 | 0.00 |
| -4.5 | 26.91 | 0.00 | 0.00 | 0.00 |
| -3.5 | 17.54 | 22.23 | -93.08 | 389.77 |
| -2.5 | 10.16 | 22.34 | -71.21 | 226.98 |
| -1.5 | 4.79 | 31.65 | -69.23 | 151.46 |
| -0.5 | 1.41 | 23.52 | -27.93 | 33.17 |
| 0.5 | 0.04 | 1.16 | -0.22 | 0.04 |
| 1.5 | 0.66 | 16.78 | 13.63 | 11.07 |
| 2.5 | 3.28 | 36.61 | 66.34 | 120.23 |
| 3.5 | 7.91 | 20.67 | 58.13 | 163.49 |
| 4.5 | 14.53 | 17.34 | 66.11 | 252.03 |
| | | 192.28 | -57.45 | 1348.25 |

First Moment:

$$\begin{aligned}\text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 0.6876666\end{aligned}$$

Second Moment:

$$\begin{aligned}\text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 1.9228250\end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.3866596$$

$$\begin{aligned}\text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= -0.574496\end{aligned}$$

$$\begin{aligned}\text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= -0.215465\end{aligned}$$

$$\begin{aligned}\text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 13.482462\end{aligned}$$

$$\begin{aligned}\text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 3.6466132\end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 75.5-76.5

| Phi Class Midpoint | Wt (g) | Wt % | Midpt*Wt% | Deviation Mpt-Mean |
|-----------------------|--------|-------|-----------|-----------------------|
| -5.5 | 0 | 0.00 | 0.00 | -6.47 |
| -4.5 | 0 | 0.00 | 0.00 | -5.47 |
| -3.5 | 0 | 0.00 | 0.00 | -4.47 |
| -2.5 | 1.6 | 0.84 | -2.11 | -3.47 |
| -1.5 | 4.6 | 2.43 | -3.64 | -2.47 |
| -0.5 | 16.6 | 8.76 | -4.38 | -1.47 |
| 0.5 | 74.6 | 39.39 | 19.69 | -0.47 |
| 1.5 | 72.4 | 38.23 | 57.34 | 0.53 |
| 2.5 | 14.4 | 7.60 | 19.01 | 1.53 |
| 3.5 | 3.2 | 1.69 | 5.91 | 2.53 |
| 4.5 | 2 | 1.06 | 4.75 | 3.53 |
| | | 189.4 | 100 | 96.57 |

| Phi Class Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------------------|-------|-----------|-----------|-----------|
| -5.5 | 41.81 | 0.00 | 0.00 | 0.00 |
| -4.5 | 29.87 | 0.00 | 0.00 | 0.00 |
| -3.5 | 19.94 | 0.00 | 0.00 | 0.00 |
| -2.5 | 12.01 | 10.15 | -35.16 | 121.87 |
| -1.5 | 6.08 | 14.77 | -36.41 | 89.77 |
| -0.5 | 2.15 | 18.83 | -27.60 | 40.45 |
| 0.5 | 0.22 | 8.54 | -3.98 | 1.85 |
| 1.5 | 0.29 | 10.91 | 5.83 | 3.12 |
| 2.5 | 2.35 | 17.90 | 27.46 | 42.14 |
| 3.5 | 6.42 | 10.85 | 27.50 | 69.70 |
| 4.5 | 12.49 | 13.19 | 46.62 | 164.77 |
| | | 105.14 | 4.27 | 533.65 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 0.9656810 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 1.0513565 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.0253567$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 0.0426827 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.0395937 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 5.3365354 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 4.8279122 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 76.5-77.5

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -6.41 |
| -4.5 | 0 | 0.00 | 0.00 | -5.41 |
| -3.5 | 0.89 | 0.42 | -1.47 | -4.41 |
| -2.5 | 3.14 | 1.48 | -3.69 | -3.41 |
| -1.5 | 5.66 | 2.66 | -3.99 | -2.41 |
| -0.5 | 27.01 | 12.70 | -6.35 | -1.41 |
| 0.5 | 83.28 | 39.17 | 19.59 | -0.41 |
| 1.5 | 62.18 | 29.25 | 43.87 | 0.59 |
| 2.5 | 19.95 | 9.38 | 23.46 | 1.59 |
| 3.5 | 5.76 | 2.71 | 9.48 | 2.59 |
| 4.5 | 4.73 | 2.22 | 10.01 | 3.59 |
| | 212.6 | 100 | 90.91 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|-------|-----------|-----------|-----------|
| Midpoint | | | | |
| -5.5 | 41.08 | 0.00 | 0.00 | 0.00 |
| -4.5 | 29.26 | 0.00 | 0.00 | 0.00 |
| -3.5 | 19.44 | 8.14 | -35.88 | 158.20 |
| -2.5 | 11.62 | 17.16 | -58.52 | 199.49 |
| -1.5 | 5.80 | 15.45 | -37.22 | 89.67 |
| -0.5 | 1.99 | 25.23 | -35.54 | 50.08 |
| 0.5 | 0.17 | 6.56 | -2.68 | 1.10 |
| 1.5 | 0.35 | 10.21 | 6.04 | 3.57 |
| 2.5 | 2.53 | 23.75 | 37.79 | 60.11 |
| 3.5 | 6.71 | 18.19 | 47.12 | 122.09 |
| 4.5 | 12.89 | 28.69 | 103.02 | 369.93 |
| | | 153.37 | 24.12 | 1054.25 |

First Moment:

$$\text{Mean} = \frac{\text{Sum}(\text{Wt}\% * \text{Midpt})}{100}$$

$$= 0.9090780$$

Second Moment:

$$\text{Dispersion} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^2))}{100}$$

$$= 1.5337369$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.2384413$$

$$\text{Third Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^3))}{100}$$

$$= 0.2411510$$

$$\text{Skewness} = \frac{\text{Third Moment}}{(\text{Standard deviation}^3)}$$

$$= 0.1269587$$

$$\text{Fourth Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^4))}{100}$$

$$= 10.542452$$

$$\text{Kurtosis} = \frac{\text{Fourth Moment}}{(\text{Standard Deviation}^4)}$$

$$= 4.4816699$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 78.5-79.5

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -6.28 |
| -4.5 | 0 | 0.00 | 0.00 | -5.28 |
| -3.5 | 0 | 0.00 | 0.00 | -4.28 |
| -2.5 | 0.1 | 0.05 | -0.13 | -3.28 |
| -1.5 | 5.9 | 3.15 | -4.73 | -2.28 |
| -0.5 | 32.8 | 17.52 | -8.76 | -1.28 |
| 0.5 | 74.4 | 39.74 | 19.87 | -0.28 |
| 1.5 | 55.3 | 29.54 | 44.31 | 0.72 |
| 2.5 | 14.9 | 7.96 | 19.90 | 1.72 |
| 3.5 | 2.6 | 1.39 | 4.86 | 2.72 |
| 4.5 | 1.2 | 0.64 | 2.88 | 3.72 |
| | 187.2 | 100 | 78.21 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|--------|-----------|-----------|-----------|
| Midpoint | | | | |
| -5.5 | 39.46 | 0.00 | 0.00 | 0.00 |
| -4.5 | 27.90 | 0.00 | 0.00 | 0.00 |
| -3.5 | 18.34 | 0.00 | 0.00 | 0.00 |
| -2.5 | 10.77 | 0.58 | -1.89 | 6.20 |
| -1.5 | 5.21 | 16.41 | -37.46 | 85.48 |
| -0.5 | 1.64 | 28.80 | -36.92 | 47.34 |
| 0.5 | 0.08 | 3.16 | -0.89 | 0.25 |
| 1.5 | 0.52 | 15.23 | 10.93 | 7.85 |
| 2.5 | 2.95 | 23.49 | 40.36 | 69.33 |
| 3.5 | 7.39 | 10.26 | 27.89 | 75.79 |
| 4.5 | 13.82 | 8.86 | 32.94 | 122.49 |
| | 106.79 | 34.96 | 414.72 | |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 0.7820512 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 1.0678829 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.0333842$$

$$\begin{aligned} \text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= 0.3496097 \end{aligned}$$

$$\begin{aligned} \text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= 0.3168093 \end{aligned}$$

$$\begin{aligned} \text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 4.1472128 \end{aligned}$$

$$\begin{aligned} \text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 3.6367127 \end{aligned}$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 79.5-80.5

| Phi Class Midpoint | Wt (g) | Wt % | Midpt*Wt% | Deviation Mpt-Mean |
|-----------------------|--------|-------|-----------|-----------------------|
| -5.5 | 0 | 0.00 | 0.00 | -6.37 |
| -4.5 | 0 | 0.00 | 0.00 | -5.37 |
| -3.5 | 0 | 0.00 | 0.00 | -4.37 |
| -2.5 | 1.14 | 0.26 | -0.66 | -3.37 |
| -1.5 | 10.1 | 2.32 | -3.48 | -2.37 |
| -0.5 | 73.42 | 16.88 | -8.44 | -1.37 |
| 0.5 | 178.4 | 41.01 | 20.50 | -0.37 |
| 1.5 | 117.1 | 26.92 | 40.37 | 0.63 |
| 2.5 | 33.4 | 7.68 | 19.19 | 1.63 |
| 3.5 | 11 | 2.53 | 8.85 | 2.63 |
| 4.5 | 10.5 | 2.41 | 10.86 | 3.63 |
| 435.06 | | 100 | 87.20 | |

| Phi Class Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------------------|-------|-----------|-----------|-----------|
| -5.5 | 40.60 | 0.00 | 0.00 | 0.00 |
| -4.5 | 28.86 | 0.00 | 0.00 | 0.00 |
| -3.5 | 19.11 | 0.00 | 0.00 | 0.00 |
| -2.5 | 11.37 | 2.98 | -10.05 | 33.88 |
| -1.5 | 5.63 | 13.06 | -30.98 | 73.50 |
| -0.5 | 1.88 | 31.77 | -43.59 | 59.80 |
| 0.5 | 0.14 | 5.68 | -2.11 | 0.79 |
| 1.5 | 0.39 | 10.61 | 6.67 | 4.19 |
| 2.5 | 2.65 | 20.35 | 33.12 | 53.92 |
| 3.5 | 6.91 | 17.46 | 45.89 | 120.59 |
| 4.5 | 13.16 | 31.77 | 115.25 | 418.11 |
| | | 133.67 | 114.19 | 764.77 |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 0.8720406 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 1.3367386 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.1561741$$

$$\text{Third Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100$$

$$= 1.1419177$$

$$\text{Skewness} = \text{Third Moment} / (\text{Standard deviation}^3)$$

$$= 0.7388649$$

$$\text{Fourth Moment} = \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100$$

$$= 7.6477344$$

$$\text{Kurtosis} = \text{Fourth Moment} / (\text{Standard Deviation}^4)$$

$$= 4.2799609$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 80.5-81.5

| Phi Class | Midpoint | Wt (g) | Wt % | Midpt*Wt% | Deviation Mpt-Mean |
|-----------|----------|--------|-------|-----------|-----------------------|
| | -5.5 | 44.4 | 16.91 | -92.98 | -4.78 |
| | -4.5 | 0 | 0.00 | 0.00 | -3.78 |
| | -3.5 | 4.71 | 1.79 | -6.28 | -2.78 |
| | -2.5 | 8.7 | 3.31 | -8.28 | -1.78 |
| | -1.5 | 23.77 | 9.05 | -13.58 | -0.78 |
| | -0.5 | 50.16 | 19.10 | -9.55 | 0.22 |
| | 0.5 | 74.1 | 28.21 | 14.11 | 1.22 |
| | 1.5 | 37.09 | 14.12 | 21.18 | 2.22 |
| | 2.5 | 11.46 | 4.36 | 10.91 | 3.22 |
| | 3.5 | 4.44 | 1.69 | 5.92 | 4.22 |
| | 4.5 | 3.8 | 1.45 | 6.51 | 5.22 |
| | | 262.63 | 100 | -72.04 | |

| Phi Class | Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|----------|--------|-----------|-----------|-----------|
| | -5.5 | 22.84 | 386.21 | -1845.94 | 8822.87 |
| | -4.5 | 14.29 | 0.00 | 0.00 | 0.00 |
| | -3.5 | 7.73 | 13.86 | -38.52 | 107.06 |
| | -2.5 | 3.17 | 10.49 | -18.67 | 33.23 |
| | -1.5 | 0.61 | 5.50 | -4.29 | 3.34 |
| | -0.5 | 0.05 | 0.93 | 0.20 | 0.05 |
| | 0.5 | 1.49 | 42.02 | 51.28 | 62.58 |
| | 1.5 | 4.93 | 69.63 | 154.60 | 343.26 |
| | 2.5 | 10.37 | 45.25 | 145.74 | 469.32 |
| | 3.5 | 17.81 | 30.11 | 127.09 | 536.35 |
| | 4.5 | 27.25 | 39.43 | 205.85 | 1074.61 |
| | | 643.43 | -1222.66 | 11452.67 | |

First Moment:

$$\begin{aligned} \text{Mean} &= \text{Sum}(\text{Wt\%} * \text{Midpt}) / 100 \\ &= -0.720386 \end{aligned}$$

Second Moment:

$$\begin{aligned} \text{Dispersion} &= \text{Sum}((\text{Wt\%}) * (\text{Dev}^2)) / 100 \\ &= 6.4343146 \end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 2.5365950$$

$$\text{Third Moment} = \text{Sum}((\text{Wt\%}) * (\text{Dev}^3)) / 100$$

$$= -12.22660$$

$$\text{Skewness} = \text{Third Moment} / (\text{Standard deviation}^3)$$

$$= -0.749122$$

$$\text{Fourth Moment} = \text{Sum}((\text{Wt\%}) * (\text{Dev}^4)) / 100$$

$$= 114.52667$$

$$\text{Kurtosis} = \text{Fourth Moment} / (\text{Standard Deviation}^4)$$

$$= 2.7663178$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 81.5-82.5

| Phi Class | Wt (g) | Wt % | Midpt*Wt% | Deviation |
|-----------|--------|-------|-----------|-----------|
| Midpoint | | | | Mpt-Mean |
| -5.5 | 0 | 0.00 | 0.00 | -5.75 |
| -4.5 | 0 | 0.00 | 0.00 | -4.75 |
| -3.5 | 7.65 | 3.26 | -11.41 | -3.75 |
| -2.5 | 12.33 | 5.25 | -13.14 | -2.75 |
| -1.5 | 18.22 | 7.76 | -11.65 | -1.75 |
| -0.5 | 47.26 | 20.14 | -10.07 | -0.75 |
| 0.5 | 88.2 | 37.58 | 18.79 | 0.25 |
| 1.5 | 41.02 | 17.48 | 26.22 | 1.25 |
| 2.5 | 12.1 | 5.16 | 12.89 | 2.25 |
| 3.5 | 4.63 | 1.97 | 6.91 | 3.25 |
| 4.5 | 3.26 | 1.39 | 6.25 | 4.25 |
| | 234.67 | 100 | 24.80 | |

| Phi Class | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------|--------|-----------|-----------|-----------|
| Midpoint | | | | |
| -5.5 | 33.04 | 0.00 | 0.00 | 0.00 |
| -4.5 | 22.54 | 0.00 | 0.00 | 0.00 |
| -3.5 | 14.05 | 45.79 | -171.63 | 643.27 |
| -2.5 | 7.55 | 39.68 | -109.03 | 299.62 |
| -1.5 | 3.06 | 23.72 | -41.47 | 72.48 |
| -0.5 | 0.56 | 11.27 | -8.43 | 6.30 |
| 0.5 | 0.06 | 2.39 | 0.60 | 0.15 |
| 1.5 | 1.57 | 27.40 | 34.31 | 42.95 |
| 2.5 | 5.07 | 26.15 | 58.89 | 132.62 |
| 3.5 | 10.58 | 20.87 | 67.85 | 220.66 |
| 4.5 | 18.08 | 25.12 | 106.79 | 454.09 |
| | 222.38 | -62.11 | 1872.15 | |

First Moment:

$$\text{Mean} = \frac{\text{Sum}(\text{Wt}\% * \text{Midpt})}{100}$$

$$= 0.2479865$$

Second Moment:

$$\text{Dispersion} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^2))}{100}$$

$$= 2.2237862$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.4912364$$

$$\text{Third Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^3))}{100}$$

$$= -0.621126$$

$$\text{Skewness} = \frac{\text{Third Moment}}{(\text{Standard deviation}^3)}$$

$$= -0.187301$$

$$\text{Fourth Moment} = \frac{\text{Sum}((\text{Wt}\%) * (\text{Dev}^4))}{100}$$

$$= 18.721518$$

$$\text{Kurtosis} = \frac{\text{Fourth Moment}}{(\text{Standard Deviation}^4)}$$

$$= 3.7857766$$

Method of Moments Grain Size Analysis

RMA 33085

Sample 84.75-85.00

| Phi Class Midpoint | Wt (g) | Wt % | Midpt*Wt% | Deviation Mpt-Mean |
|-----------------------|--------|-------|-----------|-----------------------|
| -5.5 | 0 | 0.00 | 0.00 | -6.68 |
| -4.5 | 0 | 0.00 | 0.00 | -5.68 |
| -3.5 | 0 | 0.00 | 0.00 | -4.68 |
| -2.5 | 1.96 | 1.41 | -3.52 | -3.68 |
| -1.5 | 8.16 | 5.87 | -8.80 | -2.68 |
| -0.5 | 20.45 | 14.70 | -7.35 | -1.68 |
| 0.5 | 26.5 | 19.05 | 9.53 | -0.68 |
| 1.5 | 41.23 | 29.64 | 44.46 | 0.32 |
| 2.5 | 30.6 | 22.00 | 55.00 | 1.32 |
| 3.5 | 6.1 | 4.39 | 15.35 | 2.32 |
| 4.5 | 4.1 | 2.95 | 13.26 | 3.32 |
| | | 139.1 | 100 | 117.92 |

| Phi Class Midpoint | Dev*2 | Wt%*Dev*2 | Wt%*Dev*3 | Wt%*Dev*4 |
|-----------------------|-------|-----------|-----------|-----------|
| -5.5 | 44.61 | 0.00 | 0.00 | 0.00 |
| -4.5 | 32.25 | 0.00 | 0.00 | 0.00 |
| -3.5 | 21.90 | 0.00 | 0.00 | 0.00 |
| -2.5 | 13.54 | 19.07 | -70.18 | 258.20 |
| -1.5 | 7.18 | 42.11 | -112.82 | 302.27 |
| -0.5 | 2.82 | 41.46 | -69.61 | 116.90 |
| 0.5 | 0.46 | 8.79 | -5.97 | 4.05 |
| 1.5 | 0.10 | 3.05 | 0.98 | 0.31 |
| 2.5 | 1.74 | 38.38 | 50.69 | 66.94 |
| 3.5 | 5.39 | 23.62 | 54.82 | 127.21 |
| 4.5 | 11.03 | 32.50 | 107.94 | 358.44 |
| | | 208.98 | -44.16 | 1234.33 |

First Moment:

$$\begin{aligned}\text{Mean} &= \text{Sum}(\text{Wt}\% * \text{Midpt}) / 100 \\ &= 1.1792235\end{aligned}$$

Second Moment:

$$\begin{aligned}\text{Dispersion} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^2)) / 100 \\ &= 2.0897696\end{aligned}$$

Square Root of Second Moment:

$$\text{Standard Deviation} = 1.4456035$$

$$\begin{aligned}\text{Third Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^3)) / 100 \\ &= -0.441640\end{aligned}$$

$$\begin{aligned}\text{Skewness} &= \text{Third Moment} / (\text{Standard deviation}^3) \\ &= -0.146191\end{aligned}$$

$$\begin{aligned}\text{Fourth Moment} &= \text{Sum}((\text{Wt}\%) * (\text{Dev}^4)) / 100 \\ &= 12.343332\end{aligned}$$

$$\begin{aligned}\text{Kurtosis} &= \text{Fourth Moment} / (\text{Standard Deviation}^4) \\ &= 2.8264127\end{aligned}$$

APPENDIX B. LABORATORY HYDRAULIC CONDUCTIVITY ESTIMATES

| Core # | Depth interval (ft) ¹ | Hydraulic Conductivity Estimates ($\times 10^{-2}$ cm/sec) | | | |
|--------|----------------------------------|---|---------------|-----------------|-------------|
| | | HAZEN | MASCH & DENNY | SUMMERS & WEBER | PERMEAMETER |
| 1 | 59.50-61.00 | 8.41 | 0.99 | 3.5 | 3.45 |
| 1 | 61.00-62.00 | 19.36 | 1.89 | 8.8 | |
| 1 | 62.00-63.50 | 10.89 | 0.99 | 8.8 | 0.90 |
| 1 | 69.25-70.25 | 7.29 | 0.80 | 5.3 | 3.75 |
| 1 | 70.25-71.25 | 14.44 | 2.13 | 5.3 | |
| 1 | 71.25-72.00 | 2.56 | 1.89 | 3.2 | 0.77 |
| 1 | 74.00-75.00 | 3.61 | 0.85 | 3.5 | 2.27 |
| 1 | 75.00-76.00 | 9.00 | 1.70 | 3.2 | |
| 1 | 76.00-77.00 | 7.29 | 1.89 | 1.8 | 2.10 |
| 1 | 77.00-78.00 | 6.76 | 3.22 | 1.4 | |
| 1 | 78.00-79.00 | 6.76 | 3.50 | 0.7 | 2.61 |
| 1 | 79.00-80.00 | 1.96 | 2.41 | 0.7 | |
| 1 | 80.00-81.00 | 7.84 | 1.89 | 1.8 | 2.48 |
| 1 | 81.00-81.75 | 10.89 | 1.23 | 7.9 | 1.55 |
| 1 | 81.75-82.75 | 16.00 | 1.70 | 1.4 | 1.19 |
| 1 | 82.75-83.75 | 7.84 | 0.85 | 5.3 | |
| 1 | 84.00-85.25 | 3.61 | 2.32 | 1.4 | 2.18 |
| 1 | 85.25-86.25 | 5.29 | 0.85 | 3.5 | 1.58 |
| 1 | 86.25-87.25 | 0.49 | 0.40 | 1.4 | |
| 1 | 87.25-88.50 | 0.64 | 0.38 | 3.5 | 0.01 |
| 2 | 56.50-57.50 | 3.61 | 0.95 | 3.2 | |
| 2 | 57.50-58.50 | 9.00 | 1.07 | 4.4 | |
| 2 | 58.50-59.50 | 14.44 | 0.95 | 5.3 | |
| 2 | 59.50-60.50 | 20.25 | 0.71 | 10.6 | |
| 2 | 60.50-61.50 | 10.89 | 0.71 | 8.8 | |
| 2 | 64.00-65.00 | 6.25 | 1.42 | 3.2 | |
| 2 | 65.00-66.00 | 25.00 | 0.76 | 10.6 | |
| 2 | 66.00-67.00 | 43.56 | 1.42 | 17.6 | |
| 2 | 67.00-68.00 | 29.16 | 2.60 | 14.1 | |
| 3 | 59.80-61.05 | 10.89 | 0.99 | 3.5 | |
| 3 | 61.05-62.30 | 9.00 | 0.57 | 3.5 | |
| 3 | 64.80-65.80 | 12.96 | 0.90 | 14.1 | |
| 3 | 65.80-66.80 | 24.01 | 1.18 | 10.6 | |
| 3 | 66.80-67.80 | 19.36 | 1.18 | 10.6 | |
| 3 | 67.80-69.80 | 18.49 | 0.80 | 12.3 | |
| 3 | 69.80-70.80 | 9.00 | 2.56 | 2.8 | |
| 3 | 70.80-71.80 | 36.00 | 1.18 | 12.3 | |
| 3 | 71.80-72.80 | 31.36 | 0.43 | 16.9 | |
| 3 | 72.80-74.30 | 1.69 | 0.14 | 7.1 | |
| 3 | 74.80-75.80 | 2.10 | 2.36 | 0.9 | |
| 3 | 75.80-76.80 | 3.80 | 0.94 | 1.8 | |
| 3 | 76.80-77.80 | 6.00 | 3.77 | 0.9 | |
| 3 | 77.80-78.80 | 3.60 | 3.30 | 0.9 | |
| 3 | 79.80-80.80 | 6.25 | 4.72 | 0.9 | |
| 3 | 80.80-81.80 | 4.40 | 3.30 | 0.9 | |
| 3 | 81.80-82.80 | 8.70 | 0.38 | 7.1 | |
| 3 | 82.80-83.80 | 7.29 | 1.18 | 2.7 | |
| 3 | 86.05-86.30 | 2.10 | 0.99 | 1.8 | |

(1) All depths relative to a ground elevation of 5176.4 ft

Hazen's Method for Estimating Hydraulic Conductivity

Core #1 = Injection well 33080

| Interval | | D10 | K | K/Kmax |
|----------|--------|-------|------------|--------|
| Top | Bottom | (cm) | (E-2 cm/s) | |
| 59.50 | 61.00 | 0.029 | 8.41 | 0.19 |
| 61.00 | 62.00 | 0.044 | 19.36 | 0.44 |
| 62.00 | 63.50 | 0.033 | 10.89 | 0.25 |
| 69.25 | 70.25 | 0.027 | 7.29 | 0.17 |
| 70.25 | 71.25 | 0.038 | 14.44 | 0.33 |
| 71.25 | 72.00 | 0.016 | 2.56 | 0.06 |
| 74.00 | 75.00 | 0.019 | 3.61 | 0.08 |
| 75.00 | 76.00 | 0.030 | 9.00 | 0.21 |
| 76.00 | 77.00 | 0.027 | 7.29 | 0.17 |
| 77.00 | 78.00 | 0.026 | 6.76 | 0.16 |
| 78.00 | 79.00 | 0.026 | 6.76 | 0.16 |
| 79.00 | 80.00 | 0.014 | 1.96 | 0.04 |
| 80.00 | 81.00 | 0.028 | 7.84 | 0.18 |
| 81.00 | 81.75 | 0.033 | 10.89 | 0.25 |
| 81.75 | 82.75 | 0.040 | 16.00 | 0.37 |
| 82.75 | 83.75 | 0.028 | 7.84 | 0.18 |
| 84.00 | 85.25 | 0.019 | 3.61 | 0.08 |
| 85.25 | 86.25 | 0.023 | 5.29 | 0.12 |
| 86.25 | 87.25 | 0.007 | 0.49 | 0.01 |
| 87.25 | 88.50 | 0.008 | 0.64 | 0.01 |

Core #2 = 2 feet adjacent to injection well 33080

| Interval | | D10 | K | K/Kmax |
|----------|--------|-------|------------|--------|
| Top | Bottom | (cm) | (E-2 cm/s) | |
| 56.50 | 57.50 | 0.019 | 3.61 | 0.08 |
| 57.50 | 58.50 | 0.030 | 9.00 | 0.21 |
| 58.50 | 59.50 | 0.038 | 14.44 | 0.33 |
| 59.50 | 60.50 | 0.045 | 20.25 | 0.46 |
| 60.50 | 61.50 | 0.033 | 10.89 | 0.25 |
| 64.00 | 65.00 | 0.025 | 6.25 | 0.14 |
| 65.00 | 66.00 | 0.050 | 25.00 | 0.57 |
| 66.00 | 67.00 | 0.066 | 43.56 | 1.00 |
| 67.00 | 68.00 | 0.054 | 29.16 | 0.67 |

Hazen's Method for Estimating Hydraulic Conductivity

Core #3 = Extraction well 33085

| Interval Top | Bottom | D10 (cm) | K (E-2 cm/s) | K/Kmax |
|-----------------|--------|-------------|-----------------|--------|
| 58.50 | 59.75 | 0.033 | 10.89 | 0.25 |
| 59.75 | 61.00 | 0.030 | 9.00 | 0.21 |
| 63.50 | 64.50 | 0.036 | 12.96 | 0.30 |
| 64.50 | 65.50 | 0.049 | 24.01 | 0.55 |
| 65.50 | 66.50 | 0.044 | 19.36 | 0.44 |
| 66.50 | 68.50 | 0.043 | 18.49 | 0.42 |
| 68.50 | 69.50 | 0.030 | 9.00 | 0.21 |
| 69.50 | 70.50 | 0.060 | 36.00 | 0.83 |
| 70.50 | 71.50 | 0.056 | 31.36 | 0.72 |
| 71.50 | 73.00 | 0.013 | 1.69 | 0.04 |
| 73.50 | 74.50 | 0.015 | 2.10 | 0.05 |
| 74.50 | 75.50 | 0.020 | 3.80 | 0.09 |
| 75.50 | 76.50 | 0.025 | 6.00 | 0.14 |
| 76.50 | 77.50 | 0.019 | 3.60 | 0.08 |
| 78.50 | 79.50 | 0.025 | 6.25 | 0.14 |
| 79.50 | 80.50 | 0.021 | 4.40 | 0.10 |
| 80.50 | 81.50 | 0.030 | 8.70 | 0.20 |
| 81.50 | 82.50 | 0.027 | 7.29 | 0.17 |
| 84.75 | 85.00 | 0.014 | 2.10 | 0.04 |

Masch and Denny Technique for Estimating Hydraulic Conductivity

Grain Size Parameters:

Core #1 = Injection well 33080

Interval

| Top | Bottom | D50 | DISP | D5 | D16 | D84 | D95 |
|-------|--------|------|------|------|------|-----|-----|
| 59.50 | 61.00 | -0.4 | 1.50 | -2.9 | -1.9 | 1.0 | 2.2 |
| 61.00 | 62.00 | -1.2 | 1.42 | -3.2 | -2.7 | 0.2 | 1.4 |
| 62.00 | 63.50 | -1.2 | 1.60 | -3.3 | -2.9 | 0.3 | 2.0 |
| 69.25 | 70.25 | -0.4 | 1.64 | -3.2 | -2.5 | 0.9 | 2.0 |
| 70.25 | 71.25 | -0.8 | 1.34 | -3.0 | -2.2 | 0.5 | 1.4 |
| 71.25 | 72.00 | -0.7 | 1.38 | -2.5 | -1.5 | 0.7 | 3.0 |
| 74.00 | 75.00 | -0.2 | 1.61 | -2.8 | -1.9 | 1.4 | 2.4 |
| 75.00 | 76.00 | -0.1 | 1.31 | -3.0 | -1.5 | 1.0 | 1.5 |
| 76.00 | 77.00 | 0 | 1.24 | -2.4 | -1.2 | 1.1 | 2.0 |
| 77.00 | 78.00 | 0.2 | 1.07 | -1.5 | -0.7 | 1.2 | 2.4 |
| 78.00 | 79.00 | 0.1 | 1.08 | -1.4 | -0.8 | 1.2 | 2.4 |
| 79.00 | 80.00 | 0.6 | 1.07 | -0.5 | -0.2 | 2.0 | 2.9 |
| 80.00 | 81.00 | 0 | 1.23 | -2.4 | -1.3 | 1.0 | 2.0 |
| 81.00 | 81.75 | -0.9 | 1.53 | -3.2 | -2.6 | 0.5 | 1.8 |
| 81.75 | 82.75 | 0.3 | 1.25 | -2.1 | -0.8 | 1.4 | 2.5 |
| 82.75 | 83.75 | -0.7 | 1.67 | -3.2 | -2.5 | 0.8 | 2.4 |
| 84.00 | 85.25 | 0.4 | 1.13 | -1.6 | -0.7 | 1.4 | 2.4 |
| 85.25 | 86.25 | -0.1 | 1.63 | -3.1 | -2.1 | 1.2 | 2.2 |
| 86.25 | 87.25 | 0.5 | 2.08 | -2.5 | -1.8 | 2.6 | 4.0 |
| 87.25 | 88.50 | -0.5 | 2.17 | -2.9 | -2.2 | 2.4 | 3.8 |

Hydraulic Conductivity Estimates:

Core #1 = Injection well 33080

Interval K K K/Kmax
Top Bottom gal/d*ft2 10-2cm/s

| | | | | |
|-------|-------|-----|------|------|
| 59.50 | 61.00 | 210 | 0.99 | 0.21 |
| 61.00 | 62.00 | 400 | 1.89 | 0.40 |
| 62.00 | 63.50 | 210 | 0.99 | 0.21 |
| 69.25 | 70.25 | 170 | 0.80 | 0.17 |
| 70.25 | 71.25 | 450 | 2.13 | 0.45 |
| 71.25 | 72.00 | 400 | 1.89 | 0.40 |
| 74.00 | 75.00 | 180 | 0.85 | 0.18 |
| 75.00 | 76.00 | 360 | 1.70 | 0.36 |
| 76.00 | 77.00 | 400 | 1.89 | 0.40 |
| 77.00 | 78.00 | 680 | 3.22 | 0.68 |
| 78.00 | 79.00 | 740 | 3.50 | 0.74 |
| 79.00 | 80.00 | 510 | 2.41 | 0.51 |
| 80.00 | 81.00 | 400 | 1.89 | 0.40 |
| 81.00 | 81.75 | 260 | 1.23 | 0.26 |
| 81.75 | 82.75 | 360 | 1.70 | 0.36 |
| 82.75 | 83.75 | 180 | 0.85 | 0.18 |
| 84.00 | 85.25 | 490 | 2.32 | 0.49 |
| 85.25 | 86.25 | 180 | 0.85 | 0.18 |
| 86.25 | 87.25 | 85 | 0.40 | 0.09 |
| 87.25 | 88.50 | 80 | 0.38 | 0.08 |

Masch and Denny Technique for Estimating Hydraulic Conductivity

Grain Size Parameters:

Core #2 = 2 feet from injection well 33080

| Interval | Top | Bottom | D50 | DISP | D5 | D16 | D84 | D95 |
|----------|-------|--------|------|------|------|------|------|-----|
| | 56.50 | 57.50 | 0.0 | 1.57 | -3.0 | -1.5 | 1.4 | 2.6 |
| | 57.50 | 58.50 | -0.4 | 1.54 | -3.4 | -2.2 | 0.8 | 1.8 |
| | 58.50 | 59.50 | -0.8 | 1.59 | -4.0 | -2.6 | 0.5 | 1.4 |
| | 59.50 | 60.50 | -1.5 | 1.80 | -4.8 | -3.3 | 0.2 | 1.3 |
| | 60.50 | 61.50 | -1.0 | 1.73 | -4.1 | -2.9 | 0.5 | 1.7 |
| | 64.00 | 65.00 | -0.3 | 1.40 | -2.4 | -1.6 | 1.1 | 2.4 |
| | 65.00 | 66.00 | -1.5 | 1.75 | -4.5 | -3.3 | 0.2 | 1.3 |
| | 66.00 | 67.00 | -2.4 | 1.60 | -4.4 | -3.8 | -0.6 | 0.9 |
| | 67.00 | 68.00 | -1.8 | 1.41 | -3.3 | -3.0 | -0.1 | 1.2 |

Hydraulic Conductivity Estimates:

Core #2 = 2 feet from injection well 33080

| Interval | Top | Bottom | K gal/d*ft ² | K 10-2cm/s | K/Kmax |
|----------|-------|--------|----------------------------|---------------|--------|
| | 56.50 | 57.50 | 200 | 0.95 | 0.20 |
| | 57.50 | 58.50 | 225 | 1.07 | 0.23 |
| | 58.50 | 59.50 | 200 | 0.95 | 0.20 |
| | 59.50 | 60.50 | 150 | 0.71 | 0.15 |
| | 60.50 | 61.50 | 150 | 0.71 | 0.15 |
| | 64.00 | 65.00 | 300 | 1.42 | 0.30 |
| | 65.00 | 66.00 | 160 | 0.76 | 0.16 |
| | 66.00 | 67.00 | 300 | 1.42 | 0.30 |
| | 67.00 | 68.00 | 550 | 2.60 | 0.55 |

Masch and Denny Technique for Estimating Hydraulic Conductivity

Grain Size Parameters:

Core #3 = Extraction well 33085

Interval

| Top | Bottom | D50 | DISP | D5 | D16 | D84 | D95 |
|-------|--------|------|------|------|------|------|-----|
| 58.50 | 59.75 | -0.3 | 1.51 | -3.7 | -2.1 | 0.8 | 1.5 |
| 59.75 | 61.00 | -0.2 | 1.83 | -5.0 | -2.2 | 1.0 | 1.8 |
| 63.50 | 64.50 | -1.8 | 1.68 | -3.6 | -3.0 | 0.4 | 1.9 |
| 64.50 | 65.50 | -1.6 | 1.58 | -3.8 | -3.0 | 0.1 | 1.5 |
| 65.50 | 66.50 | -1.5 | 1.59 | -3.8 | -3.0 | 0.2 | 1.4 |
| 66.50 | 68.50 | -1.6 | 1.75 | -4.1 | -3.3 | 0.3 | 1.5 |
| 68.50 | 69.50 | -0.5 | 1.24 | -2.2 | -1.5 | 0.9 | 2.0 |
| 69.50 | 70.50 | -1.8 | 1.63 | -4.5 | -3.3 | -0.1 | 1.0 |
| 70.50 | 71.50 | -2.2 | 2.06 | -5.6 | -4.2 | -0.1 | 1.2 |
| 71.50 | 73.00 | -0.9 | 2.91 | -5.6 | -4.2 | 2.0 | 3.4 |
| 73.50 | 74.50 | 0.3 | 1.15 | -1.5 | -0.8 | 1.5 | 2.4 |
| 74.50 | 75.50 | -0.3 | 1.52 | -2.8 | -1.8 | 1.0 | 2.8 |
| 75.50 | 76.50 | 0.0 | 0.97 | -1.8 | -1.0 | 0.8 | 1.8 |
| 76.50 | 77.50 | -0.3 | 1.11 | -1.8 | -1.3 | 1.0 | 1.8 |
| 78.50 | 79.50 | -0.3 | 1.02 | -1.8 | -1.3 | 0.8 | 1.7 |
| 79.50 | 80.50 | -0.3 | 1.10 | -1.8 | -1.3 | 0.8 | 2.0 |
| 80.50 | 81.50 | -1.0 | 3.03 | -8.0 | -6.0 | 0.3 | 1.7 |
| 81.50 | 82.50 | -0.7 | 1.46 | -3.8 | -2.0 | 0.5 | 1.8 |
| 84.75 | 85.00 | 0.3 | 1.49 | -2.4 | -1.4 | 1.6 | 2.5 |

Hydraulic Conductivity Estimates:

Core #3 = Extraction well 33085

Interval

| Top | Bottom | K gal/d*ft ² | K 10 ⁻² cm/s | K/Kmax |
|-------|--------|----------------------------|----------------------------|--------|
| 58.50 | 59.75 | 210 | 0.99 | 0.21 |
| 59.75 | 61.00 | 120 | 0.57 | 0.12 |
| 63.50 | 64.50 | 190 | 0.90 | 0.19 |
| 64.50 | 65.50 | 250 | 1.18 | 0.25 |
| 65.50 | 66.50 | 250 | 1.18 | 0.25 |
| 66.50 | 68.50 | 170 | 0.80 | 0.17 |
| 68.50 | 69.50 | 540 | 2.56 | 0.54 |
| 69.50 | 70.50 | 250 | 1.18 | 0.25 |
| 70.50 | 71.50 | 90 | 0.43 | 0.09 |
| 71.50 | 73.00 | 30 | 0.14 | 0.03 |
| 73.50 | 74.50 | 500 | 2.36 | 0.50 |
| 74.50 | 75.50 | 200 | 0.94 | 0.20 |
| 75.50 | 76.50 | 800 | 3.77 | 0.80 |
| 76.50 | 77.50 | 700 | 3.30 | 0.70 |
| 78.50 | 79.50 | 1000 | 4.72 | 1.00 |
| 79.50 | 80.50 | 700 | 3.30 | 0.70 |
| 80.50 | 81.50 | 80 | 0.38 | 0.08 |
| 81.50 | 82.50 | 250 | 1.18 | 0.25 |
| 84.75 | 85.00 | 210 | 0.99 | 0.21 |

Summer and Weber's Method for Estimating Hydraulic Conductivity

Grain Size Parameters:

Core #1 = Injection Well 33080

| Interval Top | Bottom | % Fine | % Sand | % Gravel |
|-----------------|--------|--------|--------|----------|
| 59.50 | 61.00 | 1.2 | 77.6 | 21.2 |
| 61.00 | 62.00 | 0.9 | 56.6 | 42.5 |
| 62.00 | 63.50 | 1.1 | 53.5 | 45.4 |
| 69.25 | 70.25 | 0.7 | 74.1 | 25.2 |
| 70.25 | 71.25 | 0.3 | 68.3 | 31.4 |
| 71.25 | 72.00 | 2.2 | 81.7 | 16.1 |
| 74.00 | 75.00 | 1.0 | 77.4 | 21.6 |
| 75.00 | 76.00 | 0.7 | 83.3 | 16.0 |
| 76.00 | 77.00 | 0.8 | 88.8 | 10.4 |
| 77.00 | 78.00 | 1.8 | 93.3 | 4.9 |
| 78.00 | 79.00 | 1.5 | 95.2 | 3.3 |
| 79.00 | 80.00 | 1.9 | 97.4 | 0.7 |
| 80.00 | 81.00 | 0.8 | 88.3 | 10.9 |
| 81.00 | 81.75 | 1.0 | 61.7 | 37.3 |
| 81.75 | 82.75 | 1.4 | 91.2 | 7.4 |
| 82.75 | 83.75 | 1.9 | 69.0 | 29.1 |
| 84.00 | 85.25 | 1.2 | 93.3 | 5.5 |
| 85.25 | 86.25 | 1.2 | 77.5 | 21.3 |
| 86.25 | 87.25 | 8.7 | 71.7 | 19.6 |
| 87.25 | 88.50 | 6.8 | 64.7 | 28.5 |

Hydraulic Conductivity Estimates:

Core #1 = Injection Well 33080

| Interval Top | Bottom | K ft/d | K 10-2cm/s | K/Kmax |
|-----------------|--------|-----------|---------------|--------|
| 59.50 | 61.00 | 100 | 3.5 | 0.20 |
| 61.00 | 62.00 | 250 | 8.8 | 0.50 |
| 62.00 | 63.50 | 250 | 8.8 | 0.50 |
| 69.25 | 70.25 | 150 | 5.3 | 0.30 |
| 70.25 | 71.25 | 150 | 5.3 | 0.30 |
| 71.25 | 72.00 | 90 | 3.2 | 0.18 |
| 74.00 | 75.00 | 100 | 3.5 | 0.20 |
| 75.00 | 76.00 | 90 | 3.2 | 0.18 |
| 76.00 | 77.00 | 50 | 1.8 | 0.10 |
| 77.00 | 78.00 | 40 | 1.4 | 0.08 |
| 78.00 | 79.00 | 20 | 0.7 | 0.04 |
| 79.00 | 80.00 | 20 | 0.7 | 0.04 |
| 80.00 | 81.00 | 50 | 1.8 | 0.10 |
| 81.00 | 81.75 | 225 | 7.9 | 0.45 |
| 81.75 | 82.75 | 40 | 1.4 | 0.08 |
| 82.75 | 83.75 | 150 | 5.3 | 0.30 |
| 84.00 | 85.25 | 40 | 1.4 | 0.08 |
| 85.25 | 86.25 | 100 | 3.5 | 0.20 |
| 86.25 | 87.25 | 40 | 1.4 | 0.08 |
| 87.25 | 88.50 | 100 | 3.5 | 0.20 |

Summer and Weber's Method for Estimating Hydraulic Conductivity

Grain Size Parameters:

Core #2 = 2 feet adjacent to injection well 33080

Interval

| Top | Bottom | % Fine | % Sand | % Gravel |
|-------|--------|--------|--------|----------|
| 56.50 | 57.50 | 2.0 | 82.8 | 15.2 |
| 57.50 | 58.50 | 1.1 | 74.9 | 24.0 |
| 58.50 | 59.50 | 0.9 | 67.3 | 31.8 |
| 59.50 | 60.50 | 0.7 | 49.0 | 50.3 |
| 60.50 | 61.50 | 0.9 | 59.9 | 39.2 |
| 64.00 | 65.00 | 1.3 | 82.0 | 16.7 |
| 65.00 | 66.00 | 0.6 | 48.4 | 51.0 |
| 66.00 | 67.00 | 0.5 | 27.6 | 71.9 |
| 67.00 | 68.00 | 0.5 | 40.7 | 58.8 |

Hydraulic Conductivity Estimates:

Core #2 = 2 feet adjacent to injection well 33080

Interval

| Top | Bottom | K ft/d | K 10-2cm/s | K/Kmax |
|-------|--------|-----------|---------------|--------|
| 56.50 | 57.50 | 90 | 3.2 | 0.18 |
| 57.50 | 58.50 | 125 | 4.4 | 0.25 |
| 58.50 | 59.50 | 150 | 5.3 | 0.30 |
| 59.50 | 60.50 | 300 | 10.6 | 0.60 |
| 60.50 | 61.50 | 250 | 8.8 | 0.50 |
| 64.00 | 65.00 | 90 | 3.2 | 0.18 |
| 65.00 | 66.00 | 300 | 10.6 | 0.60 |
| 66.00 | 67.00 | 500 | 17.6 | 1.00 |
| 67.00 | 68.00 | 400 | 14.1 | 0.80 |

Summer and Weber's Method for Estimating Hydraulic Conductivity

Grain Size Parameters:

Core #3 = Extraction Well 33085

Interval

| Top | Bottom | % Fine | % Sand | % Gravel |
|-------|--------|--------|--------|----------|
| 58.50 | 59.75 | 0.4 | 76.9 | 22.7 |
| 59.75 | 61.00 | 0.8 | 77.9 | 21.3 |
| 63.50 | 64.50 | 0.6 | 38.9 | 60.5 |
| 64.50 | 65.50 | 0.6 | 47.5 | 51.9 |
| 65.50 | 66.50 | 0.5 | 48.8 | 50.7 |
| 66.50 | 68.50 | 0.7 | 45.9 | 53.4 |
| 68.50 | 69.50 | 0.6 | 83.8 | 15.6 |
| 69.50 | 70.50 | 0.5 | 42.6 | 56.9 |
| 70.50 | 71.50 | 0.6 | 35.5 | 63.9 |
| 71.50 | 73.00 | 4.0 | 52.3 | 43.7 |
| 73.50 | 74.50 | 1.4 | 97.8 | 0.8 |
| 74.50 | 75.50 | 1.2 | 88.7 | 10.1 |
| 75.50 | 76.50 | 1.1 | 95.7 | 3.3 |
| 76.50 | 77.50 | 2.2 | 93.2 | 4.6 |
| 78.50 | 79.50 | 0.6 | 96.2 | 3.2 |
| 79.50 | 80.50 | 2.4 | 95.0 | 2.6 |
| 80.50 | 81.50 | 1.5 | 67.5 | 31.1 |
| 81.50 | 82.50 | 1.4 | 82.3 | 16.3 |
| 84.75 | 85.00 | 3.0 | 87.0 | 10.0 |

Hydraulic Conductivity Estimates:

Core #3 = Extraction Well 33085

Interval

| Top | Bottom | K ft/d | K 10-2cm/s | K/Kmax |
|-------|--------|-----------|---------------|--------|
| 58.50 | 59.75 | 100 | 3.5 | 0.20 |
| 59.75 | 61.00 | 100 | 3.5 | 0.20 |
| 63.50 | 64.50 | 400 | 14.1 | 0.80 |
| 64.50 | 65.50 | 300 | 10.6 | 0.60 |
| 65.50 | 66.50 | 300 | 10.6 | 0.60 |
| 66.50 | 68.50 | 350 | 12.3 | 0.70 |
| 68.50 | 69.50 | 80 | 2.8 | 0.16 |
| 69.50 | 70.50 | 350 | 12.3 | 0.70 |
| 70.50 | 71.50 | 450 | 16.9 | 0.96 |
| 71.50 | 73.00 | 200 | 7.1 | 0.40 |
| 73.50 | 74.50 | 25 | 0.9 | 0.05 |
| 74.50 | 75.50 | 50 | 1.8 | 0.10 |
| 75.50 | 76.50 | 25 | 0.9 | 0.05 |
| 76.50 | 77.50 | 25 | 0.9 | 0.05 |
| 78.50 | 79.50 | 25 | 0.9 | 0.05 |
| 79.50 | 80.50 | 25 | 0.9 | 0.05 |
| 80.50 | 81.50 | 200 | 7.1 | 0.40 |
| 81.50 | 82.50 | 75 | 2.7 | 0.15 |
| 84.75 | 85.00 | 50 | 1.8 | 0.10 |

APPENDIX C. LOCATION AND CONSTRUCTION OF WELLS

| <u>Well #</u> | <u>Well Type</u> | <u>Ground Elevation</u> | <u>Distance from 33080</u> | <u>Screened Depth</u> | <u>Bentonite Seal Depth</u> | <u>Depth to water</u> |
|-------------------|----------------------|-----------------------------|--------------------------------|---------------------------|---------------------------------|---------------------------|
| 33080 | Injection | 5176.4 | 0 | 52.5-87.5 | 43.5-48.5 | 56.8 |
| 33082 | Drive Pt B | 5176.0 | 9.13 | 69.0-69.5 | ---- | 56.2 |
| 33083 | Drive Pt C | 5176.0 | 9.13 | 78.0-78.5 | ---- | 56.2 |
| 33084 | Drive Pt D | 5176.0 | 9.13 | 84.0-84.5 | ---- | 56.2 |
| 33085 | Extraction | 5175.1 | 27.61 | 54.5-86.0 | 47.0-52.0 | 55.2 |
| 33086 | Monitoring | 5175.7 | 17.09 | 56.0-86.0 | 49.0-54.0 | 55.8 |
| 33087 | Drive Pt A | 5176.1 | 11.75 | 65.5-66.0 | 49.0-54.0 | 56.1 |

EBASCO SERVICES INCORPORATED
ENVIRONMENTAL PROGRAM AT ROCKY MOUNTAIN ARSENAL

FIELD LOG OF BORING

SHEET 1 OF 2

| PROJECT NAME Rocky Mountain Arsenal | | TASK NUMBER 48 | | SITE TYPE BORE | | SITE ID 33080 | | | | | | | |
|---|-----|---------------------|---|--|----------------------------|---------------------------------------|----|-------------|----------|-------------------------|-------|-----------------------------|-------------------------------|
| DRILLING COMPANY Custom Auger | | DRILLER F. PARKS | | DATE AND TIME STARTED 87286 0829 | | DATE AND TIME COMPLETED 87294 1604 | | | | | | | |
| DRILLING EQUIPMENT METHOD CME hollow stem auger / piston drive sampler (s) | | | | COMPLETION DEPTH 87.5 ft 2669 cm | | WATER LEVEL 57.5 ft 1753 cm | | | | | | | |
| SIZE AND TYPE OF BIT 8 inch | | | | HYDROGEOLOGIST / DATE J. Martin / 87294 | | CHECKED BY / DATE | | | | | | | |
| DEPTH ft | cm | SAMPLE INTERVAL | DESCRIPTION (COLOR, TEXTURE, STRUCTURE) | ESTIMATED PERCENTAGE OF | | | | | MOISTURE | CONSISTENCY/ DENSITY | COLOR | COMMENTS (SAMPLE NUMBER) | |
| | | | | VERY COARSE GRAVEL | SAND COARSE MEDIUM FINE | | | SILT / CLAY | | | | | CLAY |
| 0 | 0 | | 0-91 Yellowish brown silty fine sand, roots | - | - | - | 60 | 10 | ML | DRY | VL | 100% | Logged withings from 0- |
| 1 | 30 | | | | | | | | | | | | |
| 2 | 61 | | | | | | | | | | | | |
| 3 | 91 | | 91-152 - Yellowish brn fine sand, minor silt | - | - | - | 90 | 10 | ML | LM | VL | 100% | |
| 4 | 122 | | 152-183 Yellowish brn clayey fine sand, trace of sec grains, mica | - | 1 | - | 95 | 7 | ML | LM | L | 100% | |
| 5 | 152 | | clay in bottles | | | | | | | | | | |
| 6 | 183 | | 183-305 - Same | | | | | | | | | | |
| 7 | 213 | | | | | | | | | | | | |
| 8 | 244 | | | | | | | | | | | | |
| 9 | 274 | | 274-305 CaCO ₃ in small nodules | | | | | | | | | | |
| 10 | 305 | | | | | | | | | | | | |

EBASCO SERVICES INCORPORATED
ENVIRONMENTAL PROGRAM AT ROCKY MOUNTAIN ARSENAL

FIELD LOG OF BORING

| SITE TYPE | | SITE ID | | SHEET 2 OF 8 | | | | | | | | | | |
|-----------|-----------------|----------------------|------------------|---|-------------------------|------|----|----|-------------|--------------------------|----------|---------------------|----------|--------------------------|
| BORE | | 33080 | | | | | | | | | | | | |
| DEPTH | SAMPLE INTERVAL | DESCRIPTION INTERVAL | RECOVERY (cm/cm) | DESCRIPTION (COLOR, TEXTURE, STRUCTURE) | ESTIMATED PERCENTAGE OF | | | | | SOIL CLASSIFICATION USCS | MOISTURE | CONSISTENCY/DENSITY | COLOR | COMMENTS (SAMPLE NUMBER) |
| | | | | | VERY COARSE / GRAVEL | SAND | | | SILT / CLAY | | | | | |
| COARSE | MEDIUM | FINE | | | | | | | | | | | | |
| 10-305 | | | | 305-350 Yellowish brown med-ck sandy granular gravel, small pebbles, poorly sorted | 40 | 30 | 30 | - | Z | GP | Lm | VL | 10YR 7/6 | |
| 11-335 | | | | 350-427 Brownish yellow v.ck to med ck minor granules and small pebbles moderately sorted, subangular | 10 | 30 | 60 | - | Z | GP | Lm | VL | 10YR 7/6 | |
| 12-366 | | | | | | | | | | | | | | |
| 13-396 | | | | | | | | | | | | | | |
| 14-427 | | | | 427-518 Yellowish brn coarse sand, minor to med granules, well sorted, subrounded grains | 5 | 95 | - | - | Z | GW | Lm | VL | 10YR 7/4 | |
| 15-457 | | | | | | | | | | | | | | |
| 16-488 | | | | | | | | | | | | | | |
| 17-518 | | | | 518-579 Brownish yellow coarse sand, minor granules, fine to med, well sorted, subrounded grains | 5 | 93 | - | 2 | Z | GW | Lm | VL | 10YR 7/6 | |
| 18-549 | | | | | | | | | | | | | | |
| 19-579 | | | | 579-599 Same | | | | | | | | | | |
| 20-610 | | | | 599-610 Brownish yellow med. to coarse sandy gravel w/ minor sm pebbles poorly sorted | 10 | 55 | 35 | - | Z | GP | Lm | VL | 10YR 7/6 | |
| 21-640 | | | | 610-732 Lt yellowish brn fine to med. sand, trace of granules, minor coarse | 3 | 7 | 60 | 30 | Z | SP | Lm | VL | 10YR 7/4 | |
| 22-670 | | | | | | | | | | | | | | |
| 23-701 | | | | | | | | | | | | | | |

EBASCO SERVICES INCORPORATED
ENVIRONMENTAL PROGRAM AT ROCKY MOUNTAIN ARSENAL

FIELD LOG OF BORING

| DEPTH | | SAMPLE INTERVAL | DESCRIPTION INTERVAL | RECOVERY (cm/cm) | DESCRIPTION (COLOR, TEXTURE, STRUCTURE) | ESTIMATED PERCENTAGE OF | | | | | SILT/CLAY | SOIL CLASSIFICATION USCS | MOISTURE | CONSISTENCY/ DENSITY | COLOR | COMMENTS (SAMPLE NUMBER) |
|-------|------|--------------------|-------------------------|---------------------|--|----------------------------|--------|------|----|-------|-----------|--------------------------------|----------|-------------------------|-------|-----------------------------|
| ft | cm | | | | | VERY COARSE / GRAVEL | SAND | | | | | | | | | |
| | | | | | | COARSE | MEDIUM | FINE | | | | | | | | |
| 23 | 701 | | | | | | | | | | | | | | | |
| 24 | 732 | | | | 732-884 Same. | | | | | | | | | | | |
| 25 | 762 | | | | | | | | | | | | | | | |
| 26 | 792 | | | | | | | | | | | | | | | |
| | 823 | | | | 823 Driller notes augers are binding. Possibly clayey | | | | | | | | | | | |
| 28 | 853 | | | | | | | | | | | | | | | |
| 29 | 884 | | | | 884-1034 Yellowish brown med, coarse & very coarse sandy gravel, minor granules, in frequent pebbles (conglomerate - poorly cemented, coarse sand & pebbles) ~ 1" diam or less, poorly sorted no pebbles well cemented | 10/5 | 20 | 65 | - | 7- | GP | LM | VL | 101R/4 | | |
| 30 | 914 | | | | | | | | | | | | | | | |
| 31 | 945 | | | | | | | | | | | | | | | |
| 32 | 975 | | | | | | | | | | | | | | | |
| 33 | 1006 | | | | 1006-1067 (estimated) large pebbles in cobbles (volcanic and metamorphic) in origin (chert-petrified wood) | | | | | | | | | | | |
| | 1036 | | | | | | | | | | | | | | | |
| 35 | 1067 | | | | 1067-1189 Clayey sand and silt, in balls in cobbles Yellowish brown | - | - | - | 70 | 20/10 | CL-ML | LM | SO | 101R/4 | | |

EBASCO SERVICES INCORPORATED
ENVIRONMENTAL PROGRAM AT ROCKY MOUNTAIN ARSENAL

FIELD LOG OF BORING

| DEPTH | | SAMPLE INTERVAL | DESCRIPTION INTERVAL | RECOVERY (cm/cm) | DESCRIPTION (COLOR, TEXTURE, STRUCTURE) | ESTIMATED PERCENTAGE OF | | | | SILT/CLAY | SOIL CLASSIFICATION USCS | MOISTURE | CONSISTENCY/ DENSITY | COLOR | COMMENTS (SAMPLE NUMBER) |
|-------|------|--------------------|-------------------------|---------------------|--|----------------------------|--------|--------|------|------------------|--------------------------------|----------|-------------------------|-------|-----------------------------|
| ft | cm | | | | | VERY COARSE / GRAVEL | SAND | | | | | | | | |
| | | | | | | | COARSE | MEDIUM | FINE | | | | | | |
| 36 | 1097 | | | | along with pea gravel Note: driller felt every binding ~ 25' but did not feel any gravel or large pebbles. | | | | | | | | | | |
| 37 | 1128 | | | | | | | | | | | | | | |
| 38 | 1158 | | | | | | | | | | | | | | |
| 39 | 1189 | | | | 1189-1341 Yellowish brown clayey silt. Dry to 42 (1280) | - | - | - | - | 60% cl- ml | in | So | 10474 | | |
| | 1219 | | | | | | | | | | | | | | |
| 41 | 1250 | | | | | | | | | | | | | | |
| 42 | 1280 | | | | 42 (1280-1341) Driller notes clay more moist and easier to penetrate. | | | | | | | | | | |
| 43 | 1311 | | | | | | | | | | | | | | |
| 44 | 1341 | | | | 1341-1448 clayey silt soft (driller note) | - | - | - | - | 60% cl- ml | in | So | 10474 | | |
| 45 | 1372 | | | | | | | | | | | | | | |
| 46 | 1402 | | | | | | | | | | | | | | |
| | 1433 | | | | | | | | | | | | | | |
| | 1463 | | | | 1448-1494 clayey silt hard again (driller note) | - | - | - | - | 60% cl- ml | in | So | 10474 | | |
| 48 | 1494 | | | | | | | | | | | | | | |

FIELD LOG OF BORING

| DEPTH | | SAMPLE INTERVAL | DESCRIPTION (COLOR, TEXTURE, STRUCTURE) | ESTIMATED PERCENTAGE OF | | | | | SILT / CLAY | SOIL CLASSIFICATION USCS | MOISTURE | CONSISTENCY/ DENSITY | COLOR | COMMENTS (SAMPLE NUMBER) |
|-------|------|--------------------|--|----------------------------|--------|------|-------|----|-------------|--------------------------------|----------|-------------------------|-------|-----------------------------|
| ft | cm | | | VERY COARSE / GRAVEL | SAND | | | | | | | | | |
| | | | | COARSE | MEDIUM | FINE | | | | | | | | |
| 49 | 1494 | | 1616 nm 1494-1617 Same | | | | | | | | | | | |
| 50 | 1525 | | | | | | | | | | | | | |
| 51 | 1595 | | | | | | | | | | | | | |
| 52 | 1586 | | | | | | | | | | | | | |
| 53 | 1616 | | 1616-1753 Yellowish brn coarse sand w/ minor granules & v. coarse gravel clayey in zones, some medium, poorly sorted | 10 | 60 | 25 | - 7/5 | GP | V | moist | L | 10R 5/4 | | |
| 54 | 1697 | | | | | | | | | | | | | |
| 55 | 1672 | | | | | | | | | | | | | |
| 56 | 1700 | | | | | | | | | | | | | |
| 57 | 1738 | | | | | | | | | | | | | |
| 58 | 1753 | | 1753 Water table. (approximate) | | | | | | | | | | | |
| 59 | 1769 | | 1753-1799 Coarse sandy and granular gravel | | | | | | | | | | | |
| 60 | 1799 | | 1799-1952 Same percentages not recorded due to difficulty discern- ing grain sizes through plastic and water. | | | | | | | | | | | N 8541 |
| 61 | 1830 | | | | | | | | | | | | | |
| 62 | 1860 | | Coarse to v. coarse sandy granular pebble gravel w/ few medium grained clasts | | | | | | | | | | | |
| 63 | 1891 | | | | | | | | | | | | | |

TEBSCO SERVICES INCORPORATED
ENVIRONMENTAL PROGRAM AT ROCKY MOUNTAIN ARSENAL

FIELD LOG OF BORING

| DEPTH | | SAMPLE INTERVAL | DESCRIPTION INTERVAL | RECOVERY (cm/cm) | DESCRIPTION (COLOR, TEXTURE, STRUCTURE) | ESTIMATED PERCENTAGE OF | | | | SILT/CLAY | SOIL CLASSIFICATION USCS | MOISTURE | CONSISTENCY/ DENSITY | COLOR | COMMENTS (SAMPLE NUMBER) |
|-------|------|--------------------|-------------------------|---------------------|---|----------------------------|--------|------|--|-----------|--------------------------------|----------|-------------------------|-------|-----------------------------|
| ft | cm | | | | | VERY COARSE GRAVEL | SAND | | | | | | | | |
| | | | | | | COARSE | MEDIUM | FINE | | | | | | | |
| 62 | 1891 | | | | | | | | | | | | | | |
| 63 | 1921 | | | | | | | | | | | | | | |
| 64 | 1952 | | | | Clay line at top 1952-2104 No recording - Very fine sandy pebble gravel (assumed) | | | | | | | | | | |
| 65 | 1983 | | | | | | | | | | | | | | |
| 66 | 2013 | | | | | | | | | | | | | | |
| 67 | 2043 | | | | | | | | | | | | | | |
| 68 | 2074 | | | | | | | | | | | | | | |
| 69 | 2104 | | | | 2104 - 2257 8 1/5% Same gravel w/ less fines | | | | | | | | | | |
| 70 | 2135 | | | | No percentages recorded | | | | | | | | | | |
| 71 | 2165 | | | | | | | | | | | | | | |
| 72 | 2196 | | | | | | | | | | | | | | |
| 73 | 2226 | | | | | | | | | | | | | | |
| 74 | 2257 | | | | 45% 2257-2287 Same | | | | | | | | | | |
| 75 | 2287 | | | | | | | | | | | | | | |

CHASCO SERVICES INCORPORATED
ENVIRONMENTAL PROGRAM AT ROCKY MOUNTAIN ARSENAL

FIELD LOG OF BORING

| DEPTH | | SAMPLE INTERVAL | DESCRIPTION INTERVAL | RECOVERY (cm/cm) | DESCRIPTION (COLOR, TEXTURE, STRUCTURE) | ESTIMATED PERCENTAGE OF | | | | | SILT/CLAY | SOIL CLASSIFICATION USCS | MOISTURE | CONSISTENCY/ DENSITY | COLOR | COMMENTS (SAMPLE NUMBER) |
|-------|------|--------------------|-------------------------|---------------------|---|----------------------------|--------|--------|--|------|-----------|--------------------------------|----------|-------------------------|-------|-----------------------------|
| ft | cm | | | | | VERY COARSE /GRAVEL | SAND | | | FINE | | | | | | |
| | | | | | | | COARSE | MEDIUM | | | | | | | | |
| -75 | 2287 | | | | 2287-2409 silty fine sand minor med. + clay. if any. | | | | | | | | | | | |
| -76 | 2318 | | | | | | | | | | | | | | | |
| -77 | 2340 | | | | | | | | | | | | | | | |
| -78 | 2371 | | | | | | | | | | | | | | | |
| -79 | 2401 | | | | 90% Layers of gravelly sand and fine fine sand | | | | | | | | | | | |
| -80 | 2440 | | | | | | | | | | | | | | | |
| -81 | 2470 | | | | | | | | | | | | | | | |
| -82 | 2501 | | | | | | | | | | | | | | | |
| -83 | 2531 | | | | | | | | | | | | | | | |
| -84 | 2562 | | | | 90% FAIRLY UNIFORM FINE GRAINED SILTY SAND | | | | | | | | | | | |
| -85 | 2592 | | | | AT ~87' MARK | | | | | | | | | | | |
| -86 | 2623 | | | | ABRUPT CHANGE TO CLAY. | | | | | | | | | | | |
| -87 | 2653 | | | | IN SHOE AT BOTTOM OF CORE SAMPLER | | | | | | | | | | | |
| -88 | 2683 | | | | NOTICED SOME LG. GRAINING SAND BEGINING TO MIX IN W/ CLAY | | | | | | | | | | | |
| -89 | 2713 | | | | | | | | | | | | | | | |

FIELD LOG OF BORING


| | |
|-------------------|------------------|
| SITE TYPE BONE | SITE ID 33080 |
|-------------------|------------------|

SHEET 8 OF 8

| DEPTH ft | cm | SAMPLE INTERVAL | DESCRIPTION INTERVAL | RECOVERY (cm/cm) | DESCRIPTION (COLOR, TEXTURE, STRUCTURE) | ESTIMATED PERCENTAGE OF | | | | | SOIL CLASSIFICATION USCS | MOISTURE | CONSISTENCY/ DENSITY | COLOR | COMMENTS (SAMPLE NUMBER) |
|-------------|------|--------------------|-------------------------|---------------------|---|----------------------------|--------|--------|------|-----------|--------------------------------|----------|-------------------------|-------|-----------------------------|
| | | | | | | VERY COARSE /GRAVEL | SAND | | | SILT/CLAY | | | | | |
| | | | | | | | COARSE | MEDIUM | FINE | | | | | | |
| 89 | 2744 | | | | | | | | | | | | | | |
| 90 | 2745 | | | | | | | | | | | | | | |
| 91 | 2775 | | | | Well set at 87.5' Drilled to 92' | | | | | | | | | | |
| | 2806 | | | | Bottom of hole | | | | | | | | | | |
| 93 | 2836 | | | | | | | | | | | | | | |
| 94 | 2867 | | | | | | | | | | | | | | |
| 95 | 2872 | | | | | | | | | | | | | | |
| 96 | 2928 | | | | | | | | | | | | | | |
| 97 | 2958 | | | | | | | | | | | | | | |
| 98 | 2989 | | | | | | | | | | | | | | |
| | 3049 | | | | | | | | | | | | | | |
| 100 | 3050 | | | | | | | | | | | | | | |
| 101 | 3060 | | | | | | | | | | | | | | |

EBASCO SERVICES INCORPORATED
ENVIRONMENTAL PROGRAM AT ROCKY MOUNTAIN ARSENAL

WELL CONSTRUCTION LOG



Measuring Point is
Ground Surface unless
otherwise noted

Task No.: 48 Geologist: NM
Well Number: 33080 Checked By:

Drilling Summary
Total Depth of Bore: 92 Ft.
Borehole Diameter: 11.25 in from
Drilling Company: Custom Argus
Driller: Frank Parks
Rig: CMF 55
Bits: Hollow Stem Argus

Construction Time Log

| | Start Date | Start Time | Finish Date | Finish Time |
|----------------------|---------------|---------------|----------------|----------------|
| Drilling: | 10/14 | 0829 | 10/21 | 1604 |
| Screen Placement: | 10/22 | 1000 | 10/22 | 1050 |
| Filter Placement: | 10/22 | 1050 | 10/22 | 1309 |
| Seal Placement: | 10/22 | 1500 | 10/22 | 1515 |
| Grouting: | 10/23 | 0900 | 10/23 | 1030 |

Well Construction Material

| | Grout | Seals | Filter |
|-----------|-------------|-------------------------------|----------------------------|
| Quantity: | 3 batches * | 2.25 buckets ** | 14 bags |
| Type: | 1 # | Vulcan pellets (Bentonite) | 10-20 Colo. Silica Sand |

Screen
Size: 0.075 Config:
Area/Ft.: 55
Inside diameter: 4"
Comp: PVC
Outside Diameter: 4.25"
Manufacturer: Ardruck

Joints and Centralizers: * Flush joint threaded

Comments: * 1 batch = 3.3 lb bentonite, 6 bags cement
** 2 buckets = 1/4" dia - Vulcan pellets 0.25 buckets: 1/4" dia
*** Cement-bentonite mixture - Southwestern Portland
Cement and Quick Gel Bentonite

R. L. STOLLAR & ASSOCIATES, INC.
WELL LOG

Project No. UCLA
Well/Boring No. 53085
CombarKey No. _____

| | | | | | | |
|---|--|---------------------------------------|--|------------------|--|--|
| Project Name and Location <u>UCLA - WEST TIER</u> | | Elevation _____ | Coordinates _____ | | Township Range Section <u>33</u> | |
| Drilling Company <u>CUSTOM AUGER</u> | | Driller <u>F. PARKS</u> | Date and Time Started <u>5/15/85</u> <u>0830</u> | | Date and Time Completed <u>5/21/85</u> <u>1700</u> | |
| Drilling Equipment <u>CME-55</u> | | Boring Diameter <u>11" 00</u> | Total Drilled Depth <u>86.5' 00S</u> | | Completion Depth <u>86.6'S</u> | |
| Drilling Method <u>HOLLOW STEM AUGER</u> | | Sampler _____ | No. of Samples _____ | Cal _____ | SS _____ | |
| Size and Type of Casing <u>4" SCH 40 RUSH JOINT</u> | | Water Elevation _____ | First <u>55</u> | Completion _____ | 24 Hrs _____ | |
| Type of Perforation <u>20 SLOT</u> | | From <u>5.1</u> To <u>86</u> (FI-BGS) | Pack Size and Type <u>8 1/2"</u> | | From <u>52</u> To <u>86.4</u> (FI-BGS) | |
| Type of Seal <u>CEMENT GRANKLE</u> | | From <u>47</u> To <u>52</u> (FI-BGS) | Hydrogeologist <u>B. STAMENSON</u> | | Checked By/Date _____ | |

| Depth (feet) | Description | Lithology | Pneumometer Installation | Water Content | Estimate % of | | | Grain Count | Remarks (Drill Rate, Odor, Sample No., etc.) |
|--------------|--|-----------|--------------------------|---------------|---------------|----|----|-------------|--|
| | | | | | GR | SA | FI | | |
| 5 | CLAYEY SILTY SAND YELLOW-BRN.; POORLY SORTED; SUBANGULAR; DRY TO MOIST; W/SOME CALICHE @ 6' 00S; W/SOME GRAVEL LENSES @ 18-20' & + 36-37'; ROOTS NEAR SURFACE | | | | | | | | EASY DRILLING NO OBSCS |
| 10 | | | | | | | | | |
| 15 | | | | | | | | | |
| 20 | | | | | | | | | |
| 25 | | | | | | | | | |
| 30 | | | | | | | | | |
| 35 | | | | | | | | | |

FORM 172

Page 1 of 2

R. L. STOLLAR & ASSOCIATES, INC.
WELL LOG (Continued)

Project No.

Well/Boring No.

33085

| Depth (feet) | Description | USCS Symbol | Lithology | Piezometer Installation | Wire Content | Estimate % of | | | Remarks (Drill Rate, Odr, Sample No., etc.) |
|-----------------|---|----------------|-----------|----------------------------------|-----------------|------------------|----|----|---|
| | | | | | | GR | SA | FI | |
| 37' | CLAY ; BROWN ; VERY PLASTIC ; MOIST | CL | | CEMENT BLACK PVC CEMENT | | | 5 | 95 | TIGHT FRAMEWORK |
| 40 | | | | CEMENT 2" BLACK PVC CEMENT | | | | | |
| 45 | | | | BENTONITE BENTONITE | | | | | |
| 50 | | | | | | | | | |
| 55 | GRAVELLY COARSE SAND - WET; SUBANGULAR; POOR SORT LT. TAN BROWN; SOME SILT W/SOME FINE SANDS & COBBLES | SP | | | | 15 | 80 | 5 | 42/5 BENTON W/ PISTON SAMPLE |
| 60 | | | | | | | | | |
| 65 | | | | SAND SAND | | | | | 13/5 |
| 70 | | | | | | | | | |
| 75 | | | | | | | | | FIXED FOR 15' SAMPLE |

ROPW172

Page 2 of 3

R. L. STOLLAR & ASSOCIATES, INC.
WELL LOG (Continued)

Project No. 33085
Well/Boring No. 33085

| Depth (feet) | Description | Lithology | Piezometer Installation | Water Content | Estimate % of | | | Remarks (Drift Rate, Color, Sample No., etc.) |
|-----------------|------------------------------|-----------|----------------------------|------------------|------------------|----|----|---|
| | | | | | GR | SA | FI | |
| 80 | | | | | | | | |
| 85 | CLAY - BROWN; WET PLASTIC | CL | | | | | | TD = 86.5' GrS |
| 90 | | | | | | | | |

FORM 173

Page 3 of 3

R. L. STOLLAR & ASSOCIATES, INC.
WELL LOG

Project No. UCLA
Well/Boring No. 53086
Combor/Key No. _____

| | | | | | | | |
|--|--|-------------------------------------|--|-------------------------------------|--|------------------------------|---|
| Project Name and Location <u>UCLA - WEST TREE</u> | | Elevation | Coordinates | | Township Range Section <u>33</u> | | |
| Drilling Company <u>CUSTOM AUGER</u> | | Driller <u>F. PARKS</u> | Date and Time Started <u>5/26/88 1500</u> | | Date and Time Completed <u>5/27/88 1430</u> | | |
| Drilling Equipment <u>CME-55</u> | | Total Drift Depth <u>90' BGS</u> | | Completion Depth <u>86' BGS</u> | | | |
| Drilling Method <u>HOLLOW STEM AUGER</u> | | Boring Diameter <u>11" OD</u> | Sampler | No of Samples | Cal <u>SS</u> | | |
| Size and Type of Casing <u>2" SCH 40 RUSH JOINT</u> | | Water Elevation | First <u>55'</u> | Completion <u>24 Hrs</u> | | | |
| Type of Penetration | From <u>56</u> To <u>86</u> (F-BGS) | Pack Size and Type <u>8/12</u> | | From <u>54</u> To <u>85</u> (F-BGS) | | | |
| Type of Seal | From <u>49</u> To <u>54</u> (F-BGS) | Hydrogeologist <u>B. STOLLAR</u> | | Checked By/Date | | | |
| Depth (feet) | Description | Log Symbol | Lithology | Piezometer Installation | Water Content | Estimate % of GR SA FI | Remarks (Drill Rate, Odor, Sample No., etc.) |
| 5 | <u>CLAYEY SILTY SAND</u> <u>YELLOW-BAN.; POORLY SORTED;</u> <u>SUBANGULAR; DRY TO MOIST;</u> <u>W/SOME CALICHE @ 6' BGS;</u> <u>W/SOME GRAVEL LENSES @ 18-20' &</u> <u>36-37'; ROOTS NEAR SURFACE</u> | SM | | | | 5 80 15 | <u>EMPTY</u> <u>DRILLING</u> <u>NO OODORS</u> |
| 10 | | | | | | | |
| 15 | | | | | | | |
| 20 | | | | | | | |
| 25 | | | | | | | |
| 30 | | | | | | | |
| 35 | | | | | | | |

FORM 172

Page 1 of 3

Project No. _____
Well/Boring No. 33086

| Depth (feet) | Description | UNOS Symbol | Lithology | Pneumometer Installation | Water Content | Estimate % of | | | Blow Count | Remarks (Drift Rate, Color, Sample No., etc.) |
|-----------------|---|----------------|-----------|-----------------------------|------------------|---------------|----|------|---------------|---|
| | | | | | | GR | SA | F.I. | | |
| 37' | CLAY ; BROWN ; VERY PLASTIC ; MOIST | | CL | | | | 5 | 95 | | TIGHT FRANKLIN |
| 40 | | | | CEMENT | | | | | | |
| 45 | | | | " " | | | | | | |
| 50 | | | | BENTONITE | | | | | | |
| 55 | GRAVELLY COARSE SAND - WET; SUBANGULAR; POOR SORT LT. TAN BROWN; SOME SLT w/SOME FINE SANDS & COBBLES | SP | | SAND | .11 | 15 | 80 | 5 | 42/15 | BEGIN w/Piston Sample |
| 60 | | | | SAND | | | | | 13/5 | |
| 65 | | | | | | | | | | |
| 70 | | | | | | | | | | |
| 75 | | | | | | | | | 233/5 | FISHED FOR SAMPLE |

FORM 75

Page 2 of 3

R. L. STOLLAR & ASSOCIATES, INC.
WELL LOG (Continued)

Project No. _____

Well/Boring No.

33086

| Well/Boring No. 33086 | | USCS Symbol | Lithology | Piezometer Installation | Flow Control | Estimate % of | | | Blow Count | Remarks (Drill Rate, Color, Sample No., etc.) |
|-----------------------|---------------------------|-------------|-----------|-------------------------|--------------|---------------|----|----|------------|---|
| Depth (feet) | Description | | | | | GR | SA | FI | | |
| 80 | | | | SAND | | | | | | |
| 85 | | | | SAND | | | | | | |
| 90 | CLAY - BROWN; WET PLASTIC | CL | | GRAVELITE | | | | | | TD = 90' BGS |

Page 3 of 3

R. L. STOLLAR & ASSOCIATES, INC.
WELL LOG

Project No. UCLA
Well/Boring No. 53087
ComborKey No. _____

| | | | | | | |
|--|--|---|--|---------------------------------|--|----|
| Project Name and Location <u>UCLA - WEST TREE</u> | | Elevation | Coordinates | | Township Range Section <u>33</u> | |
| Drilling Company <u>CUSTOM AUGER</u> | | Driller <u>F. PARKS</u> | Date and Time Started <u>8/31/88 0700</u> | | Date and Time Completed <u>8/31/88 1500</u> | |
| Drilling Equipment <u>CME-55</u> | | Total Drilled Depth <u>5765</u> | | Completion Depth <u>8665</u> | | |
| Drilling Method <u>HOLLOW STEM AUGER</u> | | Boring Diameter <u>00</u> | Sampler | No of Samples | Cal | SS |
| Size and Type of Casing <u>SCM 40 RUSH JOINT</u> | | Water Elevation | First | Completion | 24 Hrs | |
| Type of Perforation <u>20 SLOT</u> | From <u>65.5</u> To <u>66</u> (Ft-BGS) | Pack Size and Type <u>NATIVE</u> | From | To | (Ft-BGS) | |
| Type of Seal <u>CENTONITE GRANKLES</u> | From <u>49</u> To <u>59</u> (Ft-BGS) | Hydrogeologist <u>B. S. FRANKENSON</u> | Checked By/Date | | | |

| Depth (feet) | Description | Rock Sample | Lithology | Piezometer Installation | Water Content | Estimate % of | | | Grain Count | Remarks (Drill Rate, Odor, Sample No., etc.) |
|--------------|---|-------------|-----------|-------------------------|---------------|---------------|----|----|-------------|--|
| | | | | | | GR | SA | FI | | |
| 5 | CLAYEY SILTY SAND YELLOW-BRN.; POORLY SORTED, SUBANGULAR; DRY TO MOIST; W/SOME CALICHE @ 6'00"; W/SOME GRAVEL LENSES @ 18-20' & 36-37'; ROOTS NEAR SURFACE | SM | | | | 5 | 80 | 15 | | EASY DRILLING NO ODDS |
| 10 | | | | | | | | | | |
| 15 | | | | | | | | | | |
| 20 | | | | | | | | | | |
| 25 | | | | | | | | | | |
| 30 | | | | | | | | | | |
| 35 | | | | | | | | | | |

FORM 12

Page 1 of 2

R. L. STOLLAR & ASSOCIATES, INC.
WELL LOG (Continued)

Project No.

Well/Boring No.

33087

| Depth (feet) | Description | USCS Symbol | Lithology | Piezometer Installation | Well Cement | Estimate % of | | | Remarks (Drill Rate, Odor, Sample No., etc.) |
|-----------------|--|----------------|-----------|----------------------------|----------------|------------------|----|----|--|
| | | | | | | GR | SA | FI | |
| 37' | CLAY ; BROWN ; VERY PLASTIC ; MOIST | CL | | | | | 5 | 95 | TIGHT FRANK |
| 40 | | | | | | | | | |
| 45 | | | | | | | | | |
| 50 | | | | | | | | | |
| 55 | GRAVELLY COARSE SAND - WET; SUBANGULAR; POOR SORT LT. TAN BROWN; SOME SLT W/SOME FINE SANDS & COBBLES | SP | | | | 15 | 80 | 5 | |
| 60 | | | | | | | | | |
| 65 | | | | | | | | | |
| 70 | | | | | | | | | |
| 75 | | | | | | | | | |

FORM 72

Page 2 of 2

APPENDIX D. SOLUTE CONCENTRATIONS IN WATER SAMPLES

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
INJECTION WELL

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| I1 | 0.12 | 59.50 | 0.44 | 1.5 |
| I2 | 0.95 | 62.10 | | |
| I3 | 1.40 | 49.76 | | |
| I4 | 1.70 | 53.50 | | |
| I5 | 2.65 | 60.60 | | |
| I6 | 2.75 | | | |
| I7 | 3.47 | 60.50 | | |
| I8 | 5.20 | 57.90 | | |
| I9 | 6.35 | 59.40 | | |
| I10 | 7.22 | 61.12 | | |
| I11 | 7.77 | 54.30 | | |
| I12 | 9.00 | 15.60 | | |
| I13 | 10.00 | 56.10 | | |
| I14 | 10.35 | 57.70 | | |
| I15 | 11.33 | 55.20 | | |
| I16 | 13.17 | 65.00 | | |
| I17 | 14.77 | 62.40 | | |
| I18 | 16.90 | 59.80 | | |
| I19 | 18.4 | | | |
| I20 | 19.40 | 70.50 | | |
| I21 | 20.50 | 61.20 | 0.32 | 1.42 |
| I22 | 21.66 | | | |
| I23 | 22.2 | | | |
| I24 | 23.00 | 67.40 | | |
| I25 | 23.30 | | | |
| I26 | 24.30 | 80.60 | | |
| I27 | 25.50 | 90.00 | | |
| I28 | 26.50 | 70.40 | | |
| I29 | 27.20 | 69.02 | | |
| I30 | 27.60 | 0.85 | | |
| I31 | 28.40 | 1.08 | | |
| I32 | 29.35 | | | |
| I34 | 31.80 | 2.53 | | |
| I35 | 33.80 | 2.78 | | |
| I36 | 35.90 | | | |
| I37 | 37.00 | | | |
| I38 | 38.40 | 4.74 | | |
| I39 | 39.50 | | 0.15 | 1.17 |
| I40 | 40.50 | | | |
| I41 | 41.60 | | | |
| I42 | 42.70 | 6.44 | | |
| I43 | 43.8 | | | |
| I44 | 44.8 | | | |
| I45 | 45.80 | 7.41 | | |
| I46 | 46.8 | | | |
| I47 | 47.80 | 8.90 | | |
| I48 | 48.9 | | | |
| I49 | 49.90 | 10.00 | | |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
INJECTION WELL

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| I50 | 50.90 | 10.50 | | |
| I51 | 51.90 | 9.90 | | |
| I52 | 53.10 | 10.40 | 0.6 | 1.01 |
| I53 | 53.90 | 11.19 | | |
| I54 | 54.90 | 11.50 | | |
| I55 | 55.90 | 11.70 | | |
| I56 | 56.83 | | | |
| I57 | 58.00 | 10.90 | | |
| I58 | 59 | | | |
| I59 | 60.00 | 10.60 | | |
| I60 | 61.3 | | | |
| I61 | 62.30 | 10.20 | | |
| I62 | 63.50 | 10.20 | | |
| I63 | 64.56 | | | |
| I64 | 65.60 | 9.20 | | |
| I65 | 66.53 | | | |
| I66 | 67.40 | 8.86 | | |
| I67 | 68.33 | | | |
| I68 | 69.30 | 8.38 | | |
| I69 | 70.35 | | | |
| I70 | 71.40 | 7.50 | | |
| I71 | 72.38 | | | |
| I72 | 73.30 | 7.00 | | |
| I73 | 74.33 | | | |
| I74 | 75.50 | 6.70 | | |
| I75 | 76.58 | | | |
| I76 | 77.60 | 5.30 | | |
| I77 | 78.6 | | | |
| I78 | 79.60 | 5.85 | | |
| I79 | 80.71 | | 0 | 0.86 |
| I80 | 82.10 | 4.62 | | |
| I81 | 84.16 | | | |
| I82 | 86.35 | | | |
| I83 | 88.40 | 3.65 | | |
| I84 | 90.41 | | | |
| I85 | 92.30 | 3.61 | | |
| I86 | 94.38 | | | |
| I87 | 96.30 | 3.30 | | |
| I88 | 98.35 | | | |
| I89 | 100.30 | 3.30 | 0 | 0.79 |
| I90 | 104.43 | | | |
| I91 | 108.60 | 2.46 | | |
| I92 | 112.5 | | | |
| I93 | 116.50 | 1.95 | | |
| I94 | 120.33 | | 0 | 0.82 |
| I95 | 124.30 | 1.70 | | |
| I96 | 129.00 | 1.40 | | |
| I97 | 133 | | | |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
INJECTION WELL

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| I98 | 137.10 | 1.30 | | |
| I99 | 141.13 | | 0 | 0.77 |
| I100 | 145.10 | 1.10 | | |
| I101 | 149.13 | | | |
| I102 | 153.10 | 0.94 | | |
| I103 | 157.10 | 0.90 | | |
| I104 | 161.20 | 0.80 | 0 | 0.75 |
| I105 | 165.75 | | | |
| I106 | 171.40 | 0.70 | | |
| I107 | 175.43 | | | |
| I108 | 179.58 | | | |
| I109 | 183.4 | | | |
| I110 | 187.58 | 0.71 | | |
| I111 | 191.88 | | | |
| I112 | 195.5 | | | |
| I113 | 199.71 | | | |
| I114 | 204.35 | | 0 | 0.7 |
| I115 | 208.25 | | | |
| I116 | 212.36 | | | |
| I117 | 216.61 | 0.46 | | |
| I118 | 220.58 | | | |
| I119 | 224.2 | | 0 | 0.69 |
| I120 | 230.13 | | | |
| I121 | 236.35 | 0.38 | | |
| I122 | 242.38 | 0.34 | | |
| I123 | 254.40 | 0.30 | | |
| I124 | 266.3 | | 0 | 0.79 |
| I125 | 278.45 | | | |
| I126 | 290.26 | | | |
| I127 | 302.2 | | 0 | 0.58 |
| I128 | 315.85 | | | |
| I129 | 332.63 | | | |
| I130 | 357.66 | | 0.07 | 0.92 |
| I131 | 405.83 | | 0 | 0.53 |
| I132 | 431.83 | | 0.25 | 1.14 |
| I133 | 477.55 | | | |
| I134 | 501.96 | | | |
| I135 | 535.26 | | | |
| I136 | 630.18 | | 0 | 0.47 |
| I137-A | 652.65 | | 1 | 1 |
| I137 | 652.65 | | 0.01 | 0 |
| I138 | 701.45 | | | |
| I139 | 769.05 | | 0 | 0.45 |
| I140 | 821.50 | | | |
| I141 | 864.90 | | | |
| I142 | 944.70 | | 0 | 0.47 |
| I143 | 991.70 | | | |
| I144 | 1033.40 | | | |
| I145 | 1104.00 | | 0 | 0.41 |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
DRIVE POINT A

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| A1 | 1.37 | | 37.306 | 44.513 |
| A2 | 3.90 | 0.01 | | |
| A3 | 7.40 | 0.01 | 34.134 | 40.79 |
| A4 | 8.57 | | | |
| A5 | 10.60 | 0.54 | | |
| A5 | 10.6 | | 35.494 | 42.5 |
| A6 | 12.55 | | 32.801 | 40.886 |
| A7 | 14.90 | 7.37 | | |
| A8 | 17.1 | 11.83 | 28.557 | 36.03 |
| A9 | 18.30 | 13.9 | | |
| A10 | 19.50 | 21.4 | | |
| A11 | 20.60 | 19.6 | 24.727 | 33.009 |
| A12 | 21.75 | 21.8 | | |
| A13 | 23.20 | 25.67 | | |
| A14 | 24.4 | 27.4 | 17.879 | 25.194 |
| A15 | 25.50 | 32.26 | | |
| A16 | 26.50 | 38 | | |
| A17 | 28.30 | 36.96 | 13.585 | 18.89 |
| A18 | 29.50 | 39.9 | 11.768 | 16.791 |
| A19 | 31.80 | 44.6 | | |
| A20 | 33.90 | 46.6 | 6.494 | 9.799 |
| A22 | 37.1 | | 6.614 | 10.044 |
| A23 | 38.40 | 49.8 | | |
| A24 | 39.60 | | 5.324 | 7.993 |
| A25 | 40.80 | | | |
| A26 | 42.10 | 51.7 | | |
| A27 | 42.90 | 45.8 | | |
| A28 | 44.2 | 50.5 | 3.835 | 5.4 |
| A29 | 45.20 | | | |
| A30 | 46.2 | 46.8 | 3.261 | 4.597 |
| A31 | 47.20 | 47.3 | | |
| A32 | 48.3 | 44.6 | 3.324 | 4.771 |
| A33 | 49.30 | 45.3 | | |
| A34 | 50.30 | 42.5 | 2.487 | 3.867 |
| A35 | 51.40 | 40.7 | | |
| A36 | 52.50 | 36.6 | 2.776 | 4.224 |
| A37 | 53.50 | | | |
| A38 | 54.60 | 36.93 | 2.51 | 4.093 |
| A39 | 55.40 | 34.34 | | |
| A40 | 56.80 | 26.4 | 2.465 | 3.995 |
| A41 | 57.60 | 23.6 | | |
| A42 | 58.60 | 24.2 | | |
| A43 | 59.70 | 21.15 | | |
| A44 | 60.93 | | 1.814 | 3.022 |
| A45 | 61.80 | 16.6 | | |
| A46 | 62.80 | 15.6 | 1.806 | 2.988 |
| A47 | 63.90 | 14.2 | | |
| A48 | 64.80 | 12.9 | 1.799 | 2.918 |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
DRIVE POINT A

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| A49 | 65.70 | 10.9 | | |
| A50 | 66.80 | 11.7 | | |
| A51 | 67.64 | 11.2 | 1.463 | 2.54 |
| A52 | 68.70 | 11 | | |
| A53 | 69.70 | 10.9 | | |
| A54 | 70.90 | 10.9 | 1.789 | 3.1 |
| A55 | 71.90 | 9.1 | | |
| A56 | 72.90 | 10.5 | 1.416 | 2.559 |
| A57 | 73.90 | 10.3 | | |
| A58 | 75.10 | 10.2 | | |
| A59 | 76.50 | 9.1 | | |
| A60 | 77.30 | 9.1 | 2.361 | 3.888 |
| A61 | 78.50 | 10.6 | | |
| A62 | 79.40 | 10.3 | 2.323 | 3.799 |
| A63 | 80.40 | 10.6 | | |
| A64 | 82.33 | | 2.761 | 4.548 |
| A65 | 84.60 | 9 | | |
| A66 | 86.38 | | 2.123 | 3.661 |
| A67 | 88.30 | 9.1 | | |
| A68 | 90.38 | | 2.141 | 3.61 |
| A69 | 92.40 | 9.1 | | |
| A70 | 94.48 | | | |
| A71 | 96.50 | 8.28 | 2.151 | 3.609 |
| A72 | 98.53 | | | |
| A73 | 100.60 | 7.7 | 2.136 | 3.517 |
| A74 | 104.80 | 6.8 | | |
| A75 | 108.50 | 5.5 | 1.757 | 3.044 |
| A76 | 112.70 | 4.7 | | |
| A77 | 116.90 | 3.99 | 2.402 | 3.648 |
| A78 | 120.30 | 3.83 | | |
| A79 | 124.30 | 3.4 | 2.503 | 3.771 |
| A80 | 129.10 | 2.8 | | |
| A81 | 133.00 | 2.3 | 2.763 | 4.045 |
| A82 | 137.20 | 2.3 | | |
| A83 | 140.90 | 2.1 | 2.652 | 3.86 |
| A84 | 144.60 | 2.1 | | |
| A85 | 148.70 | 1.8 | 2.76 | 4.173 |
| A86 | 152.70 | 1.6 | | |
| A87 | 156.70 | 1.7 | 2.934 | 4.55 |
| A88 | 160.70 | 1.6 | | |
| A89 | 165.81 | | 3.332 | 5.007 |
| A90 | 171.50 | 1.2 | | |
| A91 | 175.55 | | 3.483 | 5.236 |
| A92-A | 179.80 | 1.1 | 2.7 | 3.8 |
| A93 | 183.65 | | 3.715 | 5.487 |
| A94-A | 187.40 | 0.95 | 2.7 | 3.9 |
| A95 | 191.36 | | | |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
 DRIVE POINT A

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| A96 | 195.13 | | 3.508 | 5.238 |
| A97 | 199.36 | 0.77 | | |
| A98 | 204.41 | | | |
| A99 | 208.45 | 0.67 | 5.2 | 8.2 |
| A100 | 212.55 | | | |
| A101 | 216.71 | 0.62 | 3.933 | 6.137 |
| A102 | 220.56 | | | |
| A103 | 224.23 | 0.6 | 3.947 | 6.059 |
| A104 | 230.31 | | | |
| A105 | 236.58 | 0.49 | | |
| A106 | 242.53 | 0.41 | 4.263 | 6.512 |
| A107 | 254.56 | 0.36 | 4.286 | 6.708 |
| A108 | 266.46 | | | |
| A109 | 278.63 | | 4.5 | 8.2 |
| A110 | 290.35 | 0.1 | | |
| A111 | 302.28 | | 10.336 | 14.636 |
| A112 | 315.96 | | | |
| A113 | 326.25 | | 4.865 | 7.306 |
| A114 | 342.33 | 0.07 | 4.41 | 7.12 |
| A115 | 357.81 | | | |
| A116 | 388.33 | | 9.1 | 13.7 |
| A117 | 406.00 | | | |
| A118 | 429.91 | | 12.078 | 17.93 |
| A119 | 477.53 | | | |
| A120 | 502.05 | | 12.953 | 18.385 |
| A121 | 535.30 | | 36.758 | 44.381 |
| A122 | 607.91 | | 38.102 | 48.688 |
| A123 | 630.16 | | 17.6 | 37.8 |
| A124-A | 652.41 | | 25.998 | 35.527 |
| A124 | 652.41 | | | |
| A125 | 944.75 | | | |
| A126 | 769.05 | | | |
| A127 | 821.50 | | | |
| A128 | 864.90 | | | |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
DRIVE POINT B

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| B1 | 1.63 | | 44.21 | 50.46 |
| B2 | 4.00 | 0.01 | | |
| B3 | 6.5 | | 42.41 | 47.23 |
| B4 | 8.68 | | | |
| B5 | 10.80 | 0.01 | | |
| B6 | 13.4 | | 37.77 | 42.7 |
| B7 | 15.40 | 0.01 | | |
| B8 | 18.40 | 0.02 | 49.35 | 56.00 |
| B9 | 21.91 | | | |
| B10 | 24.00 | 0.02 | | |
| B11 | 26.06 | | | |
| B12 | 29 | | 39.96 | 44.82 |
| B13 | 31.90 | 0.15 | | |
| B14 | 34.05 | 0.2 | | |
| B15 | 37.31 | | | |
| B16 | 38.55 | | 42.09 | 47.55 |
| B17 | 40.93 | | | |
| B18 | 42.83 | | 39.86 | 46.41 |
| B19 | 44.80 | 0.3 | | |
| B20 | 46.86 | | | |
| B21 | 49 | | 38.81 | 45.77 |
| B22 | 51.03 | | | |
| B23 | 53.30 | 0.3 | | |
| B24 | 54.83 | | | |
| B25 | 57.03 | | 41.83 | 48.11 |
| B26 | 58.95 | | | |
| B27 | 61.05 | | | |
| B28 | 63.30 | 0.2 | 40.57 | 46.43 |
| B29 | 65.35 | | | |
| B30 | 67.30 | 0.13 | | |
| B31 | 69.30 | 0.14 | 36.98 | 43.28 |
| B32 | 71.35 | | | |
| B33 | 73.41 | | | |
| B34 | 75.66 | | 36.9 | 43.96 |
| B35 | 77.50 | 0.1 | | |
| B36 | 79.98 | | | |
| B37 | 83.70 | 0.1 | | |
| B38 | 87.35 | | 37.79 | 42.97 |
| B39 | 91.35 | | | |
| B40 | 95.40 | 0.06 | 37.49 | 43.94 |
| B41 | 99.56 | | | |
| B42 | 103.70 | 0.04 | | |
| B43 | 107.56 | | 40.52 | 47.82 |
| B44 | 111.43 | | | |
| B45 | 115.41 | | | |
| B46 | 118.40 | 0.02 | | |
| B47 | 120.50 | 0.03 | 29.51 | 18.86 |
| B48 | 124.83 | | | |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
 DRIVE POINT B

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| B49 | 129.20 | 0.02 | | |
| B50 | 133.18 | | | |
| B51 | 137.30 | 0.02 | | |
| B52 | 141.08 | | 39.73 | 45.62 |
| B53 | 144.80 | 0.02 | | |
| B54 | 148.81 | | | |
| B55 | 152.90 | 0.02 | | |
| B56 | 156.80 | 0.02 | | |
| B57 | 160.90 | 0.01 | 40.63 | 46.46 |
| B58 | 165.93 | | | |
| B59 | 171.60 | 0.01 | | |
| B60 | 175.65 | | | |
| B61-A | 179.90 | 0.01 | 28.20 | 32.20 |
| B62 | 183.8 | | 41.1 | 48.89 |
| B63-A | 187.60 | 0.01 | 30.10 | 34.80 |
| B64 | 191.51 | | | |
| B65 | 195.23 | | | |
| B66 | 199.48 | | | |
| B67 | 204.53 | | 39.12 | 45.8 |
| B68 | 208.58 | | | |
| B69 | 212.66 | | | |
| B70 | 216.83 | 0.01 | | |
| B71 | 220.7 | | 40.7 | 47.75 |
| B72 | 222.36 | 0.01 | | |
| B73 | 230.41 | | | |
| B74 | 236.68 | 0.01 | | |
| B75 | 242.63 | 0.01 | 41.07 | 47.46 |
| B76 | 248.20 | 0.01 | | |
| B77 | 254.70 | 0 | | |
| B78 | 260.98 | 0.02 | | |
| B79 | 266.55 | | | |
| B80 | 272.36 | 0.01 | | |
| B81 | 278.75 | | 39.59 | 47.41 |
| B82 | 284.53 | 0.01 | | |
| B83 | 290.48 | 0.01 | | |
| B84 | 296.7 | | | |
| B85 | 302.4 | | 40.54 | 48.01 |
| B86 | 308.3 | | 41.45 | 48.2 |
| B87-A | 316.08 | 0.01 | 21.40 | 42.20 |
| B87 | 316.08 | | 40.17 | 47.96 |
| B88 | 320.68 | | 41.38 | 49.91 |
| B89 | 326.36 | 0.01 | 41.75 | 49.26 |
| B90-A | 332.5 | | 22.7 | 48.8 |
| B91 | 342.46 | | 41.12 | 47.4 |
| B92 | 357.93 | | 41 | 48.79 |
| B93 | 388.33 | | 42.69 | 50.64 |
| B94 | 406.33 | | 40.54 | 48.27 |
| B95 | 432.16 | | 43.22 | 52.03 |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
DRIVE POINT B

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| B96 | 477.65 | | | |
| B97 | 502.16 | | | |
| B98 | 535.53 | | 38.775 | 48.572 |
| B99 | 607.96 | | 41.18 | 46.85 |
| B100 | 630.28 | | 40.952 | 50.102 |
| B101-A | 652.55 | | 22.40 | 47.20 |
| B102 | 701.45 | | 40.16 | 47.78 |
| B103 | 769.10 | | 39.25 | 46.69 |
| B104 | 797.45 | | 39.56 | 47.12 |
| B105 | 821.47 | | | |
| B106 | 864.90 | | 38.78 | 46.57 |
| B107 | 945.00 | | 38.97 | 46.10 |
| B108 | 991.70 | | 39.06 | 46.48 |
| B109 | 1033.40 | | 41.00 | 49.88 |
| B110 | 1104.8 | | 39.68 | 49.35 |
| B111 | 1179.2 | | 40.54 | 49.32 |
| B112 | 1213 | | 35.82 | 43.71 |
| B113 | 1216.77 | | 36.85 | 50.03 |
| B114 | 1222.3 | | 40.94 | 49.06 |
| B115 | 1225.5 | | 42.11 | 51.23 |
| B116 | 1228.2 | | 44.18 | 53.15 |
| B117 | 1231.4 | | 40.37 | 49.57 |
| B118 | 1234.7 | | 37.06 | 45.83 |
| B119 | 1236 | | 36.52 | 44.36 |
| B120 | 1237 | | 33.46 | 40.48 |
| B121 | 1238.1 | | 31.64 | 38.81 |
| B122 | 1239.5 | | | |
| B123 | 1240.9 | | 34.57 | 41.51 |
| B124 | 1242.8 | | | |
| B125 | 1244.7 | | 33.67 | 39.74 |
| B125 | 1244.7 | | | |
| B126 | 1247.3 | | 31.97 | 37.9 |
| B127 | 1249.5 | | 32.76 | 40.16 |
| B128 | 1251.5 | | 33.82 | 40.72 |
| B129 | 1254.1 | | 34.96 | 43.37 |
| B130 | 1257.3 | | 33.26 | 44.78 |
| B131 | 1260.8 | | 32.91 | 39.77 |
| B132 | 1263.9 | | 32.75 | 39.56 |
| B133 | 1266.43 | | 31.5 | 37.46 |
| B134 | 1270.95 | | | |
| B135 | 1274.1 | | | |
| B136 | 1276 | | 33.19 | 39.78 |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
DRIVE POINT C

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| C1 | 2.1 | | 30.74 | 25.99 |
| C2 | 4.15 | 0.02 | | |
| C3 | 6.63 | | 33.08 | 27.85 |
| C4 | 8.8 | | | |
| C5 | 10.90 | 0.01 | | |
| C6 | 13.5 | | 31.33 | 26.59 |
| C7 | 15.50 | 0.04 | | |
| C8 | 18.50 | 0.01 | 32.18 | 27.22 |
| C9 | 22.08 | | | |
| C10 | 24.20 | 0.01 | 34.69 | 29.59 |
| C11 | 26.2 | | | |
| C12 | 29.76 | | | |
| C13 | 32.00 | 0.01 | 34.46 | 29.36 |
| C14 | 37.33 | | 30.62 | 27.32 |
| C15 | 39.78 | | | |
| C16 | 42.25 | | 32.73 | 28.76 |
| C17 | 44.60 | 0.01 | | |
| C18 | 46.58 | | | |
| C19 | 48.58 | | 33.82 | 29.51 |
| C20 | 50.63 | | | |
| C21 | 53.03 | | 32.81 | 29.31 |
| C22 | 54.46 | | | |
| C23 | 56.60 | 0.03 | 34.26 | 30.07 |
| C24 | 58.73 | | | |
| C25 | 61.16 | | 35.95 | 32.39 |
| C26 | 63.4 | | | |
| C27 | 65.5 | | 32.42 | 29.08 |
| C28 | 67.40 | 0.02 | | |
| C29 | 69.50 | 0.02 | 33.58 | 30.38 |
| C30 | 71.51 | | | |
| C31 | 73.56 | | 31.39 | 28.89 |
| C32 | 75.86 | | | |
| C33 | 77.80 | 0.02 | 34.19 | 31.44 |
| C34 | 79.8 | | | |
| C35 | 83.53 | | 33.41 | 31.1 |
| C36 | 87.20 | 0.01 | | |
| C37 | 91.2 | | 33.56 | 32.06 |
| C38 | 95.30 | 0.04 | | |
| C39 | 99.48 | | 33.34 | 31.96 |
| C40 | 103.60 | 0.08 | | |
| C41 | 107.45 | | 33.88 | 33.26 |
| C42 | 111.55 | | | |
| C43 | 115.50 | 0.24 | 34.92 | 34.21 |
| C44 | 118.5 | | | |
| C45 | 120.80 | 0.62 | 34.07 | 33.48 |
| C46 | 125.00 | 1.22 | | |
| C47 | 129.30 | 1.64 | 32.81 | 31.74 |
| C48 | 133.30 | 2 | | |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
 DRIVE POINT C

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| C49 | 137.40 | 2.3 | 30.80 | 30.33 |
| C50 | 141.20 | 2.7 | | |
| C51 | 144.90 | 3.2 | 29.39 | 28.66 |
| C52 | 148.90 | 3.96 | | |
| C53 | 153.00 | 4.8 | 25.06 | 24.65 |
| C54 | 156.90 | 4.9 | | |
| C55 | 161.00 | 5.3 | 21.40 | 20.8 |
| C56 | 166.00 | 5.24 | | |
| C57 | 170.00 | 5.6 | | |
| C58 | 171.80 | 5.8 | | |
| C59-A | 175.70 | | 12.20 | 11.1 |
| C60 | 180.10 | 5.7 | 13.68 | 13.57 |
| C61 | 183.91 | | | |
| C62-A | 187.80 | 5.38 | 9.40 | 8.4 |
| C62 | 187.8 | | 10.62 | 10.42 |
| C63 | 191.7 | | | |
| C64 | 195.30 | 4.3 | 7.73 | 7.89 |
| C65 | 199.55 | 4.51 | | |
| C66 | 204.63 | | 7.45 | 7.64 |
| C67 | 208.60 | 3.89 | | |
| C68 | 212.75 | | 6.43 | 6.64 |
| C69 | 216.80 | 3.3 | | |
| C70 | 220.8 | | 5.36 | 5.64 |
| C71 | 224.46 | 2.88 | | |
| C72 | 230.55 | | 4.76 | 4.96 |
| C73 | 236.80 | 2.38 | | |
| C74 | 242.80 | 1.96 | 3.96 | 4.25 |
| C75 | 248.30 | 1.82 | | |
| C76 | 254.80 | 1.66 | 3.34 | 3.61 |
| C77 | 261.10 | 1.62 | | |
| C78 | 266.68 | 1.57 | 2.75 | 3.08 |
| C79 | 272.46 | | | |
| C80 | 278.88 | | 2.44 | 2.71 |
| C81 | 284.63 | 1.21 | | |
| C82 | 290.58 | | 2.01 | 2.43 |
| C83 | 296.85 | | | |
| C84 | 302.51 | | 2.1 | 2.49 |
| C85 | 308.43 | | | |
| C86-A | 316.21 | | 2.00 | 2.5 |
| C86 | 316.21 | | 3.23 | 3.56 |
| C87 | 320.8 | | | |
| C88 | 326.50 | 1.28 | | |
| C89-A | 332.58 | | 1.30 | 2.3 |
| C90 | 342.56 | 0.47 | 1.81 | 2.19 |
| C91 | 358.01 | | | |
| C92 | 388.33 | 0.19 | | |
| C93 | 406.33 | | 1.07 | 1.39 |
| C94 | 432.25 | 0.12 | | |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
 DRIVE POINT C

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|------------|--------------|-----------------|--------------|--------------|
| C95 | 477.73 | | | |
| C96 | 502.26 | 0.16 | 1.36 | 1.62 |
| C97 | 535.65 | | 1.82 | 2.04 |
| C98 | 608.06 | 0.09 | 1.091 | 1.181 |
| C99 | 630.4 | | 1.125 | 1.206 |
| C99 | 630.4 | | 0.89 | 1.36 |
| C100-A | 652.66 | | 1.00 | 1 |
| C99 (MISL) | 652.66 | | 0.98 | 1.103 |
| C100 | 701.45 | 0.07 | | |
| C101 | 769.05 | | | |
| C102 | 821.50 | 0 | | |
| C103 | 864.90 | 0 | | |
| C104 | 945.10 | | | |
| C105 | 991.9 | | | |
| C106 | 1033.4 | 0 | | |
| C107 | 1104.96 | 0 | | |
| C108 | 652.66 | | | |
| C109 | 1179.3 | 0 | | |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT

DRIVE POINT D

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| D1 | 2.18 | | 26.01 | 17.02 |
| D2 | 4.30 | 0.41 | | |
| D3 | 6.70 | 0.34 | 23.67 | 15.41 |
| D4 | 8.90 | 0.33 | | |
| D5 | 11 | 0.3 | 25.22 | 16.21 |
| D6 | 12.67 | | | |
| D7 | 15.7 | 0.33 | 23.76 | 15.47 |
| D8 | 17.18 | | | |
| D9 | 18.65 | | | |
| D10 | 19.60 | 0.34 | 22.09 | 14.28 |
| D11 | 20.71 | | | |
| D12 | 22.10 | 0.3 | 22.94 | 15.26 |
| D13 | 23.31 | | | |
| D14 | 24.60 | 0.3 | | |
| D15 | 25.61 | | | |
| D16 | 26.70 | 0.29 | 24.58 | 16.05 |
| D17 | 29.60 | 0.28 | | |
| D18 | 32.30 | 0.28 | | |
| D19 | 34.20 | 0.31 | 23.35 | 15.08 |
| D20 | 37.5 | | | |
| D21 | 39.88 | | | |
| D22 | 42.30 | 0.24 | 25.20 | 16.16 |
| D23 | 44.70 | 0.21 | | |
| D24 | 46.68 | | | |
| D25 | 48.75 | | 26.35 | 17.1 |
| D26 | 50.70 | 0.22 | | |
| D27 | 53.11 | | | |
| D28 | 54.68 | | | |
| D29 | 56.88 | | 26.6 | 17.11 |
| D30 | 58.81 | | | |
| D31 | 61.16 | | | |
| D32 | 63.50 | 0.26 | 25.02 | 15.81 |
| D33 | 65.6 | | | |
| D34 | 67.50 | 0.42 | | |
| D35 | 69.60 | 0.6 | 23.27 | 14.58 |
| D36 | 71.6 | | | |
| D37 | 73.66 | | | |
| D38 | 75.95 | | 23.2 | 15.3 |
| D39 | 78.00 | 1.6 | | |
| D40 | 80.13 | | | |
| D41 | 83.80 | 3.2 | | |
| D42 | 84.85 | | 23.02 | 14.47 |
| D43 | 87.80 | 4.06 | | |
| D44 | 89.81 | | 18.56 | 12.02 |
| D45 | 91.90 | 5.44 | | |
| D46 | 94.01 | | 21.55 | 13.85 |
| D47 | 96.00 | 6.3 | | |
| D48 | 98.00 | 5.97 | 20.62 | 12.99 |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
DRIVE POINT D

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| D49 | 100.03 | | | |
| D50 | 103.80 | 6.7 | 22.72 | 13.74 |
| D51 | 107.60 | 5.9 | | |
| D52 | 111.60 | 5.9 | 21.01 | 13.46 |
| D53 | 115.60 | 5.7 | | |
| D54 | 118.60 | 6.5 | 20.95 | 13.30 |
| D55 | 121.50 | 3.9 | | |
| D56 | 125.40 | 6.8 | 20.95 | 13.71 |
| D57 | 129.50 | 5.53 | | |
| D58 | 133.30 | 5.2 | 20.73 | 13.29 |
| D59 | 137.50 | 4.8 | | |
| D60 | 141.30 | 4.7 | 18.17 | 11.85 |
| D61 | 145.00 | 4.6 | | |
| D62 | 149.00 | 4.1 | 15.31 | 9.86 |
| D63 | 153.10 | 3.8 | | |
| D64 | 157.10 | 4.3 | 15.24 | 10.11 |
| D65 | 161.10 | 4.1 | | |
| D66 | 166.10 | 3.7 | 14.08 | 9.30 |
| D67 | 170.10 | 3.1 | | |
| D68 | 171.90 | 3 | 14.01 | 9.26 |
| D69-A | 175.83 | | 10.00 | 5.70 |
| D70 | 180.20 | 2.92 | 14.57 | 9.66 |
| D71 | 184 | | | |
| D72-A | 188.00 | 2.76 | 10.20 | 5.90 |
| D72 | 188 | | 11.51 | 7.69 |
| D73 | 191.8 | | | |
| D74 | 195.40 | 2 | 11.74 | 7.78 |
| D75 | 199.66 | | | |
| D76 | 204.71 | | 10.91 | 7.46 |
| D77 | 208.80 | 1.97 | | |
| D78 | 212.85 | | 10.43 | 7.26 |
| D79 | 217.01 | 1.8 | | |
| D80 | 220.9 | | 10.01 | 6.85 |
| D81 | 224.33 | 1.67 | | |
| D82 | 230.63 | | 8.82 | 6.17 |
| D83 | 236.83 | 1.5 | | |
| D84 | 242.88 | 1.32 | 8.36 | 5.87 |
| D85 | 248.33 | 1.15 | | |
| D86 | 254.91 | 1.21 | 8.50 | 5.99 |
| D87 | 261.23 | 1.2 | | |
| D88 | 266.78 | | 7.34 | 5.03 |
| D89 | 272.33 | | | |
| D90 | 278.98 | | 6.53 | 4.6 |
| D91 | 284.75 | 1.01 | | |
| D92 | 290.71 | | 5.76 | 4.17 |
| D93 | 296.91 | | | |
| D94 | 302.6 | | 5.48 | 4 |
| D95 | 308.5 | 0.49 | | |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
 DRIVE POINT D

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| D96-A | 316.30 | | 2.90 | 3.50 |
| D97 | 320.86 | | 5.34 | 3.89 |
| D98 | 326.33 | 1.08 | | |
| D99-A | 332.66 | | 4.00 | 4.70 |
| D99 | 332.66 | | 6.13 | 4.39 |
| D100 | 342.65 | | | |
| D101 | 358.13 | 0.29 | 5.2 | 3.79 |
| D102 | 388.33 | | | |
| D103 | 406.33 | 0.34 | 4.14 | 3.02 |
| D104 | 432.36 | 0.31 | | |
| D105 | 477.83 | | | |
| D106 | 502.35 | 0.15 | | |
| D107 | 535.7 | | | |
| D108 | 608.16 | 0.13 | 0.772 | 0.419 |
| D109 | 630.45 | | | |
| D110-A | 652.75 | | 1.00 | 1.00 |
| D110 | 652.75 | 0.1 | 0.37 | 0.17 |
| D111 | 864.9 | 0 | | |
| D112 | 701.4 | 0 | | |
| D113 | 945.2 | | | |
| D114 | 991.9 | | | |
| D115 | 1033.4 | 0 | | |
| D116 | 1105 | | | |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
FULLY PENETRATING MONITORING WELL

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| ML1 | 2.47 | 0.01 | | |
| MM1 | 2.83 | 0.02 | | |
| MU1 | 6.23 | 0.06 | | |
| M3 | 7.40 | 0.31 | 30.68 | 40.25 |
| M4 | 9.70 | 1.71 | | |
| M5 | 11.70 | 4.90 | | |
| M6 | 13.30 | 7.30 | 28.47 | 36.06 |
| M7 | 14.80 | 11.80 | | |
| M8 | 16.95 | 20.03 | 23.10 | 29.76 |
| M9 | 18.15 | 23.10 | | |
| M10 | 19.30 | 25.20 | | |
| M11 | 20.4 | 28.8 | 19.378 | 24.519 |
| M12 | 21.60 | 32.30 | | |
| M13 | 23.70 | 35.50 | 16.03 | 20.21 |
| M14 | 25.40 | 36.60 | | |
| M15 | 26.70 | 32.60 | | |
| M16 | 28.80 | 35.60 | | |
| M17 | 31.65 | 38.20 | 13.15 | 16.86 |
| M18 | 33.20 | 46.60 | | |
| M19 | 35.40 | 48.90 | 9.72 | 12.55 |
| M20 | 36.9 | | | |
| M21 | 38.80 | 33.05 | | |
| M22 | 40.30 | 41.70 | 7.33 | 9.49 |
| M23 | 42.00 | 32.80 | | |
| M24 | 43.50 | 29.60 | 8.93 | 11.69 |
| M25 | 45.10 | 18.90 | | |
| M26 | 46.20 | 22.20 | 10.40 | 13.18 |
| M27 | 47.50 | 18.10 | | |
| M28 | 49.00 | 17.52 | | |
| M29 | 50.20 | 15.76 | | |
| M30 | 51.40 | 16.30 | | |
| M31 | 52.70 | 14.40 | 10.44 | 13.53 |
| M32 | 54.10 | 15.55 | | |
| M33 | 55.30 | 15.68 | 7.87 | 10.27 |
| M34 | 56.20 | 14.57 | | |
| M35 | 57.50 | 13.90 | | |
| M36 | 58.40 | 11.49 | | |
| M37 | 59.70 | 11.90 | 9.76 | 12.54 |
| M38 | 60.80 | 10.20 | | |
| M39 | 61.80 | 10.10 | | |
| M40 | 63.00 | 9.20 | | |
| M41 | 64.00 | 10.70 | 8.76 | 11.30 |
| M42 | 65.00 | 10.50 | | |
| M43 | 66.20 | 8.80 | 9.89 | 12.86 |
| M44 | 67.10 | 9.70 | | |
| M45 | 67.9 | 8.8 | 9.111 | 11.898 |
| M46 | 69.00 | 9.70 | | |
| M47 | 70.40 | 8.80 | 8.12 | 10.30 |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
FULLY PENETRATING MONITORING WELL

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| M48 | 71.80 | 8.90 | | |
| M49 | 77.30 | 9.20 | 7.10 | 9.04 |
| M50 | 79.00 | 10.30 | | |
| M51 | 80.50 | 9.80 | 5.05 | 6.55 |
| M52 | 81.70 | 9.50 | | |
| M53 | 84 | | 3.987 | 5.35 |
| M54 | 86.80 | 6.61 | | |
| M55 | 89.1 | | 7.774 | 9.849 |
| M56 | 92.00 | 6.20 | | |
| M57 | 94.66 | | 6.097 | 7.939 |
| M58 | 96.70 | 5.94 | | |
| M59 | 99.33 | | 5.673 | 7.613 |
| M60 | 104.60 | 4.90 | | |
| M61 | 108.28 | | 4.916 | 7.084 |
| M62 | 112.43 | | | |
| M63 | 116.80 | 3.20 | 3.78 | 5.43 |
| M64 | 121.68 | | | |
| M65 | 125.50 | 2.40 | 9.60 | 12.65 |
| M66 | 129.60 | 2.10 | | |
| M67 | 133.63 | | 9.263 | 12.164 |
| M68 | 137.60 | 1.70 | | |
| M69 | 141.8 | | 9.391 | 12.612 |
| M70 | 145.30 | 1.30 | | |
| M71 | 149.33 | | 7.87 | 10.667 |
| M72 | 153.30 | 1.10 | | |
| M73 | 157.30 | 1.20 | 10.42 | 13.99 |
| M74 | 161.00 | 1.10 | | |
| M75 | 166.1 | | | |
| M76 | 171.80 | 0.80 | 10.72 | 14.40 |
| M77-A | 175.70 | | 9.70 | 11.00 |
| M78 | 179.80 | 0.81 | 12.09 | 16.00 |
| M79 | 183.73 | | | |
| M80-A | 187.66 | 0.71 | 10.30 | 11.40 |
| M80 | 187.66 | | 11.863 | 15.299 |
| M81 | 191.66 | | | |
| M82 | 195.63 | | 9.767 | 13.062 |
| M83 | 199.68 | 0.59 | | |
| M84 | 204.66 | | 11.501 | 14.895 |
| M85 | 208.55 | | 15.40 | 18.75 |
| M86 | 212.51 | 0.51 | 10.60 | 14.44 |
| M87 | 216.66 | | | |
| M88 | 220.85 | | 11.215 | 15.163 |
| M89 | 224.40 | 0.42 | | |
| M90 | 230.46 | | 11.106 | 14.568 |
| M91 | 236.55 | 0.38 | | |
| M92 | 242.58 | 0.31 | 11.22 | 14.92 |
| M93 | 254.60 | 0.27 | | |
| M94 | 266.61 | | 11.681 | 15.333 |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
FULLY PENETRATING MONITORING WELL

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| M95 | 278.68 | | 15.30 | 19.14 |
| M96 | 290.63 | | 10.985 | 15.12 |
| M97 | 302.46 | | | |
| M98 | 316.11 | | 11.792 | 15.72 |
| M99 | 326.33 | | 12.213 | 15.97 |
| M100 | 342.50 | | 13.90 | 17.25 |
| M101 | 357.95 | | | |
| M102 | 406.1 | | 12.548 | 16.83 |
| M103 | 432.08 | | | |
| M104 | 477.76 | | | |
| M105 | 502.23 | | | |
| M106 | 535.56 | | 13.18 | 17.79 |
| M107 | 608.03 | | 20.289 | 25.0915 |
| M108 | 630.31 | | 17.01 | 21.57 |
| M109-A | 652.70 | | 8.60 | 17.50 |
| M109 | 652.70 | | 15.14 | 19.52 |
| M110 | 701.50 | | | |
| M111 | 769.10 | | | |
| M112 | 821.50 | | | |
| M113 | 864.90 | | | |
| M114 | 944.90 | | | |
| M115 | 992.10 | | | |
| M116 | 1033.40 | | | |
| M117 | 1105.10 | | | |
| M118 | 1179.30 | | | |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
EXTRACTION WELL

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| S1 | 0.36 | 0.04 | 37.14 | 40.09 |
| S2 | 2.75 | | | |
| S3 | 6.40 | 0.05 | | |
| S4 | 10.4 | | | |
| S5 | 13.22 | | | |
| S6 | 14.80 | 0.08 | | |
| S7 | 16.93 | | | |
| S8 | 18.30 | 0.15 | | |
| S9 | 19.43 | | | |
| S10 | 20.6 | | | |
| S11 | 21.66 | | | |
| S12 | 22.2 | | | |
| S13 | 23.00 | 0.27 | | |
| S14 | 24.20 | 0.43 | 35.85 | 38.73 |
| S15 | 25.60 | 0.65 | | |
| S16 | 26.60 | 0.77 | | |
| S17 | 27.63 | | | |
| S18 | 28.47 | 1.22 | | |
| S19 | 29.35 | 1.57 | | |
| S21 | 31.70 | 2.3 | | |
| S22 | 33.80 | 2.91 | | |
| S23 | 35.9 | | | |
| S24 | 37.00 | 4.2 | | |
| S25 | 38.5 | | | |
| S26 | 39.60 | 4.99 | 31.47 | 34.33 |
| S27 | 40.6 | | | |
| S28 | 41.6 | | | |
| S29 | 42.70 | 6.28 | | |
| S30 | 43.8 | | | |
| S31 | 44.80 | 7 | | |
| S32 | 45.8 | | | |
| S33 | 46.9 | | | |
| S34 | 47.90 | 8.26 | | |
| S35 | 48.90 | 8.3 | | |
| S36 | 49.9 | | | |
| S37 | 50.90 | 9.58 | | |
| S38 | 51.90 | 9.4 | | |
| S39 | 53.10 | 9.72 | | |
| S40 | 53.90 | 11.07 | | |
| S41 | 54.90 | 10.98 | | |
| S42 | 56.00 | 11.16 | | |
| S43 | 56.83 | | | |
| S44 | 58.00 | 10.37 | | |
| S45 | 59 | | | |
| S46 | 60.31 | | 30.91 | 34.58 |
| S47 | 61.30 | 10.4 | | |
| S48 | 62.35 | | | |
| S49 | 63.60 | 9.52 | | |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
EXTRACTION WELL

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| S50 | 64.55 | | | |
| S51 | 65.60 | 9.1 | | |
| S52 | 66.51 | | | |
| S53 | 67.40 | 8.6 | | |
| S54 | 68.33 | | | |
| S55 | 69.40 | 8.2 | | |
| S56 | 70.4 | | | |
| S57 | 71.40 | 7.4 | | |
| S58 | 72.41 | | | |
| S59 | 73.40 | 6.7 | | |
| S60 | 74.41 | | | |
| S61 | 75.50 | 6.3 | | |
| S62 | 76.58 | | | |
| S63 | 77.70 | 5.6 | | |
| S64 | 78.68 | | | |
| S65 | 79.60 | 5.53 | | |
| S66 | 80.63 | | 29.2 | 32.65 |
| S67 | 82.20 | 5.1 | | |
| S68 | 84.50 | 3.91 | | |
| S69 | 86.35 | | | |
| S70 | 88.30 | 3.71 | | |
| S71 | 90.4 | | | |
| S72 | 92.30 | 3.41 | | |
| S73 | 94.38 | | | |
| S74 | 96.40 | 3.3 | | |
| S75 | 98.45 | | | |
| S76 | 100.50 | 3.1 | 27.04 | 30.75 |
| S77 | 104.51 | | | |
| S78 | 108.50 | 2.27 | | |
| S79 | 112.4 | | | |
| S80 | 116.40 | 1.92 | | |
| S81 | 120.60 | 1.19 | | |
| S82 | 124.65 | | | |
| S83 | 129.10 | 1.44 | | |
| S84 | 133.11 | | | |
| S85 | 137.10 | 1.1 | | |
| S86 | 141.25 | | 28.18 | 31.47 |
| S87 | 145.20 | 0.99 | | |
| S88 | 149.26 | | | |
| S89 | 153.20 | 0.85 | | |
| S90 | 157.20 | 0.9 | | |
| S91 | 161.30 | 0.8 | 28.13 | 31.48 |
| S92 | 166.2 | | | |
| S93 | 171.50 | 0.7 | | |
| S94 | 175.46 | | | |
| S95 | 179.68 | | | |
| S96 | 183.46 | | 27.57 | 31.06 |
| S97 | 187.76 | | | |

ROCKY MOUNTAIN ARSENAL INJECTION-EXTRACTION EXPERIMENT
EXTRACTION WELL

| SAMPLE | TIME (hr) | IODIDE (ppm) | TCA (ppb) | TCE (ppb) |
|--------|--------------|-----------------|--------------|--------------|
| S98 | 191.91 | 0.54 | | |
| S99 | 195.58 | | | |
| S100 | 199.73 | | | |
| S101 | 204.35 | | 27.61 | 31.92 |
| S102 | 208.31 | | | |
| S103 | 212.41 | | | |
| S104 | 216.83 | 0.42 | | |
| S105 | 220.63 | | 28.74 | 32.69 |
| S106 | 224.55 | | | |
| S107 | 230.18 | | | |
| S108 | 236.41 | 0.37 | | |
| S109 | 242.41 | 0.31 | 28.37 | 32.96 |
| S110 | 254.41 | 0.29 | | |
| S111 | 266.33 | | | |
| S112 | 278.5 | | | |
| S113 | 290.3 | | 27.71 | 32.37 |
| S114 | 302.23 | | | |
| S115 | 315.91 | | | |
| S116 | 332.43 | | | |
| S117 | 357.68 | | 28.27 | 33.11 |
| S118 | 405.83 | | | |
| S119 | 431.83 | | 32.00 | 36.10 |
| S120 | 477.56 | | 28.05 | 32.79 |
| S121 | 501.95 | | 27.97 | 32.69 |
| S122 | 535.23 | | 26.791 | 32.024 |
| S123 | 630.2 | | 31.17 | 36.55 |
| S124-A | 652.61 | | 16.50 | 31.60 |
| S124 | 652.61 | | 29.79 | 36.16 |
| S125 | 701.45 | | | |
| S126 | 769.05 | | 24.91 | 29.35 |
| S127 | 821.47 | | | |
| S128 | 864.92 | | | |
| S129 | 944.63 | | 24.95 | 29.70 |
| S130 | 991.72 | | | |
| S131 | 1033.40 | | | |
| S132 | 1104.00 | | 22.68 | 27.62 |

APPENDIX E. CALCULATIONS OF PULSE BREAKTHROUGH MEANS

Injection Well

Iodide Data

| Sample | t | I | delt t | delt | I*delt | Cum. Area |
|--------|-------|-------|--------|------|--------|-----------|
| I1 | 0.12 | 59.50 | 0.12 | 0.54 | 31.83 | 31.8325 |
| I2 | 0.95 | 62.10 | 0.83 | 0.64 | 39.74 | 71.57649 |
| I3 | 1.40 | 49.76 | 0.45 | 0.38 | 18.66 | 90.23649 |
| I4 | 1.70 | 53.50 | 0.30 | 0.63 | 33.44 | 123.6739 |
| I5 | 2.65 | 60.60 | 0.95 | 0.89 | 53.63 | 177.3049 |
| I7 | 3.47 | 60.50 | 0.82 | 1.28 | 77.14 | 254.4424 |
| I8 | 5.20 | 57.90 | 1.73 | 1.44 | 83.38 | 337.8184 |
| I9 | 6.35 | 59.40 | 1.15 | 1.01 | 59.99 | 397.8125 |
| I10 | 7.22 | 61.12 | 0.87 | 0.71 | 43.40 | 441.2077 |
| I11 | 7.77 | 54.30 | 0.55 | 1.39 | 75.48 | 516.6846 |
| I13 | 10.00 | 56.10 | 2.23 | 1.29 | 72.37 | 589.0536 |
| I14 | 10.35 | 57.70 | 0.35 | 0.67 | 38.37 | 627.4241 |
| I15 | 11.33 | 55.20 | 0.98 | 1.41 | 77.83 | 705.2561 |
| I16 | 13.17 | 65.00 | 1.84 | 1.72 | 111.80 | 817.0561 |
| I17 | 14.77 | 62.40 | 1.60 | 1.86 | 116.38 | 933.4322 |
| I18 | 16.90 | 59.80 | 2.13 | 2.31 | 138.44 | 1071.869 |
| I20 | 19.40 | 70.50 | 2.50 | 1.80 | 126.90 | 1198.769 |
| I21 | 20.50 | 61.20 | 1.10 | 1.80 | 110.16 | 1308.929 |
| I24 | 23.00 | 67.40 | 2.50 | 1.90 | 128.06 | 1436.989 |
| I26 | 24.30 | 80.60 | 1.30 | 1.25 | 100.75 | 1537.739 |
| I27 | 25.50 | 90.00 | 1.20 | 1.10 | 99.00 | 1636.739 |
| I28 | 26.50 | 70.40 | 1.00 | 0.85 | 59.84 | 1696.579 |
| I29 | 27.20 | 69.02 | 0.70 | 0.55 | 37.96 | 1734.540 |
| I30 | 27.60 | 0.85 | 0.40 | 0.60 | 0.51 | 1735.050 |
| I31 | 28.40 | 1.08 | 0.80 | 2.10 | 2.27 | 1737.318 |
| I34 | 31.80 | 2.53 | 3.40 | 2.70 | 6.83 | 1744.149 |
| I35 | 33.80 | 2.78 | 2.00 | 3.30 | 9.18 | 1753.329 |
| I38 | 38.40 | 4.74 | 4.60 | 4.45 | 21.09 | 1774.422 |
| I42 | 42.70 | 6.44 | 4.30 | 3.70 | 23.83 | 1798.250 |
| I45 | 45.80 | 7.41 | 3.10 | 2.55 | 18.90 | 1817.146 |
| I47 | 47.80 | 8.90 | 2.00 | 2.05 | 18.25 | 1835.391 |
| I49 | 49.90 | 10.00 | 2.10 | 1.55 | 15.50 | 1850.891 |
| I50 | 50.90 | 10.50 | 1.00 | 1.00 | 10.50 | 1861.391 |
| I51 | 51.90 | 9.90 | 1.00 | 1.10 | 10.89 | 1872.281 |
| I52 | 53.10 | 10.40 | 1.20 | 1.00 | 10.40 | 1882.681 |
| I53 | 53.90 | 11.19 | 0.80 | 0.90 | 10.07 | 1892.752 |
| I54 | 54.90 | 11.50 | 1.00 | 1.00 | 11.50 | 1904.252 |
| I55 | 55.90 | 11.70 | 1.00 | 1.55 | 18.13 | 1922.387 |
| I57 | 58.00 | 10.90 | 2.10 | 2.05 | 22.34 | 1944.732 |
| I59 | 60.00 | 10.60 | 2.00 | 2.15 | 22.79 | 1967.522 |
| I61 | 62.30 | 10.20 | 2.30 | 1.75 | 17.85 | 1985.372 |
| I62 | 63.50 | 10.20 | 1.20 | 1.65 | 16.83 | 2002.202 |
| I64 | 65.60 | 9.20 | 2.10 | 1.95 | 17.94 | 2020.142 |
| I66 | 67.40 | 8.86 | 1.80 | 1.85 | 16.39 | 2036.533 |
| I68 | 69.30 | 8.38 | 1.90 | 2.00 | 16.76 | 2053.293 |
| I70 | 71.40 | 7.50 | 2.10 | 2.00 | 15.00 | 2068.293 |
| I72 | 73.30 | 7.00 | 1.90 | 2.05 | 14.35 | 2082.643 |
| I74 | 75.50 | 6.70 | 2.20 | 2.15 | 14.40 | 2097.048 |
| I76 | 77.60 | 5.30 | 2.10 | 2.05 | 10.86 | 2107.913 |

Injection Well

Iodide Data

| Sample | t | I | delt t | delt | I*delt | Cum. Area |
|--------|--------|------|--------|-------|--------|-----------|
| I78 | 79.60 | 5.85 | 2.00 | 2.25 | 13.16 | 2121.075 |
| I80 | 82.10 | 4.62 | 2.50 | 4.40 | 20.33 | 2141.403 |
| I83 | 88.40 | 3.65 | 6.30 | 5.10 | 18.62 | 2160.018 |
| I85 | 92.30 | 3.61 | 3.90 | 3.95 | 14.26 | 2174.278 |
| I87 | 96.30 | 3.30 | 4.00 | 4.00 | 13.20 | 2187.478 |
| I89 | 100.30 | 3.30 | 4.00 | 6.15 | 20.29 | 2207.773 |
| I91 | 108.60 | 2.46 | 8.30 | 8.10 | 19.93 | 2227.699 |
| I93 | 116.50 | 1.95 | 7.90 | 7.85 | 15.31 | 2243.006 |
| I95 | 124.30 | 1.70 | 7.80 | 6.25 | 10.63 | 2253.631 |
| I96 | 129.00 | 1.40 | 4.70 | 6.40 | 8.96 | 2262.591 |
| I98 | 137.10 | 1.30 | 8.10 | 8.05 | 10.47 | 2273.056 |
| I100 | 145.10 | 1.10 | 8.00 | 8.00 | 8.80 | 2281.856 |
| I102 | 153.10 | 0.94 | 8.00 | 6.00 | 5.64 | 2287.496 |
| I103 | 157.10 | 0.90 | 4.00 | 4.05 | 3.64 | 2291.141 |
| I104 | 161.20 | 0.80 | 4.10 | 7.15 | 5.72 | 2296.861 |
| I106 | 171.40 | 0.70 | 10.20 | 13.19 | 9.23 | 2306.094 |
| I110 | 187.58 | 0.71 | 16.18 | 22.61 | 16.05 | 2322.144 |
| I117 | 216.61 | 0.46 | 29.03 | 24.39 | 11.22 | 2333.361 |
| I121 | 236.35 | 0.38 | 19.74 | 12.89 | 4.90 | 2338.257 |
| I122 | 242.38 | 0.34 | 6.03 | 9.02 | 3.07 | 2341.326 |
| I123 | 254.40 | 0.30 | 12.02 | 6.01 | 1.80 | 2343.129 |

Area under Injection: 1734.540 (I1 to I29)
 Total time of injection : 27.55
 Average Injection : 62.95971

Area under Second Pulse: 608.5890 (I30 to I123)
 Peak Concentration: 11.7

COM for 1st pulse: 14.77
 1/2 Area: 867.2701

COM for both pulses: 19.56
 1/2 Area: 1171.564

Drive Point A

Iodide Data

| Sample | t | I | delt t | delt | Area I*delt | Cumulative Area |
|--------|-------|-------|--------|------|----------------|--------------------|
| A2 | 3.90 | 0.01 | 3.90 | 3.70 | 0.04 | 0.04 |
| A3 | 7.40 | 0.01 | 3.50 | 3.35 | 0.03 | 0.07 |
| A5 | 10.60 | 0.54 | 3.20 | 3.75 | 2.03 | 2.10 |
| A7 | 14.90 | 7.37 | 4.30 | 3.25 | 23.95 | 26.05 |
| A8 | 17.10 | 11.83 | 2.20 | 1.70 | 20.11 | 46.16 |
| A9 | 18.30 | 13.9 | 1.20 | 1.20 | 16.68 | 62.84 |
| A10 | 19.50 | 21.4 | 1.20 | 1.15 | 24.61 | 87.45 |
| A11 | 20.60 | 19.6 | 1.10 | 1.13 | 22.05 | 109.50 |
| A12 | 21.75 | 21.8 | 1.15 | 1.30 | 28.34 | 137.84 |
| A13 | 23.20 | 25.67 | 1.45 | 1.32 | 34.01 | 171.85 |
| A14 | 24.40 | 27.4 | 1.20 | 1.15 | 31.51 | 203.36 |
| A15 | 25.50 | 32.26 | 1.10 | 1.05 | 33.87 | 237.23 |
| A16 | 26.50 | 38 | 1.00 | 1.40 | 53.20 | 290.43 |
| A17 | 28.30 | 36.96 | 1.80 | 1.50 | 55.44 | 345.87 |
| A18 | 29.50 | 39.9 | 1.20 | 1.75 | 69.83 | 415.70 |
| A19 | 31.80 | 44.6 | 2.30 | 2.20 | 98.12 | 513.82 |
| A20 | 33.90 | 46.6 | 2.10 | 3.30 | 153.78 | 667.60 |
| A23 | 38.40 | 49.8 | 4.50 | 4.10 | 204.18 | 871.78 |
| A26 | 42.10 | 51.7 | 3.70 | 2.25 | 116.33 | 988.10 |
| A27 | 42.90 | 45.8 | 0.80 | 1.05 | 48.09 | 1036.19 |
| A28 | 44.20 | 50.5 | 1.30 | 1.65 | 83.33 | 1119.52 |
| A30 | 46.20 | 46.8 | 2.00 | 1.50 | 70.20 | 1189.72 |
| A31 | 47.20 | 47.3 | 1.00 | 1.05 | 49.66 | 1239.38 |
| A32 | 48.30 | 44.6 | 1.10 | 1.05 | 46.83 | 1286.21 |
| A33 | 49.30 | 45.3 | 1.00 | 1.00 | 45.30 | 1331.51 |
| A34 | 50.30 | 42.5 | 1.00 | 1.05 | 44.63 | 1376.14 |
| A35 | 51.40 | 40.7 | 1.10 | 1.10 | 44.77 | 1420.91 |
| A36 | 52.50 | 36.6 | 1.10 | 1.60 | 58.56 | 1479.47 |
| A38 | 54.60 | 36.93 | 2.10 | 1.45 | 53.55 | 1533.02 |
| A39 | 55.40 | 34.34 | 0.80 | 1.10 | 37.77 | 1570.79 |
| A40 | 56.80 | 26.4 | 1.40 | 1.10 | 29.04 | 1599.83 |
| A41 | 57.60 | 23.6 | 0.80 | 0.90 | 21.24 | 1621.07 |
| A42 | 58.60 | 24.2 | 1.00 | 1.05 | 25.41 | 1646.48 |
| A43 | 59.70 | 21.15 | 1.10 | 1.60 | 33.84 | 1680.32 |
| A45 | 61.80 | 16.6 | 2.10 | 1.55 | 25.73 | 1706.05 |
| A46 | 62.80 | 15.6 | 1.00 | 1.05 | 16.38 | 1722.43 |
| A47 | 63.90 | 14.2 | 1.10 | 1.00 | 14.20 | 1736.63 |
| A48 | 64.80 | 12.9 | 0.90 | 0.90 | 11.61 | 1748.24 |
| A49 | 65.70 | 10.9 | 0.90 | 1.00 | 10.90 | 1759.14 |
| A50 | 66.80 | 11.7 | 1.10 | 0.97 | 11.35 | 1770.49 |
| A51 | 67.64 | 11.2 | 0.84 | 0.95 | 10.64 | 1781.13 |
| A52 | 68.70 | 11 | 1.06 | 1.03 | 11.33 | 1792.46 |
| A53 | 69.70 | 10.9 | 1.00 | 1.10 | 11.99 | 1804.45 |
| A54 | 70.90 | 10.9 | 1.20 | 1.10 | 11.99 | 1816.44 |
| A55 | 71.90 | 9.1 | 1.00 | 1.00 | 9.10 | 1825.54 |
| A56 | 72.90 | 10.5 | 1.00 | 1.00 | 10.50 | 1836.04 |

Drive Point A
Iodide Data
Sample

| | t | I | delt t | delt | Area I*delt | Cumulative Area |
|------|--------|------|--------|-------|----------------|--------------------|
| A57 | 73.90 | 10.3 | 1.00 | 1.10 | 11.33 | 1847.37 |
| A58 | 75.10 | 10.2 | 1.20 | 1.30 | 13.26 | 1860.63 |
| A59 | 76.50 | 9.1 | 1.40 | 1.10 | 10.01 | 1870.64 |
| A60 | 77.30 | 9.1 | 0.80 | 1.00 | 9.10 | 1879.74 |
| A61 | 78.50 | 10.6 | 1.20 | 1.05 | 11.13 | 1890.87 |
| A62 | 79.40 | 10.3 | 0.90 | 0.95 | 9.79 | 1900.66 |
| A63 | 80.40 | 10.6 | 1.00 | 2.60 | 27.56 | 1928.22 |
| A65 | 84.60 | 9 | 4.20 | 3.95 | 35.55 | 1963.77 |
| A67 | 88.30 | 9.1 | 3.70 | 3.90 | 35.49 | 1999.26 |
| A69 | 92.40 | 9.1 | 4.10 | 4.10 | 37.31 | 2036.57 |
| A71 | 96.50 | 8.28 | 4.10 | 4.10 | 33.95 | 2070.51 |
| A73 | 100.60 | 7.7 | 4.10 | 4.15 | 31.96 | 2102.47 |
| A74 | 104.80 | 6.8 | 4.20 | 3.95 | 26.86 | 2129.33 |
| A75 | 108.50 | 5.5 | 3.70 | 3.95 | 21.72 | 2151.05 |
| A76 | 112.70 | 4.7 | 4.20 | 4.20 | 19.74 | 2170.79 |
| A77 | 116.90 | 3.99 | 4.20 | 3.80 | 15.16 | 2185.96 |
| A78 | 120.30 | 3.83 | 3.40 | 3.70 | 14.17 | 2200.13 |
| A79 | 124.30 | 3.4 | 4.00 | 4.40 | 14.96 | 2215.09 |
| A80 | 129.10 | 2.8 | 4.80 | 4.35 | 12.18 | 2227.27 |
| A81 | 133.00 | 2.3 | 3.90 | 4.05 | 9.31 | 2236.58 |
| A82 | 137.20 | 2.3 | 4.20 | 3.95 | 9.08 | 2245.67 |
| A83 | 140.90 | 2.1 | 3.70 | 3.70 | 7.77 | 2253.44 |
| A84 | 144.60 | 2.1 | 3.70 | 3.90 | 8.19 | 2261.63 |
| A85 | 148.70 | 1.8 | 4.10 | 4.05 | 7.29 | 2268.92 |
| A86 | 152.70 | 1.6 | 4.00 | 4.00 | 6.40 | 2275.32 |
| A87 | 156.70 | 1.7 | 4.00 | 4.00 | 6.80 | 2282.12 |
| A88 | 160.70 | 1.6 | 4.00 | 7.40 | 11.84 | 2293.96 |
| A90 | 171.50 | 1.2 | 10.80 | 9.55 | 11.46 | 2305.42 |
| A92 | 179.80 | 1.1 | 8.30 | 7.95 | 8.74 | 2314.16 |
| A94 | 187.40 | 0.95 | 7.60 | 9.78 | 9.29 | 2323.45 |
| A97 | 199.36 | 0.77 | 11.96 | 10.53 | 8.10 | 2331.56 |
| A99 | 208.45 | 0.67 | 9.09 | 8.68 | 5.81 | 2337.37 |
| A101 | 216.71 | 0.62 | 8.26 | 7.89 | 4.89 | 2342.26 |
| A103 | 224.23 | 0.6 | 7.52 | 9.93 | 5.96 | 2348.22 |
| A105 | 236.58 | 0.49 | 12.35 | 9.15 | 4.48 | 2352.71 |
| A106 | 242.53 | 0.41 | 5.95 | 8.99 | 3.69 | 2356.39 |
| A107 | 254.56 | 0.36 | 12.03 | 23.91 | 8.61 | 2365.00 |
| A110 | 290.35 | 0.1 | 35.79 | 43.89 | 4.39 | 2369.39 |
| A114 | 342.33 | 0.07 | 51.98 | 25.99 | 1.82 | 2371.21 |

Total Area under both peaks: 2371.207
COM for both peaks: 46.61
1/2 Area: 1185.603

Area under Iodide front (A2 to A26): 988.1047
COM for I front: 32.41
1/2 Area: 494.0523

Drive Point A

TCE Data

| Sample | t | TCE | delt t | delt | Area TCE*delt | Cumulative Area |
|--------|-------|--------|--------|-------|------------------|--------------------|
| A1 | 1.37 | 44.513 | 1.37 | 4.385 | 195.1895 | 195.19 |
| A3 | 7.40 | 40.79 | 6.03 | 4.615 | 188.2458 | 383.44 |
| A5 | 10.6 | 42.5 | 3.2 | 2.575 | 109.4375 | 492.87 |
| A6 | 12.55 | 40.886 | 1.95 | 3.25 | 132.8795 | 625.75 |
| A8 | 17.1 | 36.03 | 4.55 | 4.025 | 145.0207 | 770.77 |
| A11 | 20.60 | 33.009 | 3.5 | 3.65 | 120.4828 | 891.26 |
| A14 | 24.4 | 25.194 | 3.8 | 3.85 | 96.9969 | 988.25 |
| A17 | 28.30 | 18.89 | 3.9 | 2.55 | 48.1695 | 1036.42 |
| A18 | 29.50 | 16.791 | 1.2 | 2.8 | 47.0148 | 1083.44 |
| A20 | 33.90 | 9.799 | 4.4 | 3.8 | 37.2362 | 1120.67 |
| A22 | 37.1 | 10.044 | 3.2 | 2.85 | 28.6254 | 1149.30 |
| A24 | 39.60 | 7.993 | 2.5 | 3.55 | 28.37515 | 1177.67 |
| A28 | 44.2 | 5.4 | 4.6 | 3.3 | 17.82 | 1195.49 |
| A30 | 46.2 | 4.597 | 2 | 2.05 | 9.42385 | 1204.92 |
| A32 | 48.3 | 4.771 | 2.1 | 2.05 | 9.78055 | 1214.70 |
| A34 | 50.30 | 3.867 | 2 | 2.1 | 8.1207 | 1222.82 |
| A36 | 52.50 | 4.224 | 2.2 | 2.15 | 9.0816 | 1231.90 |
| A38 | 54.60 | 4.093 | 2.1 | 2.15 | 8.79995 | 1240.70 |
| A40 | 56.80 | 3.995 | 2.2 | 2 | 7.99 | 1248.69 |
| A42 | 58.6 | 3.06 | 1.8 | 2.065 | 6.3189 | 1255.01 |
| A44 | 60.93 | 3.022 | 2.33 | 2.1 | 6.3462 | 1261.36 |
| A46 | 62.80 | 2.988 | 1.87 | 1.935 | 5.78178 | 1267.14 |
| A48 | 64.80 | 2.918 | 2 | 2.42 | 7.06156 | 1274.20 |
| A51 | 67.64 | 2.54 | 2.84 | 3.05 | 7.747 | 1281.95 |
| A54 | 70.90 | 3.1 | 3.26 | 2.63 | 8.153 | 1290.10 |
| A56 | 72.90 | 2.559 | 2 | 2 | 5.118 | 1295.22 |

Area under desorption curve: 1295.216
 Maximum Concentration: 44.51 ppb
 Equivalent pulse-mean = $1295.22/44.51 = 29.10$ hr

Drive Point A

TCA Data

| Sample | t | TCA | delt t | delt | Area TCA*delt | Cumulative Area |
|--------|-------|--------|--------|-------|------------------|--------------------|
| A1 | 1.37 | 37.306 | 1.37 | 4.385 | 163.59 | 163.59 |
| A3 | 7.40 | 34.134 | 6.03 | 4.615 | 157.53 | 321.12 |
| A5 | 10.6 | 35.494 | 3.2 | 2.575 | 91.40 | 412.51 |
| A6 | 12.55 | 32.801 | 1.95 | 3.25 | 106.60 | 519.12 |
| A8 | 17.1 | 28.557 | 4.55 | 4.025 | 114.94 | 634.06 |
| A11 | 20.60 | 24.727 | 3.5 | 3.65 | 90.25 | 724.31 |
| A14 | 24.4 | 17.879 | 3.8 | 3.85 | 68.83 | 793.15 |
| A17 | 28.30 | 13.585 | 3.9 | 2.55 | 34.64 | 827.79 |
| A18 | 29.50 | 11.768 | 1.2 | 2.8 | 32.95 | 860.74 |
| A20 | 33.90 | 6.494 | 4.4 | 3.8 | 24.68 | 885.41 |
| A22 | 37.1 | 6.614 | 3.2 | 2.85 | 18.85 | 904.26 |
| A24 | 39.60 | 5.324 | 2.5 | 3.55 | 18.90 | 923.16 |
| A28 | 44.2 | 3.835 | 4.6 | 3.3 | 12.66 | 935.82 |
| A30 | 46.2 | 3.261 | 2 | 2.05 | 6.69 | 942.51 |
| A32 | 48.3 | 3.324 | 2.1 | 2.05 | 6.81 | 949.32 |
| A34 | 50.30 | 2.487 | 2 | 2.1 | 5.22 | 954.54 |
| A36 | 52.50 | 2.776 | 2.2 | 2.15 | 5.97 | 960.51 |
| A38 | 54.60 | 2.51 | 2.1 | 2.15 | 5.40 | 965.91 |
| A40 | 56.80 | 2.465 | 2.2 | 2 | 4.93 | 970.84 |
| A42 | 58.6 | 1.887 | 1.8 | 2.065 | 3.90 | 974.73 |
| A44 | 60.93 | 1.814 | 2.33 | 2.1 | 3.81 | 978.54 |
| A46 | 62.80 | 1.806 | 1.87 | 1.935 | 3.49 | 982.04 |
| A48 | 64.80 | 1.799 | 2 | 2.42 | 4.35 | 986.39 |
| A51 | 67.64 | 1.463 | 2.84 | 3.05 | 4.46 | 990.85 |
| A54 | 70.90 | 1.789 | 3.26 | 2.63 | 4.71 | 995.56 |
| A56 | 72.90 | 1.416 | 2 | 2 | 2.83 | 998.39 |

Area under desorption curve:

998.3904

Maximum Concentration:

37.31 ppb

Equivalent pulse-mean= $998.39/37.31 = 26.76$ hr

Drive Point C
Iodide Data
Sample

| | t | I | delt t | delt | Area I*delt | Cumulative Area |
|-----|--------|------|--------|-------|----------------|--------------------|
| C2 | 4.15 | 0.02 | 4.15 | 5.45 | 0.11 | 0.1090 |
| C5 | 10.90 | 0.01 | 6.75 | 5.68 | 0.06 | 0.1658 |
| C7 | 15.50 | 0.04 | 4.60 | 3.80 | 0.15 | 0.3178 |
| C8 | 18.50 | 0.01 | 3.00 | 4.35 | 0.04 | 0.3613 |
| C10 | 24.20 | 0.01 | 5.70 | 6.75 | 0.07 | 0.4288 |
| C13 | 32.00 | 0.01 | 7.80 | 10.20 | 0.10 | 0.5307 |
| C17 | 44.60 | 0.01 | 12.60 | 12.30 | 0.12 | 0.6537 |
| C23 | 56.60 | 0.03 | 12.00 | 11.40 | 0.34 | 0.9958 |
| C28 | 67.40 | 0.02 | 10.80 | 6.45 | 0.13 | 1.1248 |
| C29 | 69.50 | 0.02 | 2.10 | 5.20 | 0.10 | 1.2288 |
| C33 | 77.80 | 0.02 | 8.30 | 8.85 | 0.18 | 1.4058 |
| C36 | 87.20 | 0.01 | 9.40 | 8.75 | 0.09 | 1.4933 |
| C38 | 95.30 | 0.04 | 8.10 | 8.20 | 0.33 | 1.8213 |
| C40 | 103.60 | 0.08 | 8.30 | 10.10 | 0.81 | 2.6292 |
| C43 | 115.50 | 0.24 | 11.90 | 8.60 | 2.06 | 4.6933 |
| C45 | 120.80 | 0.62 | 5.30 | 4.75 | 2.95 | 7.6383 |
| C46 | 125.00 | 1.22 | 4.20 | 4.25 | 5.19 | 12.8233 |
| C47 | 129.30 | 1.64 | 4.30 | 4.15 | 6.81 | 19.6293 |
| C48 | 133.30 | 2 | 4.00 | 4.05 | 8.10 | 27.7292 |
| C49 | 137.40 | 2.3 | 4.10 | 3.95 | 9.08 | 36.8142 |
| C50 | 141.20 | 2.7 | 3.80 | 3.75 | 10.13 | 46.9392 |
| C51 | 144.90 | 3.2 | 3.70 | 3.85 | 12.32 | 59.2592 |
| C52 | 148.90 | 3.96 | 4.00 | 4.05 | 16.04 | 75.2972 |
| C53 | 153.00 | 4.8 | 4.10 | 4.00 | 19.20 | 94.4972 |
| C54 | 156.90 | 4.9 | 3.90 | 4.00 | 19.60 | 114.0972 |
| C55 | 161.00 | 5.3 | 4.10 | 4.55 | 24.12 | 138.2123 |
| C56 | 166.00 | 5.24 | 5.00 | 4.50 | 23.58 | 161.7923 |
| C57 | 170.00 | 5.6 | 4.00 | 2.90 | 16.24 | 178.0323 |
| C58 | 171.80 | 5.8 | 1.80 | 5.05 | 29.29 | 207.3223 |
| C60 | 180.10 | 5.7 | 8.30 | 8.00 | 45.60 | 252.9223 |
| C62 | 187.80 | 5.38 | 7.70 | 7.60 | 40.89 | 293.8103 |
| C64 | 195.30 | 4.3 | 7.50 | 5.88 | 25.26 | 319.0728 |
| C65 | 199.55 | 4.51 | 4.25 | 6.65 | 29.99 | 349.0643 |
| C67 | 208.60 | 3.89 | 9.05 | 8.63 | 33.55 | 382.6155 |
| C69 | 216.80 | 3.3 | 8.20 | 7.93 | 26.17 | 408.7845 |
| C71 | 224.46 | 2.88 | 7.66 | 10.00 | 28.80 | 437.5845 |
| C73 | 236.80 | 2.38 | 12.34 | 9.17 | 21.82 | 459.4091 |
| C74 | 242.80 | 1.96 | 6.00 | 5.75 | 11.27 | 470.6791 |
| C75 | 248.30 | 1.82 | 5.50 | 6.00 | 10.92 | 481.5991 |
| C76 | 254.80 | 1.66 | 6.50 | 6.40 | 10.62 | 492.2231 |
| C77 | 261.10 | 1.62 | 6.30 | 5.94 | 9.62 | 501.8459 |
| C78 | 266.68 | 1.57 | 5.58 | 11.76 | 18.47 | 520.3170 |
| C81 | 284.63 | 1.21 | 17.95 | 29.91 | 36.19 | 556.5081 |
| C88 | 326.50 | 1.28 | 41.87 | 28.96 | 37.08 | 593.5833 |
| C90 | 342.56 | 0.47 | 16.06 | 30.91 | 14.53 | 608.1133 |

Drive Point C

Iodide Data

| Sample | t | I | delt t | delt | Area I*delt | Cumulative Area |
|--------|--------|------|--------|-------|----------------|--------------------|
| C92 | 388.33 | 0.19 | 45.77 | 44.85 | 8.52 | 616.6339 |
| C94 | 432.25 | 0.12 | 43.92 | 56.97 | 6.84 | 623.4697 |
| C96 | 502.26 | 0.16 | 70.01 | 87.90 | 14.06 | 637.5345 |
| C98 | 608.06 | 0.09 | 105.80 | 99.60 | 8.96 | 646.4980 |
| C100 | 701.45 | 0.07 | 93.39 | 93.39 | 6.54 | 653.0353 |

Total Area: 653.0353

COM: 199.08

1/2 Area: 326.5176

| Drive Point C TCE Data | | | | | | Area | Cumulative |
|---------------------------|--------|-------|--------|-------|----------|----------|------------|
| Sample | t | TCE | delt t | delt | TCE*delt | | Area |
| C1 | 2.1 | 25.99 | 2.10 | 4.37 | 113.45 | | |
| C3 | 6.63 | 27.85 | 4.53 | 5.70 | 158.75 | | |
| C6 | 13.5 | 26.59 | 6.87 | 5.94 | 157.81 | | |
| C8 | 18.50 | 27.22 | 5.00 | 5.35 | 145.63 | | |
| C10 | 24.20 | 29.59 | 5.70 | 6.75 | 199.73 | | |
| C13 | 32.00 | 29.36 | 7.80 | 6.56 | 192.75 | | |
| C14 | 37.33 | 27.32 | 5.33 | 5.13 | 140.02 | | |
| C16 | 42.25 | 28.76 | 4.92 | 5.63 | 161.78 | | |
| C19 | 48.58 | 29.51 | 6.33 | 5.39 | 159.06 | | |
| C21 | 53.03 | 29.31 | 4.45 | 4.01 | 117.53 | | |
| C23 | 56.60 | 30.07 | 3.57 | 4.06 | 122.23 | | |
| C25 | 61.16 | 32.39 | 4.56 | 4.45 | 144.14 | | |
| C27 | 65.5 | 29.08 | 4.34 | 4.17 | 121.26 | | |
| C29 | 69.50 | 30.38 | 4.00 | 4.03 | 122.43 | | |
| C31 | 73.56 | 28.89 | 4.06 | 4.15 | 119.89 | | |
| C33 | 77.80 | 31.44 | 4.24 | 4.98 | 156.73 | | |
| C35 | 83.53 | 31.1 | 5.73 | 6.70 | 208.37 | | |
| C37 | 91.2 | 32.06 | 7.67 | 7.98 | 255.68 | | |
| C39 | 99.48 | 31.96 | 8.28 | 8.13 | 259.68 | | |
| C41 | 107.45 | 33.26 | 7.97 | 8.01 | 266.41 | | |
| C43 | 115.50 | 34.21 | 8.05 | 6.68 | 228.35 | 228.3518 | |
| C45 | 120.80 | 33.48 | 5.30 | 6.90 | 231.01 | 459.3638 | |
| C47 | 129.30 | 31.74 | 8.50 | 8.30 | 263.44 | 722.8057 | |
| C49 | 137.40 | 30.33 | 8.10 | 7.80 | 236.57 | 959.3795 | |
| C51 | 144.90 | 28.66 | 7.50 | 7.80 | 223.55 | 1182.927 | |
| C53 | 153.00 | 24.65 | 8.10 | 8.05 | 198.43 | 1381.360 | |
| C55 | 161.00 | 20.8 | 8.00 | 13.55 | 281.84 | 1663.200 | |
| C60 | 180.10 | 13.57 | 19.10 | 13.40 | 181.84 | 1845.038 | |
| C62 | 187.8 | 10.42 | 7.70 | 7.60 | 79.19 | 1924.230 | |
| C64 | 195.30 | 7.89 | 7.50 | 8.41 | 66.39 | 1990.624 | |
| C66 | 204.63 | 7.64 | 9.33 | 8.72 | 66.66 | 2057.283 | |
| C68 | 212.75 | 6.64 | 8.12 | 8.09 | 53.68 | 2110.968 | |
| C70 | 220.8 | 5.64 | 8.05 | 8.90 | 50.20 | 2161.164 | |
| C72 | 230.55 | 4.96 | 9.75 | 11.00 | 54.56 | 2215.724 | |
| C74 | 242.80 | 4.25 | 12.25 | 12.13 | 51.53 | 2267.255 | |
| C76 | 254.80 | 3.61 | 12.00 | 11.94 | 43.10 | 2310.358 | |
| C78 | 266.68 | 3.08 | 11.88 | 12.04 | 37.08 | 2347.441 | |
| C80 | 278.88 | 2.71 | 12.20 | 11.95 | 32.38 | 2379.826 | |
| C82 | 290.58 | 2.43 | 11.70 | 11.81 | 28.71 | 2408.536 | |
| C84 | 302.51 | 2.49 | 11.93 | 12.81 | 31.91 | 2440.446 | |
| C86 | 316.21 | 3.56 | 13.70 | 20.03 | 71.29 | 2511.735 | |
| C90 | 342.56 | 2.19 | 26.35 | 45.06 | 98.68 | 2610.416 | |
| C93 | 406.33 | 1.39 | 63.77 | 79.85 | 110.99 | 2721.408 | |
| C96 | 502.26 | 1.62 | 95.93 | 64.66 | 104.75 | 2826.157 | |
| C97 | 535.65 | 2.04 | 33.39 | 52.90 | 107.92 | 2934.073 | |

Drive Point C

TCE Data
Sample t TCE delt t delt Area Cumulative
 TCE*delt Area

| | | | | | | |
|-----------|--------|-------|-------|-------|-------|----------|
| C98 | 608.06 | 1.181 | 72.41 | 47.38 | 55.95 | 2990.023 |
| C99 | 630.4 | 1.36 | 22.34 | 22.30 | 30.33 | 3020.351 |
| C99(MISL) | 652.66 | 1.103 | 22.26 | 22.26 | 24.55 | 3044.903 |

Average Co for TCE (Cmax): 30.06066 (C1 to C43)
Time averaged over: 118.15

Desorption starts at: 111.475
Total area under desorption curve: 3044.903

Equivalent pulse-mean = $111.48 + (3044.90/30.06) = 212.77$ hr

Drive Point C

| TCA Data Sample | t | TCA | delt t | delt | Area TCA*delt | Cumulative Area |
|--------------------|---|-----|--------|------|------------------|--------------------|
|--------------------|---|-----|--------|------|------------------|--------------------|

| | | | | | | |
|-----|--------|-------|-------|-------|--------|---------|
| C1 | 2.1 | 30.74 | 2.10 | 4.37 | 134.18 | |
| C3 | 6.63 | 33.08 | 4.53 | 5.70 | 188.56 | |
| C6 | 13.5 | 31.33 | 6.87 | 5.94 | 185.94 | |
| C8 | 18.50 | 32.18 | 5.00 | 5.35 | 172.16 | |
| C10 | 24.20 | 34.69 | 5.70 | 6.75 | 234.16 | |
| C13 | 32.00 | 34.46 | 7.80 | 6.56 | 226.23 | |
| C14 | 37.33 | 30.62 | 5.33 | 5.13 | 156.93 | |
| C16 | 42.25 | 32.73 | 4.92 | 5.63 | 184.11 | |
| C19 | 48.58 | 33.82 | 6.33 | 5.39 | 182.29 | |
| C21 | 53.03 | 32.81 | 4.45 | 4.01 | 131.57 | |
| C23 | 56.60 | 34.26 | 3.57 | 4.06 | 139.27 | |
| C25 | 61.16 | 35.95 | 4.56 | 4.45 | 159.98 | |
| C27 | 65.5 | 32.42 | 4.34 | 4.17 | 135.19 | |
| C29 | 69.50 | 33.58 | 4.00 | 4.03 | 135.33 | |
| C31 | 73.56 | 31.39 | 4.06 | 4.15 | 130.27 | |
| C33 | 77.80 | 34.19 | 4.24 | 4.98 | 170.44 | |
| C35 | 83.53 | 33.41 | 5.73 | 6.70 | 223.85 | |
| C37 | 91.2 | 33.56 | 7.67 | 7.98 | 267.64 | |
| C39 | 99.48 | 33.34 | 8.28 | 8.13 | 270.89 | |
| C41 | 107.45 | 33.88 | 7.97 | 8.01 | 271.38 | |
| C43 | 115.50 | 34.92 | 8.05 | 6.68 | 233.09 | 233.09 |
| C45 | 120.80 | 34.07 | 5.30 | 6.90 | 235.08 | 468.17 |
| C47 | 129.30 | 32.81 | 8.50 | 8.30 | 272.32 | 740.50 |
| C49 | 137.40 | 30.80 | 8.10 | 7.80 | 240.24 | 980.74 |
| C51 | 144.90 | 29.39 | 7.50 | 7.80 | 229.24 | 1209.98 |
| C53 | 153.00 | 25.06 | 8.10 | 8.05 | 201.73 | 1411.71 |
| C55 | 161.00 | 21.40 | 8.00 | 13.55 | 289.97 | 1701.68 |
| C60 | 180.10 | 13.68 | 19.10 | 13.40 | 183.31 | 1884.99 |
| C62 | 187.8 | 10.62 | 7.70 | 7.60 | 80.71 | 1965.71 |
| C64 | 195.30 | 7.73 | 7.50 | 8.41 | 65.05 | 2030.75 |
| C66 | 204.63 | 7.45 | 9.33 | 8.72 | 65.00 | 2095.76 |
| C68 | 212.75 | 6.43 | 8.12 | 8.09 | 51.99 | 2147.74 |
| C70 | 220.8 | 5.36 | 8.05 | 8.90 | 47.70 | 2195.45 |
| C72 | 230.55 | 4.76 | 9.75 | 11.00 | 52.36 | 2247.81 |
| C74 | 242.80 | 3.96 | 12.25 | 12.13 | 48.02 | 2295.82 |
| C76 | 254.80 | 3.34 | 12.00 | 11.94 | 39.88 | 2335.70 |
| C78 | 266.68 | 2.75 | 11.88 | 12.04 | 33.11 | 2368.81 |
| C80 | 278.88 | 2.44 | 12.20 | 11.95 | 29.16 | 2397.97 |
| C82 | 290.58 | 2.01 | 11.70 | 11.81 | 23.75 | 2421.72 |
| C84 | 302.51 | 2.1 | 11.93 | 12.81 | 26.91 | 2448.63 |
| C86 | 316.21 | 3.23 | 13.70 | 20.03 | 64.68 | 2513.31 |
| C90 | 342.56 | 1.81 | 26.35 | 45.06 | 81.56 | 2594.87 |
| C93 | 406.33 | 1.07 | 63.77 | 79.85 | 85.44 | 2680.31 |
| C96 | 502.26 | 1.36 | 95.93 | 64.66 | 87.94 | 2768.24 |
| C97 | 535.65 | 1.82 | 33.39 | 52.90 | 96.28 | 2864.52 |

Drive Point C

TCA Data

Sample

t

TCA

delt t

delt

Area
TCA*delt

Cumulative
Area

| | | | | | | |
|-----------|--------|-------|-------|-------|-------|---------|
| C98 | 608.06 | 1.091 | 72.41 | 47.38 | 51.69 | 2916.21 |
| C99 | 630.4 | 0.89 | 22.34 | 22.30 | 19.85 | 2936.06 |
| C99(MISL) | 652.66 | 0.98 | 22.26 | 22.26 | 21.70 | 2957.76 |

Average Co for TCA (Cmax): 33.29188 (C1 to C43)
Time averaged over: 118.15

Desorption starts at: 111.475
Total area under desorption curve: 2957.759

Equivalent pulse-mean = $111.48 + (2957.76/33.29) = 200.33$ hr

| Drive Point D Iodide Data | | | | | Area | Cumulative |
|------------------------------|--------|------|--------|-------|--------|------------|
| Sample | t | I | delt t | delt | I*delt | Area |
| D2 | 4.30 | 0.41 | 4.30 | 3.35 | 1.37 | 1.37 |
| D3 | 6.70 | 0.34 | 2.40 | 2.30 | 0.78 | 2.16 |
| D4 | 8.90 | 0.33 | 2.20 | 2.15 | 0.71 | 2.87 |
| D5 | 11.00 | 0.3 | 2.10 | 3.40 | 1.02 | 3.89 |
| D7 | 15.70 | 0.33 | 4.70 | 4.30 | 1.42 | 5.30 |
| D10 | 19.60 | 0.34 | 3.90 | 3.20 | 1.09 | 6.39 |
| D12 | 22.10 | 0.3 | 2.50 | 2.50 | 0.75 | 7.14 |
| D14 | 24.60 | 0.3 | 2.50 | 2.30 | 0.69 | 7.83 |
| D16 | 26.70 | 0.29 | 2.10 | 2.50 | 0.73 | 8.56 |
| D17 | 29.60 | 0.28 | 2.90 | 2.80 | 0.78 | 9.34 |
| D18 | 32.30 | 0.28 | 2.70 | 2.30 | 0.64 | 9.99 |
| D19 | 34.20 | 0.31 | 1.90 | 5.00 | 1.55 | 11.54 |
| D22 | 42.30 | 0.24 | 8.10 | 5.25 | 1.26 | 12.80 |
| D23 | 44.70 | 0.21 | 2.40 | 4.20 | 0.88 | 13.68 |
| D26 | 50.70 | 0.22 | 6.00 | 9.40 | 2.07 | 15.75 |
| D32 | 63.50 | 0.26 | 12.80 | 8.40 | 2.18 | 17.93 |
| D34 | 67.50 | 0.42 | 4.00 | 3.05 | 1.28 | 19.21 |
| D35 | 69.60 | 0.6 | 2.10 | 5.25 | 3.15 | 22.36 |
| D39 | 78.00 | 1.6 | 8.40 | 7.10 | 11.36 | 33.72 |
| D41 | 83.80 | 3.2 | 5.80 | 4.90 | 15.68 | 49.40 |
| D43 | 87.80 | 4.06 | 4.00 | 4.05 | 16.44 | 65.84 |
| D45 | 91.90 | 5.44 | 4.10 | 4.10 | 22.30 | 88.15 |
| D47 | 96.00 | 6.3 | 4.10 | 3.05 | 19.21 | 107.36 |
| D48 | 98.00 | 5.97 | 2.00 | 3.90 | 23.28 | 130.65 |
| D50 | 103.80 | 6.7 | 5.80 | 4.80 | 32.16 | 162.80 |
| D51 | 107.60 | 5.9 | 3.80 | 3.90 | 23.01 | 185.81 |
| D52 | 111.60 | 5.9 | 4.00 | 4.00 | 23.60 | 209.41 |
| D53 | 115.60 | 5.7 | 4.00 | 3.50 | 19.95 | 229.36 |
| D54 | 118.60 | 6.5 | 3.00 | 2.95 | 19.18 | 248.54 |
| D55 | 121.50 | 3.9 | 2.90 | 3.40 | 13.26 | 261.80 |
| D56 | 125.40 | 6.8 | 3.90 | 4.00 | 27.20 | 289.00 |
| D57 | 129.50 | 5.53 | 4.10 | 3.95 | 21.84 | 310.84 |
| D58 | 133.30 | 5.2 | 3.80 | 4.00 | 20.80 | 331.64 |
| D59 | 137.50 | 4.8 | 4.20 | 4.00 | 19.20 | 350.84 |
| D60 | 141.30 | 4.7 | 3.80 | 3.75 | 17.63 | 368.47 |
| D61 | 145.00 | 4.6 | 3.70 | 3.85 | 17.71 | 386.18 |
| D62 | 149.00 | 4.1 | 4.00 | 4.05 | 16.61 | 402.78 |
| D63 | 153.10 | 3.8 | 4.10 | 4.05 | 15.39 | 418.17 |
| D64 | 157.10 | 4.3 | 4.00 | 4.00 | 17.20 | 435.37 |
| D65 | 161.10 | 4.1 | 4.00 | 4.50 | 18.45 | 453.82 |
| D66 | 166.10 | 3.7 | 5.00 | 4.50 | 16.65 | 470.47 |
| D67 | 170.10 | 3.1 | 4.00 | 2.90 | 8.99 | 479.46 |
| D68 | 171.90 | 3 | 1.80 | 5.05 | 15.15 | 494.61 |
| D70 | 180.20 | 2.92 | 8.30 | 8.05 | 23.51 | 518.12 |
| D72 | 188.00 | 2.76 | 7.80 | 7.60 | 20.98 | 539.10 |
| D74 | 195.40 | 2 | 7.40 | 10.40 | 20.80 | 559.90 |
| D77 | 208.80 | 1.97 | 13.40 | 10.81 | 21.29 | 581.18 |
| D79 | 217.01 | 1.8 | 8.21 | 7.76 | 13.98 | 595.16 |

Drive Point D
Iodide Data
Sample

| | t | I | delt t | delt | Area I*delt | Cumulative Area |
|------|--------|------|--------|-------|----------------|--------------------|
| D81 | 224.33 | 1.67 | 7.32 | 9.91 | 16.55 | 611.71 |
| D83 | 236.83 | 1.5 | 12.50 | 9.28 | 13.91 | 625.62 |
| D84 | 242.88 | 1.32 | 6.05 | 5.75 | 7.59 | 633.21 |
| D85 | 248.33 | 1.15 | 5.45 | 6.01 | 6.92 | 640.13 |
| D86 | 254.91 | 1.21 | 6.58 | 6.45 | 7.80 | 647.93 |
| D87 | 261.23 | 1.2 | 6.32 | 14.92 | 17.90 | 665.84 |
| D91 | 284.75 | 1.01 | 23.52 | 23.63 | 23.87 | 689.71 |
| D95 | 308.5 | 0.49 | 23.75 | 20.79 | 10.19 | 699.89 |
| D98 | 326.33 | 1.08 | 17.83 | 24.81 | 26.80 | 726.69 |
| D101 | 358.13 | 0.29 | 31.80 | 40.00 | 11.60 | 738.29 |
| D103 | 406.33 | 0.34 | 48.20 | 37.12 | 12.62 | 750.91 |
| D104 | 432.36 | 0.31 | 26.03 | 26.03 | 8.07 | 758.98 |

Total Area: 758.9833
 1/2 Area: 379.4916
 COM: 145.55

Drive Point D

TCE Data

| Sample | t | TCE | delt t | delt | Area TCE*delt | Cumulative Area |
|--------|--------|-------|--------|-------|------------------|--------------------|
| D1 | 2.18 | 17.02 | 2.18 | 4.44 | 75.57 | |
| D3 | 6.70 | 15.41 | 4.52 | 4.41 | 67.96 | |
| D5 | 11 | 16.21 | 4.30 | 4.50 | 72.95 | |
| D7 | 15.7 | 15.47 | 4.70 | 4.30 | 66.52 | |
| D10 | 19.60 | 14.28 | 3.90 | 3.20 | 45.70 | |
| D12 | 22.10 | 15.26 | 2.50 | 3.55 | 54.17 | |
| D16 | 26.70 | 16.05 | 4.60 | 6.05 | 97.10 | |
| D19 | 34.20 | 15.08 | 7.50 | 7.80 | 117.62 | |
| D22 | 42.30 | 16.16 | 8.10 | 7.27 | 117.56 | |
| D25 | 48.75 | 17.1 | 6.45 | 7.29 | 124.66 | |
| D29 | 56.88 | 17.11 | 8.13 | 7.38 | 126.19 | 126.19 |
| D32 | 63.50 | 15.81 | 6.62 | 6.36 | 100.55 | 226.74 |
| D35 | 69.60 | 14.58 | 6.10 | 6.23 | 90.76 | 317.50 |
| D38 | 75.95 | 15.3 | 6.35 | 7.63 | 116.66 | 434.16 |
| D42 | 84.85 | 14.47 | 8.90 | 6.93 | 100.28 | 534.44 |
| D44 | 89.81 | 12.02 | 4.96 | 4.58 | 55.05 | 589.49 |
| D46 | 94.01 | 13.85 | 4.20 | 4.09 | 56.72 | 646.21 |
| D48 | 98.00 | 12.99 | 3.99 | 4.90 | 63.59 | 709.79 |
| D50 | 103.80 | 13.74 | 5.80 | 6.80 | 93.43 | 803.22 |
| D52 | 111.60 | 13.46 | 7.80 | 7.40 | 99.60 | 902.83 |
| D54 | 118.60 | 13.30 | 7.00 | 6.90 | 91.77 | 994.60 |
| D56 | 125.40 | 13.71 | 6.80 | 7.35 | 100.77 | 1095.37 |
| D58 | 133.30 | 13.29 | 7.90 | 7.95 | 105.66 | 1201.02 |
| D60 | 141.30 | 11.85 | 8.00 | 7.85 | 93.02 | 1294.04 |
| D62 | 149.00 | 9.86 | 7.70 | 7.90 | 77.89 | 1371.94 |
| D64 | 157.10 | 10.11 | 8.10 | 8.55 | 86.44 | 1458.38 |
| D66 | 166.10 | 9.30 | 9.00 | 7.40 | 68.82 | 1527.20 |
| D68 | 171.90 | 9.26 | 5.80 | 7.05 | 65.28 | 1592.48 |
| D70 | 180.20 | 9.66 | 8.30 | 8.05 | 77.76 | 1670.24 |
| D72 | 188 | 7.69 | 7.80 | 7.60 | 58.44 | 1728.69 |
| D74 | 195.40 | 7.78 | 7.40 | 8.36 | 65.00 | 1793.69 |
| D76 | 204.71 | 7.46 | 9.31 | 8.73 | 65.09 | 1858.78 |
| D78 | 212.85 | 7.26 | 8.14 | 8.09 | 58.77 | 1917.55 |
| D80 | 220.9 | 6.85 | 8.05 | 8.89 | 60.90 | 1978.44 |
| D82 | 230.63 | 6.17 | 9.73 | 10.99 | 67.81 | 2046.25 |
| D84 | 242.88 | 5.87 | 12.25 | 12.14 | 71.26 | 2117.52 |
| D86 | 254.91 | 5.99 | 12.03 | 11.95 | 71.58 | 2189.10 |
| D88 | 266.78 | 5.03 | 11.87 | 12.03 | 60.54 | 2249.63 |
| D90 | 278.98 | 4.6 | 12.20 | 11.97 | 55.04 | 2304.67 |
| D92 | 290.71 | 4.17 | 11.73 | 11.81 | 49.25 | 2353.92 |
| D94 | 302.6 | 4 | 11.89 | 15.08 | 60.30 | 2414.22 |
| D97 | 320.86 | 3.89 | 18.26 | 15.03 | 58.47 | 2472.69 |
| D99 | 332.66 | 4.39 | 11.80 | 18.63 | 81.81 | 2554.49 |
| D101 | 358.13 | 3.79 | 25.47 | 36.83 | 139.60 | 2694.10 |

Drive Point D

TCE Data

| Sample | t | TCE | delt t | delt | Area TCE*delt | Cumulative Area |
|--------|--------|-------|--------|--------|------------------|--------------------|
| D103 | 406.33 | 3.02 | 48.20 | 125.01 | 377.55 | 3071.64 |
| D108 | 608.16 | 0.419 | 201.83 | 123.21 | 51.62 | 3123.27 |
| D110 | 652.75 | 0.17 | 44.59 | 44.59 | 7.45 | 3130.71 |

Average Co for TCA (Cmax): 16.04913 (D1 to D29)
 Time averaged over: 60.19

Desorption curve starts at: 52.815
 Total area under desorption curve: 3130.714

Equivalent pulse-mean = $52.82 + (3130.71/16.05) = 247.88$ hr

Drive Point D

TCA Data

| Sample | t | TCA | delt t | delt | Area TCA*delt | Cumulative Area |
|--------|--------|-------|--------|-------|------------------|--------------------|
| D1 | 2.18 | 26.01 | 2.18 | 4.44 | 115.48 | |
| D3 | 6.70 | 23.67 | 4.52 | 4.41 | 104.38 | |
| D5 | 11 | 25.22 | 4.30 | 4.50 | 113.49 | |
| D7 | 15.7 | 23.76 | 4.70 | 4.30 | 102.17 | |
| D10 | 19.60 | 22.09 | 3.90 | 3.20 | 70.69 | |
| D12 | 22.10 | 22.94 | 2.50 | 3.55 | 81.44 | |
| D16 | 26.70 | 24.58 | 4.60 | 6.05 | 148.71 | |
| D19 | 34.20 | 23.35 | 7.50 | 7.80 | 182.13 | |
| D22 | 42.30 | 25.20 | 8.10 | 7.27 | 183.33 | |
| D25 | 48.75 | 26.35 | 6.45 | 7.29 | 192.09 | |
| D29 | 56.88 | 26.6 | 8.13 | 7.38 | 196.18 | 196.18 |
| D32 | 63.50 | 25.02 | 6.62 | 6.36 | 159.13 | 355.30 |
| D35 | 69.60 | 23.27 | 6.10 | 6.23 | 144.86 | 500.16 |
| D38 | 75.95 | 23.2 | 6.35 | 7.63 | 176.90 | 677.06 |
| D42 | 84.85 | 23.02 | 8.90 | 6.93 | 159.53 | 836.59 |
| D44 | 89.81 | 18.56 | 4.96 | 4.58 | 85.00 | 921.59 |
| D46 | 94.01 | 21.55 | 4.20 | 4.09 | 88.25 | 1009.84 |
| D48 | 98.00 | 20.62 | 3.99 | 4.90 | 100.93 | 1110.77 |
| D50 | 103.80 | 22.72 | 5.80 | 6.80 | 154.50 | 1265.27 |
| D52 | 111.60 | 21.01 | 7.80 | 7.40 | 155.47 | 1420.74 |
| D54 | 118.60 | 20.95 | 7.00 | 6.90 | 144.56 | 1565.30 |
| D56 | 125.40 | 20.95 | 6.80 | 7.35 | 153.98 | 1719.28 |
| D58 | 133.30 | 20.73 | 7.90 | 7.95 | 164.80 | 1884.08 |
| D60 | 141.30 | 18.17 | 8.00 | 7.85 | 142.63 | 2026.72 |
| D62 | 149.00 | 15.31 | 7.70 | 7.90 | 120.95 | 2147.67 |
| D64 | 157.10 | 15.24 | 8.10 | 8.55 | 130.30 | 2277.97 |
| D66 | 166.10 | 14.08 | 9.00 | 7.40 | 104.19 | 2382.16 |
| D68 | 171.90 | 14.01 | 5.80 | 7.05 | 98.77 | 2480.93 |
| D70 | 180.20 | 14.57 | 8.30 | 8.05 | 117.29 | 2598.22 |
| D72 | 188 | 11.51 | 7.80 | 7.60 | 87.48 | 2685.70 |
| D74 | 195.40 | 11.74 | 7.40 | 8.36 | 98.09 | 2783.78 |
| D76 | 204.71 | 10.91 | 9.31 | 8.73 | 95.19 | 2878.97 |
| D78 | 212.85 | 10.43 | 8.14 | 8.09 | 84.43 | 2963.41 |
| D80 | 220.9 | 10.01 | 8.05 | 8.89 | 88.99 | 3052.39 |
| D82 | 230.63 | 8.82 | 9.73 | 10.99 | 96.93 | 3149.33 |
| D84 | 242.88 | 8.36 | 12.25 | 12.14 | 101.49 | 3250.82 |
| D86 | 254.91 | 8.50 | 12.03 | 11.95 | 101.57 | 3352.39 |
| D88 | 266.78 | 7.34 | 11.87 | 12.03 | 88.34 | 3440.73 |
| D90 | 278.98 | 6.53 | 12.20 | 11.97 | 78.13 | 3518.86 |
| D92 | 290.71 | 5.76 | 11.73 | 11.81 | 68.03 | 3586.89 |
| D94 | 302.6 | 5.48 | 11.89 | 15.08 | 82.61 | 3669.50 |
| D97 | 320.86 | 5.34 | 18.26 | 15.03 | 80.26 | 3749.76 |
| D99 | 332.66 | 6.13 | 11.80 | 18.63 | 114.23 | 3863.99 |
| D101 | 358.13 | 5.2 | 25.47 | 36.83 | 191.54 | 4055.53 |

Drive Point D

TCA Data

| Sample | t | TCA | delt t | delt | Area TCA*delt | Cumulative Area |
|--------|--------|-------|--------|--------|------------------|--------------------|
| D103 | 406.33 | 4.14 | 48.20 | 125.01 | 517.56 | 4573.09 |
| D108 | 608.16 | 0.772 | 201.83 | 123.21 | 95.12 | 4668.21 |
| D110 | 652.75 | 0.37 | 44.59 | 44.59 | 16.28 | 4684.49 |

Average Co for TCA (Cmax): 24.75639 (D1 to D29)
Time averaged over: 60.19

Desorption curve starts at: 52.815
Total area under desorption curve: 4684.486

Equivalent pulse-mean = $52.82 + (4684.49/24.76) = 242.02$ hr

Fully Penetrating Monitoring Well

Iodide Data

| Sample | t | I | delt t | delt | Area I*delt | Cumulative Area |
|--------|---|---|--------|------|----------------|--------------------|
|--------|---|---|--------|------|----------------|--------------------|

| | | | | | | |
|-----|-------|-------|------|------|--------|---------|
| M1 | 6.23 | 0.01 | 6.23 | 1.17 | 0.01 | 0.01 |
| M3 | 7.40 | 0.31 | 1.17 | 1.73 | 0.54 | 0.55 |
| M4 | 9.70 | 1.71 | 2.30 | 2.15 | 3.68 | 4.23 |
| M5 | 11.70 | 4.90 | 2.00 | 1.80 | 8.82 | 13.05 |
| M6 | 13.30 | 7.30 | 1.60 | 1.55 | 11.32 | 24.36 |
| M7 | 14.80 | 11.80 | 1.50 | 1.83 | 21.54 | 45.90 |
| M8 | 16.95 | 20.03 | 2.15 | 1.67 | 33.55 | 79.45 |
| M9 | 18.15 | 23.10 | 1.20 | 1.17 | 27.14 | 106.59 |
| M10 | 19.30 | 25.20 | 1.15 | 1.13 | 28.35 | 134.94 |
| M11 | 20.4 | 28.8 | 1.10 | 1.15 | 33.12 | 168.06 |
| M12 | 21.60 | 32.30 | 1.20 | 1.65 | 53.30 | 221.35 |
| M13 | 23.70 | 35.50 | 2.10 | 1.90 | 67.45 | 288.80 |
| M14 | 25.40 | 36.60 | 1.70 | 1.50 | 54.90 | 343.70 |
| M15 | 26.70 | 32.60 | 1.30 | 1.70 | 55.42 | 399.12 |
| M16 | 28.80 | 35.60 | 2.10 | 2.47 | 88.11 | 487.23 |
| M17 | 31.65 | 38.20 | 2.85 | 2.20 | 84.04 | 571.27 |
| M18 | 33.20 | 46.60 | 1.55 | 1.88 | 87.38 | 658.65 |
| M19 | 35.40 | 48.90 | 2.20 | 2.80 | 136.92 | 795.57 |
| M21 | 38.80 | 33.05 | 3.40 | 2.45 | 80.97 | 876.54 |
| M22 | 40.30 | 41.70 | 1.50 | 1.60 | 66.72 | 943.26 |
| M23 | 42.00 | 32.80 | 1.70 | 1.60 | 52.48 | 995.74 |
| M24 | 43.50 | 29.60 | 1.50 | 1.55 | 45.88 | 1041.62 |
| M25 | 45.10 | 18.90 | 1.60 | 1.35 | 25.52 | 1067.14 |
| M26 | 46.20 | 22.20 | 1.10 | 1.20 | 26.64 | 1093.78 |
| M27 | 47.50 | 18.10 | 1.30 | 1.40 | 25.34 | 1119.12 |
| M28 | 49.00 | 17.52 | 1.50 | 1.35 | 23.65 | 1142.77 |
| M29 | 50.20 | 15.76 | 1.20 | 1.20 | 18.91 | 1161.68 |
| M30 | 51.40 | 16.30 | 1.20 | 1.25 | 20.37 | 1182.06 |
| M31 | 52.70 | 14.40 | 1.30 | 1.35 | 19.44 | 1201.50 |
| M32 | 54.10 | 15.55 | 1.40 | 1.30 | 20.21 | 1221.71 |
| M33 | 55.30 | 15.68 | 1.20 | 1.05 | 16.46 | 1238.17 |
| M34 | 56.20 | 14.57 | 0.90 | 1.10 | 16.03 | 1254.20 |
| M35 | 57.50 | 13.90 | 1.30 | 1.10 | 15.29 | 1269.49 |
| M36 | 58.40 | 11.49 | 0.90 | 1.10 | 12.64 | 1282.13 |
| M37 | 59.70 | 11.90 | 1.30 | 1.20 | 14.28 | 1296.41 |
| M38 | 60.80 | 10.20 | 1.10 | 1.05 | 10.71 | 1307.12 |
| M39 | 61.80 | 10.10 | 1.00 | 1.10 | 11.11 | 1318.23 |
| M40 | 63.00 | 9.20 | 1.20 | 1.10 | 10.12 | 1328.35 |
| M41 | 64.00 | 10.70 | 1.00 | 1.00 | 10.70 | 1339.05 |
| M42 | 65.00 | 10.50 | 1.00 | 1.10 | 11.55 | 1350.60 |
| M43 | 66.20 | 8.80 | 1.20 | 1.05 | 9.24 | 1359.84 |
| M44 | 67.10 | 9.70 | 0.90 | 0.85 | 8.25 | 1368.09 |
| M45 | 67.9 | 8.8 | 0.80 | 0.95 | 8.36 | 1376.45 |
| M46 | 69.00 | 9.70 | 1.10 | 1.25 | 12.13 | 1388.57 |
| M47 | 70.40 | 8.80 | 1.40 | 1.40 | 12.32 | 1400.89 |
| M48 | 71.80 | 8.90 | 1.40 | 3.45 | 30.71 | 1431.60 |

Fully Penetrating Monitoring Well

Iodide Data

| Sample | t | I | delt t | delt | Area I*delt | Cumulative Area |
|--------|--------|-------|--------|-------|----------------|--------------------|
| M49 | 77.30 | 9.20 | 5.50 | 3.60 | 33.12 | 1464.72 |
| M50 | 79.00 | 10.30 | 1.70 | 1.60 | 16.48 | 1481.20 |
| M51 | 80.50 | 9.80 | 1.50 | 1.35 | 13.23 | 1494.43 |
| M52 | 81.70 | 9.50 | 1.20 | 3.15 | 29.93 | 1524.35 |
| M54 | 86.80 | 6.61 | 5.10 | 5.15 | 34.04 | 1558.39 |
| M56 | 92.00 | 6.20 | 5.20 | 4.95 | 30.69 | 1589.08 |
| M58 | 96.70 | 5.94 | 4.70 | 6.30 | 37.42 | 1626.50 |
| M60 | 104.60 | 4.90 | 7.90 | 10.05 | 49.25 | 1675.75 |
| M63 | 116.80 | 3.20 | 12.20 | 10.45 | 33.44 | 1709.19 |
| M65 | 125.50 | 2.40 | 8.70 | 6.40 | 15.36 | 1724.55 |
| M66 | 129.60 | 2.10 | 4.10 | 6.05 | 12.71 | 1737.25 |
| M68 | 137.60 | 1.70 | 8.00 | 7.85 | 13.34 | 1750.60 |
| M70 | 145.30 | 1.30 | 7.70 | 7.85 | 10.20 | 1760.80 |
| M72 | 153.30 | 1.10 | 8.00 | 6.00 | 6.60 | 1767.40 |
| M73 | 157.30 | 1.20 | 4.00 | 3.85 | 4.62 | 1772.02 |
| M74 | 161.00 | 1.10 | 3.70 | 7.25 | 7.98 | 1780.00 |
| M76 | 171.80 | 0.80 | 10.80 | 9.40 | 7.52 | 1787.52 |
| M78 | 179.80 | 0.81 | 8.00 | 7.93 | 6.42 | 1793.94 |
| M80 | 187.66 | 0.71 | 7.86 | 9.94 | 7.06 | 1801.00 |
| M83 | 199.68 | 0.59 | 12.02 | 12.42 | 7.33 | 1808.33 |
| M86 | 212.51 | 0.51 | 12.83 | 12.36 | 6.30 | 1814.63 |
| M89 | 224.40 | 0.42 | 11.89 | 12.02 | 5.05 | 1819.68 |
| M91 | 236.55 | 0.38 | 12.15 | 9.09 | 3.45 | 1823.14 |
| M92 | 242.58 | 0.31 | 6.03 | 9.03 | 2.80 | 1825.93 |
| M93 | 254.60 | 0.27 | 12.02 | 12.02 | 3.25 | 1829.18 |

Area under peaks: 1829.179
 1/2 Area: 914.5897
 COM of peaks: 40.46

Area under iodide front: 795.5688
 1/2 Area: 397.7844
 COM of iodide front: 27.71

Fully Penetrating Monitoring Well

TCE Data

Sample

t

TCE

delt t delt

Area Cumulative
TCE*delt Area

| | | | | | | |
|-----|--------|--------|------|-------|--------|---------|
| M3 | 7.40 | 40.25 | 7.40 | 10.35 | 416.63 | 416.63 |
| M6 | 13.30 | 36.06 | 5.90 | 4.78 | 172.18 | 588.81 |
| M8 | 16.95 | 29.76 | 3.65 | 3.55 | 105.65 | 694.46 |
| M11 | 20.4 | 24.519 | 3.45 | 3.38 | 82.75 | 777.21 |
| M13 | 23.70 | 20.21 | 3.30 | 5.63 | 113.66 | 890.87 |
| M17 | 31.65 | 16.86 | 7.95 | 5.85 | 98.60 | 989.47 |
| M19 | 35.40 | 12.55 | 3.75 | 4.32 | 54.27 | 1043.74 |
| M22 | 40.30 | 9.49 | 4.90 | 4.05 | 38.44 | 1082.18 |
| M24 | 43.50 | 11.69 | 3.20 | 2.95 | 34.50 | 1116.68 |
| M26 | 46.20 | 13.18 | 2.70 | 4.60 | 60.64 | 1177.32 |
| M31 | 52.70 | 13.53 | 6.50 | 4.55 | 61.58 | 1238.89 |
| M33 | 55.30 | 10.27 | 2.60 | 3.50 | 35.95 | 1274.84 |
| M37 | 59.70 | 12.54 | 4.40 | 4.35 | 54.53 | 1329.37 |
| M41 | 64.00 | 11.30 | 4.30 | 3.25 | 36.72 | 1366.09 |
| M43 | 66.20 | 12.86 | 2.20 | 1.95 | 25.07 | 1391.17 |
| M45 | 67.9 | 11.898 | 1.70 | 2.10 | 24.99 | 1416.15 |
| M47 | 70.40 | 10.30 | 2.50 | 4.70 | 48.40 | 1464.55 |
| M49 | 77.30 | 9.04 | 6.90 | 5.05 | 45.65 | 1510.20 |
| M51 | 80.50 | 6.55 | 3.20 | 3.35 | 21.94 | 1532.14 |
| M53 | 84 | 5.35 | 3.50 | 4.30 | 23.00 | 1555.14 |
| M55 | 89.1 | 9.849 | 5.10 | 5.33 | 52.50 | 1607.64 |
| M57 | 94.66 | 7.939 | 5.56 | 5.12 | 40.61 | 1648.25 |
| M59 | 99.33 | 7.613 | 4.67 | 6.81 | 51.84 | 1700.09 |
| M61 | 108.28 | 7.084 | 8.95 | 8.74 | 61.88 | 1761.97 |
| M63 | 116.80 | 5.43 | 8.52 | 8.52 | 46.29 | 1808.26 |

Area under desorption curve: 1808.258
 Initial concentration (Cmax): 40.25 ppb

Equivalent pulse-mean = $1808.26/40.25 = 44.93$ hr

Fully Penetrating Monitoring Well

TCA Data

| Sample | t | TCA | delt t | delt | Area TCA*delt | Cumulative Area |
|--------|--------|-------|--------|-------|------------------|--------------------|
| M3 | 7.40 | 30.68 | 7.40 | 10.35 | 317.53 | 317.53 |
| M6 | 13.30 | 28.47 | 5.90 | 4.78 | 135.93 | 453.46 |
| M8 | 16.95 | 23.10 | 3.65 | 3.55 | 82.00 | 535.46 |
| M11 | 20.4 | 19.38 | 3.45 | 3.38 | 65.40 | 600.86 |
| M13 | 23.70 | 16.03 | 3.30 | 5.63 | 90.17 | 691.03 |
| M17 | 31.65 | 13.15 | 7.95 | 5.85 | 76.91 | 767.94 |
| M19 | 35.40 | 9.72 | 3.75 | 4.32 | 42.02 | 809.96 |
| M22 | 40.30 | 7.33 | 4.90 | 4.05 | 29.68 | 839.64 |
| M24 | 43.50 | 8.93 | 3.20 | 2.95 | 26.33 | 865.97 |
| M26 | 46.20 | 10.40 | 2.70 | 4.60 | 47.84 | 913.81 |
| M31 | 52.70 | 10.44 | 6.50 | 4.55 | 47.52 | 961.33 |
| M33 | 55.30 | 7.87 | 2.60 | 3.50 | 27.53 | 988.86 |
| M37 | 59.70 | 9.76 | 4.40 | 4.35 | 42.46 | 1031.32 |
| M41 | 64.00 | 8.76 | 4.30 | 3.25 | 28.48 | 1059.80 |
| M43 | 66.20 | 9.89 | 2.20 | 1.95 | 19.29 | 1079.09 |
| M45 | 67.9 | 9.11 | 1.70 | 2.10 | 19.13 | 1098.22 |
| M47 | 70.40 | 8.12 | 2.50 | 4.70 | 38.16 | 1136.39 |
| M49 | 77.30 | 7.10 | 6.90 | 5.05 | 35.83 | 1172.22 |
| M51 | 80.50 | 5.05 | 3.20 | 3.35 | 16.92 | 1189.14 |
| M53 | 84 | 3.99 | 3.50 | 4.30 | 17.14 | 1206.28 |
| M55 | 89.1 | 7.77 | 5.10 | 5.33 | 41.44 | 1247.72 |
| M57 | 94.66 | 6.10 | 5.56 | 5.12 | 31.19 | 1278.90 |
| M59 | 99.33 | 5.67 | 4.67 | 6.81 | 38.63 | 1317.54 |
| M61 | 108.28 | 4.92 | 8.95 | 8.74 | 42.94 | 1360.48 |
| M63 | 116.80 | 3.78 | 8.52 | 8.52 | 32.21 | 1392.68 |

Area under desorption curve: 1392.683
 Initial concentration (Cmax): 30.68 ppb

Equivalent pulse-mean = $1392.68/30.68 = 45.39$ hr

| Extraction Well Iodide Data | | | | | Area | Cumulative |
|--------------------------------|--------|--------|--------|------|--------|------------|
| Sample | t | Iodide | delt t | delt | I*delt | Area |
| S1 | 0.36 | 0.04 | 0.36 | 3.38 | 0.14 | 0.14 |
| S3 | 6.40 | 0.05 | 6.04 | 7.22 | 0.36 | 0.50 |
| S6 | 14.80 | 0.08 | 8.40 | 5.95 | 0.48 | 0.97 |
| S8 | 18.30 | 0.15 | 3.50 | 4.10 | 0.61 | 1.59 |
| S13 | 23.00 | 0.27 | 4.70 | 2.95 | 0.80 | 2.38 |
| S14 | 24.20 | 0.43 | 1.20 | 1.30 | 0.56 | 2.94 |
| S15 | 25.60 | 0.65 | 1.40 | 1.20 | 0.78 | 3.72 |
| S16 | 26.60 | 0.77 | 1.00 | 1.43 | 1.10 | 4.83 |
| S28 | 28.47 | 1.22 | 1.87 | 1.38 | 1.68 | 6.51 |
| S19 | 29.35 | 1.57 | 0.88 | 1.62 | 2.54 | 9.04 |
| S21 | 31.70 | 2.3 | 2.35 | 2.22 | 5.12 | 14.16 |
| S22 | 33.80 | 2.91 | 2.10 | 2.65 | 7.71 | 21.87 |
| S24 | 37.00 | 4.2 | 3.20 | 2.90 | 12.18 | 34.05 |
| S26 | 39.60 | 4.99 | 2.60 | 2.85 | 14.22 | 48.27 |
| S29 | 42.70 | 6.28 | 3.10 | 2.60 | 16.33 | 64.60 |
| S31 | 44.80 | 7 | 2.10 | 2.60 | 18.20 | 82.80 |
| S34 | 47.90 | 8.26 | 3.10 | 2.05 | 16.93 | 99.73 |
| S35 | 48.90 | 8.3 | 1.00 | 1.50 | 12.45 | 112.18 |
| S37 | 50.90 | 9.58 | 2.00 | 1.50 | 14.37 | 126.55 |
| S38 | 51.90 | 9.4 | 1.00 | 1.10 | 10.34 | 136.89 |
| S39 | 53.10 | 9.72 | 1.20 | 1.00 | 9.72 | 146.61 |
| S40 | 53.90 | 11.07 | 0.80 | 0.90 | 9.96 | 156.58 |
| S41 | 54.90 | 10.98 | 1.00 | 1.05 | 11.53 | 168.10 |
| S42 | 56.00 | 11.16 | 1.10 | 1.55 | 17.30 | 185.40 |
| S44 | 58.00 | 10.37 | 2.00 | 2.65 | 27.48 | 212.88 |
| S47 | 61.30 | 10.4 | 3.30 | 2.80 | 29.12 | 242.00 |
| S49 | 63.60 | 9.52 | 2.30 | 2.15 | 20.47 | 262.47 |
| S51 | 65.60 | 9.1 | 2.00 | 1.90 | 17.29 | 279.76 |
| S53 | 67.40 | 8.6 | 1.80 | 1.90 | 16.34 | 296.10 |
| S55 | 69.40 | 8.2 | 2.00 | 2.00 | 16.40 | 312.50 |
| S57 | 71.40 | 7.4 | 2.00 | 2.00 | 14.80 | 327.30 |
| S59 | 73.40 | 6.7 | 2.00 | 2.05 | 13.73 | 341.04 |
| S61 | 75.50 | 6.3 | 2.10 | 2.15 | 13.54 | 354.58 |
| S63 | 77.70 | 5.6 | 2.20 | 2.05 | 11.48 | 366.06 |
| S65 | 79.60 | 5.53 | 1.90 | 2.25 | 12.44 | 378.50 |
| S67 | 82.20 | 5.1 | 2.60 | 2.45 | 12.50 | 391.00 |
| S68 | 84.50 | 3.91 | 2.30 | 3.05 | 11.93 | 402.92 |
| S70 | 88.30 | 3.71 | 3.80 | 3.90 | 14.47 | 417.39 |
| S72 | 92.30 | 3.41 | 4.00 | 4.05 | 13.81 | 431.20 |
| S74 | 96.40 | 3.3 | 4.10 | 4.10 | 13.53 | 444.73 |
| S76 | 100.50 | 3.1 | 4.10 | 6.05 | 18.75 | 463.49 |
| S78 | 108.50 | 2.27 | 8.00 | 7.95 | 18.05 | 481.53 |
| S80 | 116.40 | 1.92 | 7.90 | 6.05 | 11.62 | 493.15 |
| S81 | 120.60 | 1.19 | 4.20 | 6.35 | 7.56 | 500.71 |
| S83 | 129.10 | 1.44 | 8.50 | 8.25 | 11.88 | 512.59 |
| S85 | 137.10 | 1.1 | 8.00 | 8.05 | 8.85 | 521.44 |
| S87 | 145.20 | 0.99 | 8.10 | 8.05 | 7.97 | 529.41 |

Extraction Well

Iodide Data

| Sample | t | Iodide | delt t | delt | Area I*delt | Cumulative Area |
|--------|--------|--------|--------|-------|----------------|--------------------|
| S89 | 153.20 | 0.85 | 8.00 | 6.00 | 5.10 | 534.51 |
| S90 | 157.20 | 0.9 | 4.00 | 4.05 | 3.65 | 538.16 |
| S91 | 161.30 | 0.8 | 4.10 | 7.15 | 5.72 | 543.88 |
| S93 | 171.50 | 0.7 | 10.20 | 15.31 | 10.71 | 554.59 |
| S98 | 191.91 | 0.54 | 20.41 | 22.67 | 12.24 | 566.83 |
| S104 | 216.83 | 0.42 | 24.92 | 22.25 | 9.34 | 576.17 |
| S108 | 236.41 | 0.37 | 19.58 | 12.79 | 4.73 | 580.91 |
| S109 | 242.41 | 0.31 | 6.00 | 9.00 | 2.79 | 583.70 |
| S110 | 254.41 | 0.29 | 12.00 | 12.00 | 3.48 | 587.18 |

Area under Iodide peak: 587.1766
1/2 Area: 293.5883

COM for Iodide peak: 68.11